



Embedded Video Storage

User's Manual



Foreword

General

This manual introduces the functions and operations of the embedded video storage server (hereinafter referred to as "the Device"). Read carefully before using the device, and keep the manual safe for future reference.

Models






EVS7124D; EVS7148D



In the name EVS71XXD, XX refers to HDD number (24, or 48); D indicates that the Device is dual-controller type.

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 TIPS	Provides methods to help you solve a problem or save time.
 NOTE	Provides additional information as a supplement to the text.

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

Revision History

Version	Revision Content	Release Time
V2.0.1	Added virtual IP.	May 2022
V2.0.0	Added the functions such as one-click disarming, voice talk, and SSD health detection.	May 2022
V1.0.0	First release.	September 2020

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the Device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, and comply with the guidelines when using it.

Operation Requirements



- This is a class A product. In a domestic environment this may cause radio interference in which case you may be required to take adequate measures.
- The device is heavy and needs to be carried by several persons together to avoid personal injuries.



- Check whether the power supply is correct before use.
- Do not unplug the power cord on the side of the device while the adapter is powered on.
- Operate the device within the rated range of power input and output.
- Use the device under allowed humidity and temperature conditions.
- Do not drip or splash liquid onto the device, make sure that there is no object filled with liquid on the device to prevent liquid from flowing into it.
- Do not disassemble the Device.
- The device can only be used with batteries possessing internal protection.
- Your configurations will be lost after performing a factory reset. Please be advised.
- Do not restart, shut down or disconnect the power to the device during an update.
- Make sure the update file is correct because an incorrect file can result in a device error occurring.
- Do not frequently turn on/off the device. Otherwise, the product life might be shortened.
- Back up important data on a regular basis when using the device.
- Operating temperature: 0 °C to 45 °C (32 °F to 113 °F).
- Salt spray in the operating environment of the device might corrode its electronic components and cables. To ensure the normal operation of the device and prolong its service life, use the device in an indoor environment that is 3 kilometers away from the sea.

Installation Requirements



- Strictly comply with the local electric safety code and standards. Make sure the ambient voltage is stable and meets the power supply requirements of the device.

- Do not expose the battery to environments with extremely low air pressure, or extremely high or low temperatures. Also, it is strictly prohibited for the battery to be thrown into a fire or furnace, and to cut or put mechanical pressure on the battery. This is to avoid the risk of fire and explosion.
- Use the standard power adapter or cabinet power supply. We will assume no responsibility for any injuries or damages caused by the use of a nonstandard power adapter.



- Do not place the device in a place exposed to sunlight or near heat sources.
- Keep the device away from dampness, dust, and soot.
- Put the device in a well-ventilated place, and do not block its ventilation.
- Install the server on a stable surface to prevent it from falling.
- The device is a class I electrical appliance. Make sure that the power supply of the device is connected to a power socket with protective earthing.
- Use power cords that conform to your local requirements and rated specifications.
- Before connecting the power supply, make sure the input voltage matches the server power requirement.
- When installing the device, make sure that the power plug and appliance coupler can be easily reached to cut off power.
- Install the server in an area that only professionals can access.
- Extra protection is necessary for the device casing to reduce the transient voltage to the defined range.
- If you did not push the HDD box to the bottom, then do not close the handle to avoid damage to the HDD slot.
- Install the device near a power socket for emergency disconnect.
- It is prohibited for non-professionals and unauthorized personnel to open the device casing.
- Affix the device securely to the building before use.

Maintenance Requirements



- Make sure to use the same model when replacing the battery to avoid fire or explosion. Dispose the battery strictly according to the instructions on it.
- Power off the device before maintenance.



- AI module does not support hot plug. If you need to install or replace the AI module, unplug the device power cord first. Otherwise, it will lead to file damage on the AI module.

- The device casing provides protection for internal components. Use a screwdriver to loosen the screws before detaching the casing. Make sure to put the casing back on and secure it in its original place before powering on and using the device.
- It is prohibited for non-professionals and unauthorized personnel to open the device casing.
- The appliance coupler is a disconnection device. Keep it at a convenient angle when using it. Before repairing or performing maintenance on the device, first disconnect the appliance coupler.

Transportation Requirements



Transport the device under allowed humidity and temperature conditions.

Storage Requirements



Store the device under allowed humidity and temperature conditions.

Table of Contents

Foreword	I
Important Safeguards and Warnings	III
1 Overview	1
1.1 Introduction.....	1
1.2 Front Panel.....	1
1.3 Rear Panel.....	3
1.4 Menu Items.....	4
2 Installation and Powering Up	5
2.1 Installing HDD.....	5
2.2 Powering Up.....	7
2.2.1 Preparation.....	7
2.2.2 Powering up the Device.....	7
3 Initial Settings	8
3.1 Initializing the Device.....	8
3.2 Quick Settings.....	11
3.3 Login.....	13
3.3.1 Logging in to PCAPP Client.....	13
3.3.2 Logging in to Web Interface.....	17
3.4 Configuring Remote Device.....	18
3.4.1 Initializing Remote Device.....	18
3.4.2 Adding Remote Device.....	23
4 AI Operations	34
4.1 Face Detection.....	34
4.1.1 Enabling AI Plan.....	34
4.1.2 Configuring Face Detection.....	35
4.1.3 Live View of Face Detection.....	37
4.1.4 Face Search.....	40
4.2 Face Recognition.....	44
4.2.1 Enabling AI Plan.....	44
4.2.2 Configuring Face Recognition.....	44
4.2.3 Live View of Face Recognition.....	45
4.2.4 Face Search.....	47
4.3 People Counting.....	49
4.3.1 Enabling AI Plan.....	49
4.3.2 People Counting.....	49
4.3.3 Queuing Detection.....	50
4.3.4 Live View.....	52
4.4 Video Metadata.....	52
4.4.1 Enabling AI Plan.....	53
4.4.2 Configuring Video Metadata.....	53
4.4.3 Live View of Video Metadata.....	54
4.4.4 AI Search.....	57

4.5 IVS	64
4.5.1 Enabling AI Plan	64
4.5.2 Configuring IVS	64
4.5.3 Live View of IVS	69
4.5.4 IVS Search	72
4.6 Vehicle Recognition	73
4.6.1 Enabling AI Plan	74
4.6.2 Setting Vehicle Recognition	74
4.6.3 Live View of Vehicle Recognition	74
4.6.4 Searching for Detection Information	77
4.7 Crowd Distribution Map	77
4.7.1 Enabling AI Plan	77
4.7.2 Configuring Crowd Distribution Map	77
4.7.3 Live View of Crowd Distribution	79
4.8 Call Alarm	80
4.8.1 Enabling AI Plan	80
4.8.2 Configuring Call Alarm	80
4.8.3 Live View of Call Alarm	82
4.9 Smoking Alarm	82
4.9.1 Configuring Smoking Alarm	82
4.9.2 Live View of Smoking Alarm	83
5 General Operations	84
5.1 Live and Monitor	84
5.1.1 View Management	85
5.1.2 Resources Pool	101
5.1.3 PTZ	102
5.2 Recorded Files	110
5.2.1 Playing Back Recorded Video	111
5.2.2 Clipping Recorded Video	115
5.2.3 Playing Back Snapshots	116
5.2.4 Exporting File	118
5.2.5 Video Tag	121
5.2.6 Locking Files	121
5.3 Alarm List	122
5.4 System Information	123
5.5 Background Task	123
5.6 Buzzer	124
6 System Configuration	125
6.1 Configuration Page	125
6.2 Device Management	125
6.2.1 Viewing Device Information	126
6.2.2 Remote Devices	127
6.3 Network Management	141
6.3.1 Basic Network	141
6.3.2 Network Apps	148

6.4 Event Management.....	161
6.4.1 Alarm Actions.....	161
6.4.2 Local Device.....	167
6.4.3 Remote Device.....	174
6.5 Storage Management.....	180
6.5.1 Local Hard Disk.....	180
6.5.2 RAID.....	183
6.5.3 Network Hard Disk.....	190
6.5.4 FTP/SFTP.....	192
6.6 Video Recording.....	194
6.6.1 Storage Mode.....	194
6.6.2 Recording Schedule.....	199
6.6.3 Basic.....	201
6.6.4 Record Transfer.....	202
6.7 Security Strategy.....	203
6.7.1 HTTPS.....	204
6.7.2 Configuring Access Permission.....	208
6.7.3 Safety Protection.....	210
6.7.4 Enabling System Service Manually.....	211
6.7.5 Configuring Firewall.....	212
6.7.6 Configuring Time Synchronization Permission.....	213
6.8 Account Management.....	214
6.8.1 User Group.....	214
6.8.2 Device User.....	217
6.8.3 Password Maintenance.....	219
6.8.4 ONVIF.....	224
6.9 System Configuration.....	227
6.9.1 Setting System Parameters.....	227
6.9.2 System Time.....	228
6.9.3 Schedule.....	230
6.10 Network Storage.....	231
6.10.1 Creating Storage Pool.....	232
6.10.2 Managing Share Account.....	233
6.10.3 Configuring Share Folder.....	234
6.10.4 Configuring Share Control.....	236
6.10.5 Configuring FTP Parameters.....	237
7 System Management.....	238
7.1 File Management.....	238
7.1.1 Video Tag Management.....	238
7.1.2 FILE LOCKED.....	238
7.1.3 Watermark Verification.....	239
7.2 Task Management.....	240
7.3 Backup.....	243
7.4 AI Report.....	245
7.4.1 In-area People Counting Report.....	245

7.4.2 Queue People Counting Report	247
8 System Maintenance	249
8.1 Overview	249
8.2 System Information	250
8.2.1 Viewing Device Information	250
8.2.2 Viewing Legal Information	250
8.3 System Resources	250
8.4 Logs	251
8.5 Intelligent Diagnosis	253
8.5.1 Run Log	253
8.5.2 One-click Export	253
8.5.3 One-click Diagnosis	254
8.6 Network Care	254
8.6.1 Online User	254
8.6.2 Packet Capture	255
8.7 Device Maintenance	256
8.7.1 Upgrading Device	256
8.7.2 Default	258
8.7.3 Automatic Maintenance	258
8.7.4 IMP/EXP	259
8.8 Disk Maintenance	259
8.8.1 S.M.A.R.T Detection	260
8.8.2 Health Monitoring	260
8.8.3 SSD Health Detection	260
8.8.4 Firmware Update	260
9 PCAPP Introduction	262
9.1 Page Description	262
9.2 History Record	262
9.3 Viewing Downloads	263
9.4 Configuring PCAPP	263
9.5 Viewing Version Details	265
10 Log Out, Reboot, Shut Down, Lock	266
Appendix 1 Particulate and Gaseous Contamination Specifications	268
Appendix 1.1 Particulate Contamination Specifications	268
Appendix 1.2 Gaseous Contamination Specifications	268
Appendix 2 RAID	270
Appendix 3 Glossary	272
Appendix 4 Cybersecurity Recommendations	274

1 Overview

1.1 Introduction

The Device is designed for the management, storage and application of high-definition video data. It uses Linux operation system and professional customized hardware platform, and it is configured with multiple Hard Disk Drive (HDD) management system, front-end HD device management system, HD video analysis system and large capacity video storage system.

It adopts high-traffic data network transmission & forward technology and multi-channel video decoding & display technology, and realizes intelligent management, secure storage, fast forwarding and HD decoding of large capacity and multi-channel HD video data.

The Device provides standard network file sharing service and offers integrated network storage solution. It provides centralized storage solutions with large capacity, high scalability and high security for all kinds of video monitoring systems.

1.2 Front Panel

Figure 1-1 EVS7124D




Figure 1-2 EVS7148D




Table 1-1 Front panel description

No.	Name	Description
1	Power button	Turns on or off the Device. <ul style="list-style-type: none"> ● If the Device is off, press this button to turn the Device on. ● To turn off the Device, press and hold this button for 5 seconds.
2	HDD status indicator	<ul style="list-style-type: none"> ● The light is off when the HDD is in normal operation. ● The light is solid red if no HDD, HDD error or insufficient HDD space.
3	Alarm status indicator	<ul style="list-style-type: none"> ● The light is off when the Device is running properly. ● The light is solid red when the power, temperature or fan is abnormal.
4	Network status indicator	The light is solid red if there is a network failure, IP conflict or MAC conflict.
5	USB ports	Connect to external USB devices, such as flash drive.

1.3 Rear Panel

Figure 1-3 EVS7124D




Figure 1-4 EVS7148D





Table 1-2 Rear panel ports









No.	Port	Description
1	Power module	Connects to AC power supply. Contains fans for case cooling.
2	RS-232	Used to debug general serial ports, configure IP address and transmit transparent serial data.
	WEB	Gigabit management port. Can be used as data port.
	SAS HD	Connects to the expansion cabinet.  The SAS HD ports might differ depending on the device you are using. We recommend using SAS HD2.
	eSATA	Connects to external storage devices.

No.	Port	Description
	USB 3.0	Connects the mouse or USB storage devices.
	EX-1-EX-4/1-4	Gigabit Ethernet ports. Used to transfer data.
	HDMI	Outputs high definition video data and multi-channel audio data to external displays.
	PCI-E	High-speed expansion port, connects to components with X4 or X8 plug.

1.4 Menu Items

This section introduces the icons and buttons you will frequently use when using the Device.

Table 1-3 Icons and buttons

Icon/Button	Description
	Restore default configuration.
	Get the latest configuration information.
	Save the modified configuration.
	
	Cancel the modified configuration and close the window.
<input type="checkbox"/>	Checkbox. You can select multiple configuration items at the same time.  : Selected.
<input type="radio"/>	Radio button. You can select a configuration item.  : Selected.
	Drop-down list. Click this icon to display the drop-down menu.

2 Installation and Powering Up

2.1 Installing HDD


The HDD is not installed by default on factory delivery. You need to install it by yourself.

 **WARNING**

Some devices are heavy and should be carried jointly by several persons to avoid injury.

Step 1 Press the red button on the disk tray to unlock the handle.

Figure 2-1 Open the handle




Step 2 Pull out the empty disk tray.

Figure 2-2 Disk tray



Step 3 Put the disk into the disk tray and fasten the screws at the bottom of the tray.

Figure 2-3 Fasten the screws



Step 4 Insert the disk tray into the HDD slot, push it to the bottom and lock the handle.



To avoid any damage to the slot, do not lock the handle until the disk tray has been pushed to the bottom.

2.2 Powering Up

2.2.1 Preparation

Properly connect the cables before powering up the Device and check against the following items:

- Make sure that all power lines are connected correctly.
- Check whether the supplied power voltage complies with device requirements.
- Check whether the network cables and SAS cables are connected correctly.

2.2.2 Powering up the Device

Press the power button on the front panel, and then check whether the indicators are normally displayed.

- When the indicators are normal, the Device is powered up successfully.
- If the indicators are abnormal, solve the problems and then power up the Device again.

3 Initial Settings

When using EVS for the first time, initialize the Device, and set basic information and functions first.

3.1 Initializing the Device

If it is your first time to use the Device after purchasing or after restoring factory defaults, set a login password of admin (system default user). At the same time, you can set proper password protection method.



This section uses web remote initialization for example.

Step 1 Open the browser, enter IP address, and then press the Enter key.



The default IP addresses of network port 1 to network port n in slot 1 are 192.168.1.108 to 192.168.n.108. Enter the corresponding IP address of the actually connected network port.


Step 2 On the **Language Set** page, select a country or region, a language, and a language standard. Click **Next**. The language setting step is only available on the local interface of the Device.

Figure 3-1 Time setting

Step 3 On the **Time** page, set time parameters.

Table 3-1 Time parameters description

Parameters	Description
Time Zone	The time zone of the Device.

Parameters	Description
Time	Set system date and time manually or by synchronizing with NTP server time. <ul style="list-style-type: none"> Manual setting: Select date and time from the calendar. Sync with Internet Time Server: Select Sync with Internet Time Server, enter NTP server IP address or domain, and then set the automatic synchronization interval.  Device time will synchronize with the server time after Sync with Internet Time Server is set.

Step 4 Click **Next**.

Figure 3-2 Set password

Step 5 Set admin login password.

Table 3-2 Description of password parameters

Parameters	Description
Username	The default username is admin.
Password	Set admin login password, and confirm the password. The password must consist of 8–32 non-blank characters and contain at least two types of the following characters: uppercase, lowercase, number, and special character (excluding ' " ; : &). Enter a strong password according to the password strength indication.
Confirm Password	

Step 6 Click **Next**.

Figure 3-3 Password protection

Step 7 Set password protection information.

You can use the email you set here to reset admin password. See "6.8.3.2 Resetting Password" for detailed information.

- 1) Click to enable email.
- 2) Enter an email address in the **Email** box.

Step 8 Click **Finish** to complete device initialization.

The device initialization success page is displayed. Click **Enter quick settings** to go to the quick setting page, and then set device basic information. See "3.2 Quick Settings" for details.

Figure 3-4 Initialization completed

3.2 Quick Settings

After initializing the Device, the system goes to quick settings page. You can quickly configure system time, and network settings.



Make sure that at least one Ethernet port has connected to the network before you set IP address.

Step 1 On the completion page of initialization, click **Enter Quick Setting**.

Figure 3-5 IP setting

Quick Configuration

1 IP Set

Enable ⚠ It is recommended that virtual IP address and default NIC IP address should be in the same network segment.

IP Address Subnet Mask

Default Gateway

Slot Slot1

NIC	NIC Type	Dhcp	IP Address	Subnet Mask	Mac	Speed	Operate
● Ethernet ...	Electric Port	No	192.168.1.127	255.255.255.0		10M/100M/10...	
● Ethernet ...	Electric Port	No	192.168.2.108	255.255.255.0		10M/100M/10...	
● Ethernet ...	Electric Port	No	192.168.3.108	255.255.255.0		10M/100M/10...	
● Ethernet ...	Electric Port	No	192.168.4.108	255.255.255.0		10M/100M/10...	

DNS Server Default NIC

IP Type IPv4 Default Ethernet Ethernet Network1

Obtain DNS server address automatically

Use the following DNS server address

Preferred DNS

Alternate DNS

Finish

Step 2 Click to enable the virtual IP address, and then set the virtual IP address, subnet mask and default gateway.

The main board and standby board have their respective physical IP. After setting the virtual IP, despite the switch between the main and standby boards, you can always log in to the web interface with the virtual IP.



The default virtual IP address is 192.168.0.108. We recommend you set the virtual IP address and the IP address of the default NIC on the same network segment.


Step 3 Select a slot from **Slot1** and **Slot2** and then set the NICs in each slot.

1) Click of the corresponding NIC.

Figure 3-6 Edit Ethernet network

2) Set parameters.

Table 3-3 TCP/IP parameters description

Parameters	Description
Speed	Current NIC max network transmission speed.
IP Type	Select IPv4 or IPv6.
Use dynamic IP address	When there is a DHCP server on the network, check Use Dynamic IP Address , system can allocate a dynamic IP address to the Device. There is no need to set IP address manually.
Use static IP address	Check Use Static IP Address , and then set static IP address, subnet mask and gateway to set a static IP address for the Device.
MTU	Set NIC MTU value. The default setup is 1500 Byte. We recommend you check the MTU value of the gateway first and then set the Device MTU value equal to or smaller than the gateway value. Reduce the packets slightly and enhance network transmission efficiency.  Changing MTU value might result in NIC reboot, network offline and affect current running operation. Please be careful!

3) Click **OK**.

Device goes back to **IP Set** page.

Step 4 Set DNS server information.

You can select to get DNS server manually or enter DNS server information.



This step is compulsive if you want to use domain service.

- 1) Select an IP type for DNS server. You can select IPv4 or IPv6.
- 2) Select the way of setting DNS IP address.

- ◇ Select **Obtain DNS server address automatically**, and then the Device can automatically get the DNS server IP address on the network.
- ◇ Select **Use the following DNS server address**, and then enter the preferred DNS IP address and the alternate DNS IP address.

Step 5 Set default NIC.

Select default NIC from the drop-down list.



Make sure that the default NIC is online.

Step 6 Click **Next** to save settings.

3.3 Login

You can access and manage the Device remotely by using the PCAPP (PC client), or the web interface.


3.3.1 Logging in to PCAPP Client

Log in to the PCAPP for system configuration and operation.

Step 1 Download PCAPP.

- 1) Open the browser, enter IP address, and press Enter.

Figure 3-7 Web login



- 2) Click **Download PCAPP** to download PCAPP installation package.

Step 2 Install PCAPP.

- 1) Double-click the PCAPP installation package.
The installation page is displayed.

Figure 3-8 Installation page




- 2) Select a language of the PCAPP.
- 3) Click **EULA**, read through the content, and then select the checkbox of **I Agree EULA**.
- 4) (Optional) Click **Custom** and then select an installation path and create shortcut.

Figure 3-9 Custom installation




- 5) Click **Install**.
On completion, the completion page is displayed.

Figure 3-10 The installation is completed



Step 3 Log in to PCAPP.

1) There are two ways to enter PCAPP.

- On the installation completion page, click **Run**.
- Double-click the shortcut icon  on the PC desktop.




- When PC theme is not Aero, the system will remind you to switch the theme. See Figure 3-11. To ensure video smoothness, switch your PC to Aero theme. For details, see "9.4 Configuring PCAPP".
- System display PCAPP at full-screen by default. Click  to display the task column. See Figure 3-12.

Figure 3-11 Prompt




Figure 3-12 Initial page





2) Enter device IP address, and then press Enter or click .

Figure 3-13 Login



3) Enter device username and password.



- Click **Login**. For your device safety, change the admin password regularly and keep it well.
- In case you forgot password, click **Forgot password** to reset. See "6.8.3.2 Resetting Password" for detailed information.

4) Select the login type among TCP, UDP and Multicast. Keep it TCP if you have no special requirement for TCP or UDP.

5) Click **Login**.

Figure 3-14 Home page







Table 3-4 Home page description

No.	Name	Description
1	Task column	Displays enabled application icon. Point to the app and then click  to close the app.  The live function is enabled by default and cannot be closed.
2	Add icon	Click to display or hide the app page. Open the app page to view or enable app.
3	Operation page	Displays currently enabled app operation page.
4	System information	Click to view system information. See "5.4 System Info" for detailed information.
5	One-click diagnosis	Check the configuration and status of the Device through one-click diagnosis for better use of the Device.
6	Buzzer	Click the icon to view buzzer messages. For details, see "5.6 Buzzer".
7	Background task	Click to view the background running task information. See "5.5 Background Task" for detailed information.
8	System configuration	Click to enter system configuration mode. See "6 System Configuration" for detailed information.
9	Login user	Click it to change user password, lock user, logout user, reboot device or close device.
10	Quick settings	Click this icon and select Video or Network Storage to go to the STORAGE page.
11	Alarm list	Click to view the unprocessed alarm event quantity. See "5.3 Alarm List" for detailed information.  Drag this icon to move its position.

3.3.2 Logging in to Web Interface


System supports general browser such as Google Chrome, Firefox to access the web to manage the Device remotely, operate and maintain the system.



When you are using general browser to access the web, system supports setting function only. It cannot display the view. It is suggested that PCAPP should be used.

Step 1 Open the browser, enter IP address, and then press Enter.

Figure 3-15 Web login



Step 2 Enter username and password.



- Click Login. For your device safety, change the admin password regularly and keep it well.
- In case you forgot password, click **Forgot password** to reset. See "6.8.3.2 Resetting Password" for detailed information.

Step 3 Select the login type among TCP, UDP and Multicast. Keep it TCP if you have no special requirement for TCP or UDP.

Step 4 Click **Login**.

System displays **LIVE** page.

3.4 Configuring Remote Device

Register remote device to the system. Here you can view the live video from the remote device, change remote device settings, and so on.

3.4.1 Initializing Remote Device

After you initialize the remote device, you can change remote device login password and IP address. Remote devices can be connected to the Device only after being initialized.



Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Figure 3-16 Device management

Channel No.	State	Channel Name	Address	Register ID	Port	User Name	Password	Manufacturer	Product Model	Sn	Remote Ch.	Operate
2	●	49	10.10.10.10	---	80	admin	*****	Onvif	D-...	Z-...	1	⚙️
4	●	IPC	10.10.10.10	---	37777	admin	*****	Private	IP-...	SN-...	1	⚙️
6	●	30	10.10.10.10	---	37777	315258	*****	Private	D-...	SN-...	1	⚙️
7	●	2	10.10.10.10	---	80	admin	*****	Onvif	L-...	SN-...	1	⚙️
8	●	12	10.10.10.10	---	37777	315258	*****	Private	D-...	SN-...	2	⚙️

Step 2 On the **Device List** page, click **Add**.

Step 3 On the **Smart Add** page, click **Smart Search**.



To set search conditions, you can click

Figure 3-17 Remote device

(0)	Initialization State	Address	Product Model	Manufacturer	Port	Product Type	Sn	Operate
<input type="checkbox"/>	✓ Initialized	Private	37777	IPC	2G02FEPA...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	IPC	YZC4DZ032...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	CN6000	YZC3MW012...	⚙️ LEVE
<input type="checkbox"/>	✗ Uninitialized	Private	37777	IPC	5C00C36YA...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	IPC	PZC4CV094...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	IPC	1A02C04YAZ...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	NVR	2J05923YAZ...	⚙️ LEVE
<input type="checkbox"/>	✓ Initialized	Private	37777	EVS	4M04904VA	⚙️ LEVE

Total 20 Item(s) Show up to 50

Remaining Bandwidth/Total: 1018.06 Mbps/ 1024 Mbps

Step 4 Select the uninitialized remote device and then click **Initialize**.



Click **Initialization status** and then select **Uninitialized**, you can quickly filter the uninitialized remote device.

Figure 3-18 Initializing the Device

Step 5 Set remote device password and password protection.



Using current device password and password protection information is enabled by default. Keep it enabled so as to automatically use current device admin password and email information without manual configuration. Go to Step 6 if you keep it enabled.

- 1) To manually configure password, click to disable Using current device password and password protection information.

Figure 3-19 Password setting


- 2) Set parameters.

Table 3-5 Description of password parameters

Parameters	Description
Username	The default username is admin.
Password	In the New Password box, enter the new password and enter it again in the Confirm Password box.
Confirm Password	The password should consist of 8 to 32 non-blank characters and contain at least two types of characters among uppercase, lowercase, number, and special character (excluding ' " ; : &). Enter a strong password according to the password strength indication.

3) Click **Next**.

Figure 3-20 Password protection



4) Set an email address.

Enter an email address. You can use the email address here to reset password in case you forgot password in the future.

Step 6 Click **Next**.

Figure 3-21 Modify IP

The screenshot shows a 'Device Initialization' window with three steps: 'Password', 'Password Protection', and '3 Modify IP'. The 'Modify IP' step is active. It features a table with columns for '(1) Sn' and 'IP Address'. Below the table, there are input fields for 'Static IP Address', 'Subnet Mask', and 'Gateway', each with a placeholder '- . - .'. An 'Incremental Value' field is set to '1'. At the bottom right, there are 'Back', 'Next' (highlighted in blue), and 'Cancel' buttons.

Step 7 Set camera IP address.


- When there is DHCP server in the network, select DHCP, and the remote device gets dynamic IP address automatically. It is unnecessary to enter IP address, subnet mask and gateway.
- Select **Static**, and then enter static IP address, subnet mask, default gateway and incremental value.



- After you enter incremental value, system can add the fourth address of the IP address one by one to automatically allocate the IP addresses.
- If you want to change several devices IP addresses at the same time, system allocates IP address of the same network segment.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. If batch change IP address, device automatically skips the conflicted IP and begins the allocation according to the incremental value.

Step 8 Click **Next**.

Figure 3-22 Initialize



Step 9 Click **Confirm and Add**, or click **OK**.

- Click **Confirm and Add**: System completes initializing the remote device and then adds the remote device to the list. System goes back to **Add device** page.
- Click **OK**: System completes initializing remote device. System goes back to **Add device** page.


3.4.2 Adding Remote Device

Device supports smart add, manual add and template add.

Table 3-6 Add mode

Add Mode	Description
Smart Add	Search for the remote devices on the same network and then filter to register. For details, see "3.4.2.1 Smart Add". It is useful if you do not know the exact IP address.
Manual Add	Enter the IP address, username and password of remote device. For details, see "3.4.2.2 Manual Add". For some remote devices, you can enter IP address, username, and password to register.
RTSP	Add remote devices through RTSP. For details, see "3.4.2.3 RTSP". To add stream media devices, you are recommended to choose RTSP.
Batch add (by CSV template)	Fill in information about remote device in the template, import the template to add the Device. For details, see "3.4.2.4 Batch Add". For batch adding, when IP address, username and other information of remote device is inconsistent, it is suggested to use this mode.

3.4.2.1 Smart Add

Step 1 Click , and then select **DEVICE**.


Step 2 Click  or **Add**, and then select **Smart Add**.









Figure 3-23 Smart add

Add Device
✕

Smart Add
Manual Add
RTSP
Batch Import

▶ Start Search

🔑 Password
🔍 Initialize
✎ Modify IP
🔼

(1)	Initialization State	Address	Product Model	Manufacturer	Port	Product Type	Sn	Operate
<input checked="" type="checkbox"/>	✓ Initialized	192.168.1.101	IPC-HFW148S	Onvif	80	--	--	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.102	IPC-HFW148S	Onvif	80	--	--	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.103	IPC-HFW148S SR_2	Onvif	80	--	--	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.104	IPC-HFW148S SR_2	Onvif	80	--	--	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.105	IPC-HFW136S	Private	37777	IPC-HFW136S	4M04994YA...	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.106	IPC-HFW136S	Private	37777	IPC-HFW136S	4M04994YA...	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.107	IPC-HFW136S	Private	37777	IPC-HFW136S	4M04994YA...	 LIVE
<input type="checkbox"/>	✓ Initialized	192.168.1.108	IPC-HFW116	Private	37777	IPC-HFW116	1.000.0000.0.R	 LIVE

Total 8 Item(s) Show up to 50

⏪
⏩
1/1
⏴
⏵
GO

Remaining Bandwidth/Total: 1024.00 Mbps/ 1024 Mbps

Add
Cancel

Step 3 Click Start Search.



To set search conditions, you can click .

Figure 3-24 Search results

<input checked="" type="checkbox"/> (1)	Initialization State	Address	Product Model	Manufacturer	Port	Product Type	Sn	Operate
<input checked="" type="checkbox"/>	✓ Initialized	192.168.1.101	148S	Onvif	80	--	--	
<input type="checkbox"/>	✓ Initialized	192.168.1.102	148S	Onvif	80	--	--	
<input type="checkbox"/>	✓ Initialized	192.168.1.103	SR_2	Onvif	80	--	--	
<input type="checkbox"/>	✓ Initialized	192.168.1.104	SR_2	Onvif	80	--	--	
<input type="checkbox"/>	✓ Initialized	192.168.1.105	136S	Private	37777	IP	4M04994YA...	
<input type="checkbox"/>	✓ Initialized	192.168.1.106	136S	Private	37777	IP	4M04994YA...	
<input type="checkbox"/>	✓ Initialized	192.168.1.107	136S	Private	37777	IP	4M04994YA...	
<input type="checkbox"/>	✓ Initialized	192.168.1.108	0116	Private	37777	IP	1.000.0000.0.R	


Total 8 Item(s) Show up to 50

Remaining Bandwidth/Total: 1024.00 Mbps/ 1024 Mbps

Table 3-7 Result description

Parameters	Description
Start Search	Click Start Search to start searching remote device. Now it becomes Stop Search . Click Stop Search to stop searching remote device.
Password	Enter the username and password of the selected device for adding it.
Initialize	Select uninitialized remote device and then click Initialize to initialize remote device. See "3.4.1 Initializing Remote Device" for detailed information.
Modify IP	See "6.2.2.2 Changing IP Address" to change the registered device IP address.
Initialization State	Displays remote device initialization status. Click ▼ to filter initialized or uninitialized remote device.
Operation	Click to display real-time video from the remote device. See Figure 3-24. Click or Close to close the real-time preview window. You can view the live video if admin password of the remote device is admin, or remote device admin password is the same as the system.
Bandwidth	Displays bandwidth remaining and the total bandwidth.

Figure 3-25 Live view



Step 4 Add a remote device.

Select a remote device, click **Password**, and then enter the username and password of the selected device. Click **OK**.



- If you do not enter device username and password, the system will try to add the Device by using the username and password of the current EVS.
- During the adding process, click **Cancel**, you can cancel adding process. Click **Stop** button of the corresponding remote device to cancel add.

Step 5 Click **Add**. The confirmation page is displayed.



- Double-click remote device IP address, username, password, manufacturer, port to change corresponding information.
- If system fails to add the remote device, see the reason on the **Status** column to change the remote device information and then click **Retry** to try to add again.
- If a remote device is exception due to network disconnection other reasons, it can also be added. It comes online after the exception is resolved.


Figure 3-26 Confirm

Add Confirm - X						
Address	User Name	Password	Manufacturer	Port	Channel No	Status
<input type="text"/>	admin	*****	Private	37777	Auto Allocation	Added
Remaining Bandwidth/Total: 996.96 Mbps/ 1024 Mbps					<input type="button" value="Continue to add"/> <input type="button" value="Finish"/>	

Step 6 Click **Continue** to add or **Finish**.

- Click **Continue to add**, device goes back to **Smart add** page to add more remote device.
- Click **Finish** to complete adding remote device process. Device displays **Device** page to view the newly added remote device information.

3.4.2.2 Manual Add

Step 1 Click , and then select **DEVICE**.


Step 2 Click , and then select **Manual add**.

Figure 3-27 Manual add





Step 3 Click Add Device.

Figure 3-28 Add device

Step 4 Set parameters.

Table 3-8 Parameters of manual add

Parameters	Description
Channel No.	Select a channel number for the remote device on IVSS. If you select Auto Allocation , IVSS will provide a channel number automatically.

Parameters	Description
Manufacturer	Displays the connection protocol of the remote device. Default protocol of the system is Private . Click Private to select other protocols.
IP Address	Enter the IP address of the remote device.
Device SN	Enter the unique SN allocated by the server for the remote device.  When the Manufacturer is Register , you need to configure this parameter.
RTSP Mode	Select Self-adaptive or Customize . If the mode is Customize , enter the RTSP port number.
RTSP Port	 When the Manufacturer is Onvif or Onvifs , the two parameters are available.
HTTP Port	Enter the HTTP port number. The default port number is 80. The value ranges from 1 through 65535. After changing the HTTP port number, you need to add the HTTP port number to the IP address in the address bar of the browser for login.
HTTPS Port	Enter the HTTP port number. The default port number is 80. The value ranges from 1 through 65535.  When the Manufacturer is Onvifs , you need to configure this parameter.
User Name	Enter the username and password of the remote device.
Password	
Port	Enter the port number of the remote device.  When the Manufacturer is Private , you need to configure this parameter.
Remote CH No.	Select the channel number for the remote device. 1. Select a link type. 2. To get the total number of channels, click Connect . 3. Enter the range of channels you need, and then click Selected . 4. Click OK .

Step 5 Select the remote device and then click **Add**. Device begins adding remote device and pops up the confirmation page.



- During the adding process, click **Cancel**, you can cancel adding process. Click **Stop** button of the corresponding remote device to cancel.
- Double-click remote device IP address, username, password, manufacturer, port to change corresponding information.

- If system fails to add the remote device, see the reason on the **Status** column to change the remote device information and then click **Retry** to try to add again. See Figure 3-29.
- If a remote device is exception due to network disconnection other reasons, it can also be added. It comes online after the exception is resolved.


Figure 3-29 Confirm

Add Confirm - X						
Address	User Name	Password	Manufacturer	Port	Channel No	Status
<input type="text"/>	admin	*****	Private	37777	Auto Allocation	Added
Remaining Bandwidth/Total: 996.96 Mbps/ 1024 Mbps					<input type="button" value="Continue to add"/> <input type="button" value="Finish"/>	

Step 6 Click **Continue** to add or Finish.

- Click **Continue to add**, device goes back to **Smart add** page to add more remote device.
- Click **Finish** to complete adding remote device process. Device displays **Device** page to view the newly added remote device information.

3.4.2.3 RTSP

Step 1 Click , and then select **DEVICE**.

Step 2 In the **Device List** page, click **Add**.

Step 3 Click **RTSP**.

Figure 3-30 RTSP

Step 4 Enter RTSP address as required.


RTSP address format is `rtsp://<username>:<password>@<IP address >:<port>/cam/realmonitor?channel=1&subtype=0`.

- Port: 554 by default.
- Channel: The channel number of the stream media device to be added.
- Subtype: Stream type. 0 for main stream, and 1 for sub stream.

Step 5 Select a channel No.

Step 6 Click **Add**.

3.4.2.4 Batch Add

Step 1 Click , and then select **DEVICE**.




Step 2 Click , and then select **Import CSV file** tab.

Figure 3-31 Batch import

Step 3 Fill in template file.

- 1) Click **Download Template** to download template file.

File path might vary depending on page operations, and slight difference might be found on the actual page.

- At PCAPP, click , and then select **Download** to view file saving path. For details, see "9.3 Viewing Downloads".
- Select file saving path during local operation.

Connect USB device to the system if you are on the local menu to operate.
- During web operations, files are saved under default downloading path of the browser.

- 2) Fill in template file and save according to your actual situation.

The following information of template file shall be filled in.



If information about remote device is not filled in completely, improve it after importing template.

Figure 3-32 Template

Address	Regist ID	Port	Channel No.	Channel Name	Manufacturer	User Name	Password	Link Type	Remote CH No.	Product Model	SN

Step 4 Import template file.

- 1) Click **Browse** to select the upgrade file.
- 2) Select an import mode and then click **Import**.

- **Overwrite:** The system removes the added remote devices before importing new devices.



If you select **Overwrite**, all the existing devices will be deleted.

- **ADD:** The system imports remote devices without deleting the existing ones.

Step 5 Select the remote device and then click **Add**.



- If information about remote device is not filled in completely, improve it after importing template.
- If the system fails to add the remote device, check the reason on the **Status** column, change the remote device information and then click **Retry** to try to add again.

Figure 3-33 Confirm

Add Confirm - X						
Address	User Name	Password	Manufacturer	Port	Channel No	Status
<input type="text"/>	admin	****	Private	37777	Auto Allocation	Added
Remaining Bandwidth/Total: 996.96 Mbps/ 1024 Mbps					<input type="button" value="Continue to add"/> <input type="button" value="Finish"/>	

Step 6 Click Continue to add or Finish.

- Click **Continue to add**, device goes back to **Smart add** page to add more remote device.
- Click **Finish** to complete adding remote device process. Device displays **Device manager** page to view the newly added remote device information.

4 AI Operations

In addition to the basic video monitoring functions, the Device can also provide a number of AI functions including face recognition, people counting, video metadata, vehicle recognition, and IVS (behavior detections such as fence-crossing, intrusion, loitering, crowd gathering, parking and more.). This chapter introduces how to configure the AI functions respectively.

The AI detections are done by camera (AI by Camera). The intelligent analysis job is completed on the camera, and EVS just receives and processes the results.



- The AI functions might vary depending on the Device function capability.
- To use AI by Camera, complete AI detection configuration at remote device. See remote device user's manual.
- The **AI by Camera** tab does not appear if the current camera does not support this function.
- Some AI features are conflicting. Do not enable conflicting AI features at the same time.

4.1 Face Detection



System triggers alarms when human faces are detected within the detection zone.

4.1.1 Enabling AI Plan

You need to enable AI plan first.



- AI plan is available on select models.
- You need first enable the corresponding AI plan; otherwise the AI function does not work.
- The Device automatically shows the AI functions available on the connected cameras.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select a camera in the device tree on the left.

Step 3 Select **AI Plan > AI Plan > AI Plan**.




- The page might vary depending on the function capabilities of cameras.
- If the camera is a PTZ camera, configure presets on the camera system first, and then you can set AI features for each preset of the PTZ camera.

Figure 4-1 AI plan (1)



Figure 4-2 AI plan (2)





Step 4 Click  to enable AI detection plan. The icon becomes .

When there is a conflict between the to-be-enabled AI plan and an enabled plan, disable the enabled plan first.

Step 5 Click **Save**.

4.1.2 Configuring Face Detection


Configure alarm rule of face detection.

Step 1 Click  or click  on the configuration page, and then select **EVENT**.

Step 2 Select a remote device in the device tree on the left.

Step 3 Select **AI Plan > Face Detection**.

Figure 4-3 Face detection




Step 4 Click to enable face detection.



Support the **Face Enhance** function. After enabling **Face Enhance** function, system displays enhanced human face zone on the surveillance window.

Step 5 Set detection region on the video (yellow area).

Figure 4-4 Area



- Click or white dot on detect region frame, and drag to adjust its size.
- Click or to set the minimum size or maximum size of the face detection area. System triggers an alarm once the size of detected target is between the maximum size and the minimum size.

Step 6 Click **Deployment Time** to select schedule from the drop-down list.

After setting arm period, system triggers corresponding operations when there is a motion detection alarm in the specified period.



You can select an existing schedule from the **Deployment Time** drop-down list. You can also add a new schedule. For details, see "6.9.3 Schedule".

Step 7 Click **Action** to set alarm action. See "6.4.1 Alarm Actions" for detailed information.

Step 8 Click **Save**.

4.1.3 Live View of Face Detection

You can view real-time face detection images and video.

4.1.3.1 Setting AI Display

You can configure display rule of face detection results.




Before using this function, ensure that view has been created. See "5.1.1 View Management" for detailed information.

Step 1 On the **LIVE** page, click and select the **Face** tab.



- Click **Sync from AI-Dis.**, obtain global smart detection display rule of EVS. See "6.4.2.4.2 Setting AI Display" for detailed information.
- Click **Apply to all windows** to copy current configuration to other window(s).

Figure 4-5 Face




Step 2 Enable **Show Tracking Box** by clicking .

After it is enabled, when the system detects face or human, the window will display corresponding rule box.

Step 3 Enable **Features Panel**, and select feature(s) you want to display.

- 1) Click next to **Features Panel**, to enable the function. When the panel is enabled, the snapshots of detected faces are displayed on the live view.
- 2) Click to select **Face Detection** tab. indicates that the panel is selected.

- 3) (Optional) Drag  to adjust features panel transparency. The higher the value, the more transparent the features panel.
- 4) (Optional) Select the features you need to display.
 - System supports displaying 4 feature types.
 - System has checked four features by default. To select other features, cancel the selected features, and then select the ones you need.


Step 4 Click **OK** to save the configuration.


4.1.3.2 Live View

Go to the **LIVE** page, enable view, and then view videos are displayed. See Figure 4-6.

- The view window displays currently detected face rule boxes.
- Features panels are displayed on the right side in real time.
The features panel displays detection time, face snapshot and face features details.

Figure 4-6 Live




Point to a features panel, and click  or double-click the detected image, so the system starts to play back the recorded videos (about 10 s) at the time of snapshot.

4.1.3.3 Face Records

On the **LIVE** page, click . The **FACE TOTAL** page is displayed. Click . And then select **Face Detection**. The latest face detection records are displayed.

Figure 4-7 Detection image



On the **FACE TOTAL** page, the following operations are available.

- Point to a piece of face record, click or double-click the detected image, and then the system starts to play back the recorded videos (about 10 s) at the time of snapshot.
- Point to a piece of face record, click , and then you can save that record locally including the video and pictures.


4.1.4 Face Search

Search for face detection information, including face detection image, record and features.

4.1.4.1 Searching by Property

Step 1 Click , select **AI SEARCH > Search by Face**.

Figure 4-8 Search by face



Step 2 Select a remote device, and then set **Event Type** to be **Face Detection**.




In the **Event Type** drop-down list, if you select **All**, the search results will include both face detection records and face recognition records.

Step 3 Set face property and time.










Step 4 Click **Query**.

Figure 4-9 Search results



Point to a piece of record, and then the following icons are displayed.

Table 4-1 Description

Icon	Operation
	<ul style="list-style-type: none"> Select one by one: Click the panel or move the mouse pointer onto the panel, and then click  to select the panel.  means it is selected. Batch select: Check All to select all panels on the page.
	Click  or double-click the panel, the system starts to play back the recorded videos (about 10 s).
	Click  or select the panel and click  to export images, videos and Excel to designated storage path.  After setting alarm linkage snapshot, during exporting images, the system exports detected images and panoramic images at the time of snapshot.


4.1.4.2 Exporting Face Records

The search results of face records can be exported. You can select to export video, picture and excel.



- The exported alarm-linked snapshot contains the face snapshot and the background picture.
- To save the background picture, make sure that you have configured alarm-linked snapshot storage.

Figure 4-10 Search results of face records



- Export in batches

Export more than one record. Support specifying file formats.

Step 1 Select more than one record.



To export all records, select the checkbox of **All**.



Step 2 Click , and then select file formats.


Figure 4-11 File format



Step 3 Click **OK**, and then follow the onscreen instructions to finish exporting.

- Export one by one

Export one piece of record. The exported file contains excel, snapshot and video by default.

Step 1 Point to a piece of record, and then click .

Step 2 Select a file type between DAV and MP4, set the saving path, and then click **OK**.

4.2 Face Recognition

The system compares captured face with the face database. When the similarity reaches the threshold as you have defined, an alarm will be triggered.




Make sure that the face database has been configured on the camera. For details, see user's manual of camera.

4.2.1 Enabling AI Plan

To use AI by Camera, you need to enable the corresponding AI plan first. For details, see "4.1.1 Enabling AI Plan".

4.2.2 Configuring Face Recognition


Configure face recognition rules.


Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select remote device in the device tree on the left.

Step 3 Select **AI Plan > Face Recognition**.

Figure 4-12 Face recognition



Step 4 Click  to enable face recognition.

Step 5 Click **Deployment Time** to select schedule from the drop-down list.

After setting arm period, system triggers actions when there is a motion detection alarm in the specified period.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.

Step 6 Click **Actions** to set alarm actions. For details, see "6.4.1 Alarm Actions".

Step 7 Click **Save**.

4.2.3 Live View of Face Recognition

Smart panel display. You can view real-time face detection and human face recognition images.


4.2.3.1 Setting AI Display

You can configure display rule of AI detection results.



Before using this function, ensure that view has been created. See "5.1.1 View Management" for detailed information.


Step 1 On the **LIVE** page, open a view window.

Step 2 Click  and select the **Face** tab.



- Click **Sync from AI-Dis.**, obtain global smart detection display rule of EVS. See "6.4.2.4.2 Setting AI Display" for detailed information.
- Click **Apply to all windows** to copy current configuration to other window(s).





Figure 4-13 Face



Step 3 Click  next to **Show Tracking Box**, to enable the function.

After it is enabled, when the system detects face or human, the window will display corresponding rule box.

Step 4 Enable features panel.

- 1) Click  next to **Features Panel**, to enable the function. When the panel is enabled, the snapshots of detected faces are displayed on the live view.
- 2) Click  to select **Face DB** tab and **Face Recognition** tab.  indicates that the panel is selected.
 - If the **Face DB** panel is selected, it is displayed on the live video when the similarity between a detected face and one in the face database reaches the threshold.
 - If the **Face Recognition** panel is selected, it is displayed on the live video when the similarity between a detected face and one in the face database does not reach the threshold.
- 3) (Optional) Drag  to adjust features panel transparency. The higher the value, the more transparent the features panel.
- 4) (Optional) Select the features you need to display.
 - System supports displaying 4 feature types.
 - System has checked four features by default. To select other features, cancel the selected features, and then select the ones you need.


Step 5 Click **OK** to save the configuration.

4.2.3.2 Live View

Go to the **LIVE** page, enable view, and then device displays view video.

- The view window displays currently detected face rule box.
- The right side displays features panel.

The features panel displays detection time, face snapshot and face features.

Point to a features panel, and then click  or double-click the detected image, so the system starts to play back the recorded videos (about 10 s) at the time of snapshot.

4.2.3.3 Face Total


On the **LIVE** page, click . Face detection panel is displayed. Point to a panel, and the operation icons are displayed.

Figure 4-14 Detection image



- Point to a panel, and click or double-click the detected image, so the system starts to play back the recorded videos (about 10 s) at the time of snapshot.
- Point to a panel, click , and then you can save that record locally.


4.2.4 Face Search

Search for face detection information, including face detection image, record and features. Search according to record and image.

Procedure

Step 1 Click , select **AI SEARCH > Search by Face**.

Figure 4-15 Search by face



Step 2 Select a remote device, and then set **Event Type** to be **Face Detection**.



In the **Event Type** drop-down list, if you select **All**, the search results will include both face detection records and face recognition records.

Step 3 Set face property and time.

Step 4 Click **Query**.

Figure 4-16 Search results

Camera	Time	Gender	Age	Glasses	Mouth Mask
camera1	14:21:52	Female	Young	No	No
camera1	14:21:58	Male	Young	No	No
camera1	14:21:57	Male	Young	No	No
camera1	14:22:27	Female	Young	No	No
camera1	14:22:37	Male	Young	No	No
camera1	14:23:02	Male	Middle-aged	No	Yes
camera1	14:24:05	Male	Young	No	No
camera1	14:25:23	Male	Middle-aged	No	Yes
camera1	14:25:32	Male	Middle-aged	No	No
camera1	14:25:44	Male	Young	No	No
camera1	14:25:57	Male	Young	No	No
camera1	14:26:08	Male	Young	No	No
camera1	14:26:51	Male	Elderly	No	No
camera1	14:27:41	Male	Young	Black-fra..	No
camera1	14:27:41	Male	Young	Black-fra..	No

Related Operations

Point to a piece of record, the following icons are displayed.

Table 4-2 Description

Icon	Operation
	<ul style="list-style-type: none"> Select one by one: Click the panel or move the mouse pointer onto the panel, and then click to select the panel. means it is selected. Batch select: Check All to select all panels on the page.
	Click or double-click the panel, the system starts to play back the recorded videos (about 10 s).
	Click or select the panel and click to export images, videos and Excel to designated storage path. After setting alarm linkage snapshot, during exporting images, the system exports detected images and panoramic images at the time of snapshot.

4.3 People Counting

Statistics of in-area people number, and queuing number.



- The people counting function is only available with AI by Camera. Make sure that the camera has been configured with people counting rules.
- The old people counting data will be overwritten when the storage space is runs out. You are recommended to back up the data in time.

4.3.1 Enabling AI Plan

To use AI by Camera, you need first enable the corresponding AI plan; otherwise the AI function does not work. For details, see "4.1.1 Enabling AI Plan".


4.3.2 People Counting


Configure this function to count the number of people in and out of the detection area. When the statistical number is larger or smaller than the threshold, an alarm is triggered.


Step 1 Click , click , and then select **EVENT**.


Step 2 Select a camera in the device tree, and then select **AI Plan > People Counting > In Area No.**

Figure 4-17 In Area No.



Step 3 Click  to set a people counting area.

- Click and drag  to adjust the position and length.

- Click the white dot on the frame of the area to add turning corners.
- Click  to restore to the default area.

Step 4 Set parameters.

Table 4-3 Parameters description of people counting

Parameters	Description
Enable	Click <input type="checkbox"/> to enable the selected area.
Name	Enter area name
Area People Counting Alarm	<ol style="list-style-type: none"> 1. Click <input type="checkbox"/> to enable the alarm. 2. Set people number threshold. <ul style="list-style-type: none"> • Select <input type="text" value=">="/> , and enter a threshold value. When the people number in the area is greater than the threshold, an alarm will be triggered. • Select <input type="text" value="<="/> , and enter a threshold value. When the people number in the area is smaller than the threshold, an alarm will be triggered.
Strand Alarm	<ol style="list-style-type: none"> 1. Click <input type="checkbox"/> to enable the alarm. 2. Set time threshold for the alarm. When the dwell time of any person in the area is greater than the threshold, an alarm will be triggered.

Step 5 Select a schedule in the **Deployment Time** drop-down list.

Alarms are triggered only within the scheduled time.

Step 6 Click **Actions** to set alarm linkage actions. For details, see "6.4.1 Alarm Actions".

Step 7 Click **Save**.


4.3.3 Queuing Detection

The system counts the number of people queuing in the detection area. When the number of people exceeds the threshold or the queue time is longer than the pre-defined time, an alarm is triggered.

Step 1 Click , click , and then select **EVENT**.

Step 2 Select a camera in the device tree, and then select **AI Plan > People Counting > Queuing**.

Figure 4-18 Queuing


Step 3 Draw a queuing detection area.

- 1) Click to draw the first detection area.
 Click to draw more areas. You can draw 4 areas at most.
- 2) Click to edit the area.
 - ◇ Click and drag to adjust the position and length.
 - ◇ Click the white dot on the frame of the area to add turning corners.
 - ◇ Click to restore to the default area.

Step 4 Set parameters.

Table 4-4 Parameters description of queuing detection

Parameters	Description
Enable	Click to enable the selected area.
Name	Enter the area name
Area People Counting Alarm	<ol style="list-style-type: none"> 1. Click to enable the alarm. 2. Set people number threshold. <ul style="list-style-type: none"> ● Select , and enter a threshold value. When the people number in the area is greater than the threshold, an alarm will be triggered. ● Select , and enter a threshold value. When the people number in the area is smaller than the threshold, an alarm will be triggered.

Parameters	Description
Queuing Time Alarm	<ol style="list-style-type: none"> 1. Click <input type="checkbox"/> to enable the alarm. 2. Set time threshold for the alarm. When the queuing time of any person in the area is longer than the threshold, an alarm will be triggered.

Step 5 Select a schedule in the **Deployment Time** drop-down list.

Alarms are triggered only within the scheduled time.

Step 6 Click **Actions** to set alarm linkage actions. For details, see "6.4.1 Alarm Actions".


Step 7 Click **Save**.

4.3.4 Live View

On the **LIVE** page, enable a view window that contains people counting video.

The live video which shows real-time people number and queuing time is displayed.

Figure 4-19 Live view



The live video displays real-time people number in the region, and the region frame flashes red once there is an alarm. The queue-detection live view also shows head frames and the dwell time of each person.

4.4 Video Metadata

The system analyzes real-time video stream to detect the existence of 4 target types: human, human face, motor vehicle, non-motor vehicle. Once a target is detected, the system can record video, take snapshots and trigger alarms.

This section introduces how to configure the video metadata feature from enabling it and selecting target types to setting the live view of video metadata.

4.4.1 Enabling AI Plan

Enable AI plan when AI by Camera is used. See "4.1.1 Enabling AI Plan" to enable AI detect function.

4.4.2 Configuring Video Metadata

After enabling video metadata, EVS links the current remote device for taking snapshots when alarm is triggered.




Video metadata cannot be enabled at the same time with face detection and IVS, because it conflicts with the two functions.

Step 1 Click or , and then select **EVENT**.

Step 2 Select a device from the device tree at the left side.

Step 3 Select **AI Plan > Video Metadata**.

Figure 4-20 Video metadata



Step 4 Select the detection target.

- People: Click the corresponding to enable people detection. Face detection can also be enabled at the same time.
- Vehicle: Click the corresponding to enable vehicle detection.
- Non-Motor Vehicle: Click the corresponding to enable non-motor vehicle detection.

Step 5 Click **Deployment Time** drop-down list to select schedule.

EVS links alarm event when an alarm is triggered within the schedule configured.

- Click **Add Schedule** to add new schedule if no schedule is added or the existing schedule does not meet requirements. For details, see "6.9.3 Schedule".
- Click **View Schedule** to view details of schedule.

Step 6 Click **Save**.

4.4.3 Live View of Video Metadata

View the detection results of face, people, motor vehicle and non-motor vehicle on the **LIVE** page.


4.4.3.1 Setting AI Display

Set the filtering conditions to display AI detection results.



Create view(s) before setting filtering conditions. To create a view, see "5.1.1 View Management".


Step 1 Select a view from **LIVE > View > View Group**.


Step 2 Click  at the lower side of the **LIVE** page, and then select **Face, Human, Vehicle** or **Non-Motor Vehicle**.



The figure uses **Human** for example. The page is for reference only.

Figure 4-21 Human





Step 3 Click  next to **Show Tracking Box**, and then a tracking box is displayed in the video when target that meets the filtering conditions is detected.

Step 4 Configure feature panel.

1) Click  next to **Features Panel** to enable feature panel.

A features panel is displayed on the right side of the video when target that meets the conditions is detected.

2) Click  to select the panel type, for example, the **Human Detection** tab.

- 3) (Optional) Drag  to adjust the transparency of panel. The higher the value, the more transparent the panel.
- 4) (Optional) Select the features to be displayed in the panel.
 - Up to 4 features can be displayed.
 - 4 features are selected by default. To select another feature, click the selected feature to cancel it, and then click the feature to be displayed.

Step 5 Click **OK**.


4.4.3.2 Live View

On the **LIVE** page, select a view from **View Group**, and the video image of the view will be displayed. See Figure 4-23.

- Rule box is displayed in real-time in the video image. Different detection targets correspond to different colors of rule box.
- Features panels are displayed on the right side of the video image.

Figure 4-22 Live



Point to the features panel, and then click , or double-click the detected image to play back the video record (10 s before and after the snapshot).



4.4.3.3 Detection Statistics

View the detection statistics of human, motor vehicle and non-motor vehicle.

4.4.3.3.1 Human

On the **LIVE** page, click , the **PEOPLE TOTAL** page is displayed.

Click , and then select **Snap With Face** and **Snap Without Face**. The information of detected human and face is displayed.

- Point to the snapshot, and then click  or double-click a pted picture to play back the video record (10 s before and after the snapshot).
- Point to the snapshot, and then click  to export the video record to specified saving path.

4.4.3.3.2 Motor Vehicle

On the **LIVE** page, click , the **VEHICLE TOTAL** page is displayed.





Click , and then select **Vehicle Recognition**, the information of detected vehicles is displayed. See Figure 4-24.

Figure 4-23 Motor vehicle detection




- Move the mouse pointer to the panel, and then click , or double-click detected picture to play back the video record (10 s before and after the snapshot).
- Move the mouse pointer to the panel, and then click  to export the video record to specified saving path.



4.4.3.3.3 Non-motor Vehicle

On the **LIVE** page, click , the **NONMOTOR TOTAL** page is displayed.

Click , and then select **Snap With Face** and **Snap Without Face**. The information of detected non-motor vehicles is displayed.

Figure 4-24 Non-motor vehicle detection



- Move the mouse pointer to the detected information, and then click , or double-click detected picture to play back the video record (10 s before and after the snapshot).
- Move the mouse pointer to the detected information, and then click  to export the video record to specified saving path.

4.4.4 AI Search

Select device and set properties to search for detection results.

4.4.4.1 Human Search

Select device and set human properties to search human detection results.

Step 1 Click , and then select **AI SEARCH > Search by Human**.

Figure 4-25 Search by human


Step 2 Select a device, and then set human properties and time period.

Click  or  to set the color.  means more than one color.

Step 3 Click **Query**.

- If face is captured, the human and face snapshots are displayed.
- If no face is captured, the human snapshot and human properties are displayed.

Figure 4-26 Search result



Related Operations

Point to one displayed panel, and the icons are displayed.

Table 4-5 Operation

Icon	Operation
	<ul style="list-style-type: none"> Select one by one: Click to select the panel. means the panel is selected. Select in batches: Select All to select all the panels on the page.
	Click or double-click the panel to play back the video record (10 s before and after the snapshot).
	Click , or select the panel and then click to export picture, video, and Excel file to specified saving path.


4.4.4.2 Vehicle Search

Set event type and vehicle properties to search vehicle detection results.

Procedure

Step 1 Click and then select **AI SEARCH > Search by Vehicle**.

Figure 4-27 Vehicle search



Step 2 Select Vehicle Detection as Event Type.


Step 3 Set vehicle properties and time period.

Click  or  to set the color.  means more than one color.

Step 4 Click **Query**.

If license plate is detected, both the scenario and the license plate will be displayed.

Figure 4-28 Search result



Related Operations

Point to one displayed panel, and the icons are displayed.

Figure 4-29 Icons




Table 4-6 Operation

Icon	Operation
	<ul style="list-style-type: none"> Select one by one: Click to select the panel. means the panel is selected. Select in batches: Select All to select all the panels on the page.
	Click or double-click the panel to play back the video record (10 s before and after the snapshot).
	Click , or select the panel and then click to export picture, video, and Excel file to specified saving path.

4.4.4.3 Non-motor Vehicle Search

Set event type and non-motor vehicle properties to search non-motor vehicle detection results.

Procedure

Step 1 Click and then select **AI SEARCH > Search by NonMotor**.

Figure 4-30 Search by non-motor vehicle

The screenshot shows a search interface with the following elements:

- Search Bar:** SearchDevice Name/IP
- Device Selection:** A list of devices with checkboxes and status icons (warning or video).
 - 1-3 (Warning icon)
 - 2-IPC (Warning icon)
 - 3-IPC
 - 4-16 (Video icon)
 - 5-1
 - 6-camera6 (Warning icon)
 - Access
 - RTSP Media
- Event Type:** All
- Non-Motor Property:**
 - Type: All
 - Color:
 - Subc...: All
 - Num...: All
 - Bag: All
- Date Range:**
 - Start: 2021 - 04 - 15 00 : 00 : 00
 - End: 2021 - 04 - 15 23 : 59 : 59
- Query Button:** A blue button labeled "Query".
- Warning:** Search range 30 days


Step 2 Select the Device you want to search.

Step 3 Set non-motor vehicle properties and time period.

Click or to set the color. means more than one color.

Step 4 Click **Query**.

Figure 4-31 Search results



Related Operations

Point to one displayed panel, and the icons are displayed.

Figure 4-32 Icons




Table 4-7 Operation

Icon	Operation
	<ul style="list-style-type: none"> Select one by one: Click to select the panel. means the panel is selected. Select in batches: Select All to select all the panels on the page.
	Click or double-click the panel to play back the video record (10 s before and after the snapshot).
	Click , or select the panel and then click to export picture, video, and excel file to specified saving path.

4.5 IVS

The IVS feature includes a number of behavior detections such as fence-crossing, intrusion, tripwire, parking, crowd gathering, missing object, abandoned object, and loitering. You can configure alarm notifications of those intelligent detections.

This section introduces how to configure the intelligent detections.



- For the same camera, IVS and face detection cannot be enabled at the same time.
- Some device models only support IVS by camera.



4.5.1 Enabling AI Plan

Enable AI plan when AI by Camera is used. See "4.1.1 Enabling AI Plan" to enable AI detect function.

4.5.2 Configuring IVS

4.5.2.1 Global Configuration


Configure global rules of IVS, including anti-disturbance and sensitivity settings.

Step 1 Click  or click  on the configuration page, and then select **EVENT**.


Step 2 In the device tree, select a camera.


Step 3 Select **AI Plan > IVS > Global Config**.

Figure 4-33 Global config






Step 4 Configure anti-disturbance and sensitivity settings.

- Click  to enable anti-disturbance function.

- Drag  to adjust sensitivity.

Step 5 Calibrate horizontal and vertical scales.

- 1) Click  to draw an area.
- 2) Click  to draw three vertical lines, enter the actual length, and then click **Calibration Verification**.
- 3) Click  to draw a horizontal line, enter the actual length, and then click **Calibration Verification**.

Step 6 Click **Save**.

4.5.2.2 Rule Configuration

Configure rules of IVS functions such as fence-crossing, tripwire, intrusion, abandoned object, parking detection, people gathering, object removed, and loitering. Different cameras support different functions.

Table 4-8 IVS functions description

Functions	Description
Fence-crossing	Alarm is triggered when a target is crossing the pre-defined fence.
Tripwire	Alarm is triggered when a target is crossing the pre-defined tripwire.
Intrusion	Alarm is triggered when a target is entering, leaving, or appears in the detection area.
Abandoned Object	Alarm is triggered when an object is left in the detection area and the existence time is longer than the threshold.
Missing Object	Alarm is triggered when an object is removed from the detection area and not put back after the pre-defined time period.
Parking Detection	Alarm is triggered when a target remains still within a time period longer than the pre-defined time duration.
People Gathering	Alarm is triggered when people gathering is detected or people density is larger than the threshold.
Loitering	Alarm is triggered when a target keeps loitering in a time period longer than the threshold. Alarm will be triggered again if the target stays in the detection area after the first alarm.


Take tripwire as the example. The configuration procedure is as follows.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select remote device in the device tree on the left.

Step 3 Select **AI Plan > IVS**.


Figure 4-34 Add rules



Step 4 Set tripwire rules.

- 1) Click **Add Rule**, and then select **Tripwire**.

Figure 4-35 Configuring tripwire detection rules




- 2) Click to enable detection rule.
 - Click to delete detection rule.
- 3) Click to edit the tripwire line.
 - Drag to adjust position or length of the line.
 - Click or to set the directions. An alarm will be triggered only when the target crosses the line in the designated direction.
 - Click the white dot on the line to add a turning point. Drag at the turning point to adjust position or length.
- 4) Click or to set minimum size or maximum size of detection target.

System triggers an alarm once the detected target size is between the maximum size and the minimum size.

Step 5 (Optional) Set other requirements.

Table 4-9 IVS rules configuration requirements


Functions	Description
Fence-crossing	Draw 2 detection lines.  <ul style="list-style-type: none"> Transparent fences such as iron fence are not supported. Extremely short walls (height lower than normal height) are not supported.
Tripwire	Draw 1 detection line.
Intrusion	Draw 1 detection line.
Abandoned Object	With the abandoned object detection, a person or vehicle that stays still for a long time will also trigger an alarm; if the object is smaller than human or vehicle, you can set the target size to filter out people and cars, or extend the minimum lasting duration to avoid false alarms caused by short dwell of people. For the crowd gathering detection, if the installation height is too low, human body size will take a large proportion in the image, or the camera view might be blocked. That might result in false alarms caused by continuous shaking of the camera, shaking leaves, frequent door opening and closing, and dense traffic of vehicles and people.
Missing Object	
Parking Detection	
Crowd Gathering	
Loitering	



Step 6 Set AI Recognition.

After setting AI recognition, when the system detects a person, vehicle or non-motor vehicle, a rule box will appear beside the target on the video.

- 1) Click  to enable AI recognition function.

Figure 4-36 Type



- 2) Select a recognition type.
 -  is to recognize human, and  is to recognize vehicle.
 - After enabling AI recognition function, at least one recognition type shall be selected.

Step 7 Click **Deployment Time** to select schedule from the drop-down list.

After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**.

Step 8 Click **Actions** to set alarm action. See "6.4.1 Alarm Actions" for detailed information.



Repeat Step 4-Step 8 to add multiple detection rules. You can add max. 10 detection rules at the same time.

Step 9 Click **Save**.

4.5.3 Live View of IVS

On the **LIVE** page, view real-time IVS results.

4.5.3.1 Setting AI Display

Set the display rules of detection results.



Make sure that view is created before setting AI display. To create view, see "5.1.1 View Management".

Step 1 Select a view from **LIVE > View > View Group**.

Step 2 Click , and then select the **Human** or **Vehicle** tab.

Figure 4-37 Human





Figure 4-38 Vehicle



Step 3 Click next to **Show Tracking Box**.

Step 4 Configure feature panel.

- 1) Click next to **Features Panel** to enable feature panel.

A features panel is displayed on the right side of the video when a target that meets the conditions is detected.

- 2) Click to select the panel type, for example, the **Human Detection** tab.
- 3) (Optional) Drag to adjust the transparency of panel. The higher the value, the more transparent the panel.
- 4) (Optional) Select the features to be displayed in the panel.
 - Up to 4 features can be displayed.
 - 4 features are selected by default. To select another feature, click the selected feature to cancel it, and then click the feature to be displayed.


Step 5 Click **OK**.

4.5.3.2 Live View

Go to the **LIVE** interface, enable view, and then Device displays view video.

- When a target triggers cross line or cross region rule, the line or region frame in the view flickers in red.
- After setting AI recognition, when the system detects a person or vehicle, a rule frame will appear beside the person and vehicle in the view.
- There is a feature panel on the right side of the video window.

Figure 4-39 Live




Point to features panel, and the operation icons are displayed. Click or double-click the detected image, so the system starts to play back the recorded videos (10 s before and after the snapshot).

4.5.3.3 Detection Statistics

On the **LIVE** page, click . The **PEOPLE TOTAL** page is displayed. Click , and then select **IVS**. The people detection records are displayed.



Figure 4-40 People total






Click . The **VEHICLE TOTAL** page is displayed. Click , and then select **IVS**. The detected vehicles are displayed.

Figure 4-41 Vehicle total



- Point to a picture and click , or double-click the picture, so the system starts playing back video (10 s before and after the snapshot moment).
- Point to a picture and click  to export video.

On the **LIVE** page, click . The **NONMOTOR TOTAL** page is displayed. Click , and then select **IVS**. The detected non-motor vehicles are displayed.

- Point to a picture and click , or double-click the picture, so the system starts playing back video (10 s before and after the snapshot moment).
- Point to a picture and click  to export video.

4.5.4 IVS Search

Search for IVS records.


Step 1 Click  and then select **AI SEARCH > IVS**.


Figure 4-42 IVS



Step 2 Select the remote device, and set event type and time.

Step 3 Click **Query**.

Figure 4-43 Search result



Click the panel. The following operation icons are displayed.

Table 4-10 More operations

Name	Operation
Select a panel	<ul style="list-style-type: none"> Select one by one: Move the mouse onto the panel. Click <input type="checkbox"/> to select the panel. <input checked="" type="checkbox"/> means it is selected. Click ALL to select all the panels.
Playback	Click the panel, and click or double-click the panel. The system starts to play back the recorded videos (10 s before and after the snapshot).
Export file	Click the panel and click , or click the panel and click to export images, videos and Excel to designated storage path. After setting alarm linkage snapshot, during exporting images, the system exports detected images and panoramic images at the time of snapshot.

4.6 Vehicle Recognition

Alarm is triggered when vehicle property that meets detection rule is detected.



EVS supports only vehicle recognition through AI by Camera. Make sure that the vehicle recognition parameters of camera are configured. For details, see the user's manual of the camera.

4.6.1 Enabling AI Plan

Before using AI by Camera, AI plan needs to be enabled first. For details, see "4.1.1 Enabling AI Plan".

4.6.2 Setting Vehicle Recognition


Set the deployment time of vehicle recognition and alarm linkage event.

Step 1 Click  or , and then select **EVENT**.

Step 2 Select device from the device tree at the left side.

Step 3 Select **AI Plan > Vehicle Recognition**.

Figure 4-44 Vehicle recognition



Step 4 Click the **Deployment Time** drop-down list to select schedule.

EVS links alarm event when alarm is triggered within the defined schedule.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. For details, see "6.9.3 Schedule".

Step 5 Click **Actions** to set alarm action. For details, see "6.4.1 Alarm Actions".

Step 6 Click **Save**.

4.6.3 Live View of Vehicle Recognition

View vehicle recognition results on the **LIVE** page.

4.6.3.1 Setting AI Display

Set the display rules of detection results.



Make sure that view is created before setting AI display. To create view, see "5.1.1 View Management".

Step 1 Select a view from **LIVE > View > View Group**.



Step 2 Click , and then select **Vehicle** tab.

Figure 4-45 Motor vehicle



Step 3 Click next to **Show Tracking Box** to enable tracking box function.


A tracking box is displayed in the video image when target meeting detection rule is detected.

Step 4 Set features panel.

1) Click next to **Features Panel** to enable features panel function.

Features panel will be displayed at the right side of video image when target with selected features is detected.

2) Select the **Vehicle Detection** panel type by clicking . means the panel is selected.

3) (Optional) Drag  to adjust the transparency of panel. The higher the value, the more transparent the panel.

4) (Optional) Select the features to be displayed in the panel.

- Up to 4 features can be displayed.
- 4 features are selected by default. To select another feature, click the selected feature to cancel it, and then click the feature to be displayed.


Step 5 Click **OK**.

4.6.3.2 Live View

On the **LIVE** page, select a view, and the video image of the view is displayed.

- Tracking box is displayed in the video image.
- Features panel is displayed at the right side of the video image.

Figure 4-46 Live




Move the mouse pointer to the features panel, and then you can click or double-click the vehicle image to play back the video image (10 s before and after the snapshot).

4.6.3.3 Detection Statistics


On the **LIVE** page, select a view and then click . The **VEHICLE TOTAL** page is displayed.

Click , and then select **Vehicle Detection**. The information of detected vehicles is displayed.

Figure 4-47 Vehicle detection



- Move the mouse pointer to the information panel, and then click or double-click the picture to play back the video image (10 s before and after the snapshot).

- Move the mouse pointer to the information panel, and then click  to export the video to specified saving path.

4.6.4 Searching for Detection Information

Set event type and vehicle properties, and then search vehicle detection information. For details, see "4.4.4.2 Vehicle Search".

4.7 Crowd Distribution Map

View and monitor people crowd to avoid crowd incidents, for example, stampede.



This function is only available with AI by Camera.

4.7.1 Enabling AI Plan



Enable the corresponding AI plan before using AI by Camera functions. For details, see "4.1.1 Enabling AI Plan".

4.7.2 Configuring Crowd Distribution Map

Set crowd distribution alarm rules.

4.7.2.1 Global Configuration


Draw lines on the image to determine the geographical scale of the image.

Step 1 Click  or click  on the configuration page, and then select **EVENT**.



Step 2 In the device tree, select a camera.

Step 3 Select **AI Plan > Crowd Distribution Map > Global Config**.

Figure 4-48 Global config





Step 4 Draw lines. Draw one horizontal line and three vertical lines.

- Click , draw vertical lines, and then enter their geographical distance values.
- Click , draw a horizontal line, and then enter the geographical distance value.

Step 5 Click **Save**.

4.7.2.2 Rule Configuration

Configure the alarm threshold for crowd monitoring. For example, when the crowd density reaches 8, an alarm is triggered.

Step 1 Click  or click  on the configuration page, and then select **EVENT**.

Step 2 In the device tree, select a camera.


Step 3 Select **AI Plan > Crowd Distribution Map > Rule Config**.

Step 4 Click  next to **Enabled** to enable rule configuration.

Step 5 Set detection rules.

- Set regional detection rules.
 - 1) Click **Add Rule**. The following page is displayed.

Figure 4-49 Add Rules



- 2) Drag to adjust the size.
 - 3) Configure alarm threshold. Alarm is triggered when the detected people number reaches the threshold.
 - Set global alarm.
- 1) Click , and then drag to adjust the size of the yellow area.
 - 2) Click to enable global detection.
 - 3) Set crowd density. Alarm is triggered when the detected crowd density reaches the threshold.

Step 6 Select a schedule from the **Deployment Time** drop-down list.
The alarm linkage action is triggered only during the scheduled period.



To modify the schedule, click **Add Schedule**.

Step 7 Click **Actions**, and then select an action to be associated to the alarm.

Step 8 Click **Save**.

4.7.3 Live View of Crowd Distribution

On the **LIVE** page, open a view that contains the crowd distribution detection camera.

The video shows people numbers in the detection areas in real time. The area frame flashes red when there is an alarm in the area.

Figure 4-50 Live view of crowd distribution



- Right-click on the live video, and then select **Crowd Distribution Map > PIP**. A blue section is displayed, and it shows the crowd distribution status inside the current view.
- Right-click on the live video, and then select **Crowd Distribution Map > Global** to switch to the distribution view. The view indicates crowd density and people heads in different colors.

4.8 Call Alarm

An alarm is triggered when the system detects a person calling. To configure call alarm, set call detection rules for the visible light channel of a thermal camera.



Call alarm is only available with AI by Camera.

4.8.1 Enabling AI Plan


Enable the corresponding AI plan before using AI by Camera functions. For details, see "6.2.1 Enabling AI Plan".

4.8.2 Configuring Call Alarm

Configure call alarm rules.

- Step 1 Click or click on the configuration page, and then select **EVENT**.
- Step 2 In the device tree, select the visible light channel of a thermal camera.
- Step 3 Select **AI Plan > Call Alarm**.
- Step 4 Click next to **Enabled** to enable rule configuration.

Figure 6-106 Configure call alarm



Step 5 Click and drag to adjust the size of the detection area (yellow area).

Step 6 Set **Sensitivity** and **Min Duration**.

- Sensitivity: The higher the **Sensitivity** is, the easier the call action is detected.
- Min Duration: The minimum duration the call action lasts. If the call action still lasts after the **Min Duration**, the system will trigger an alarm.

Step 7 Click **Deployment Time** to select a schedule from the drop-down list.

System triggers corresponding alarm actions only during the alarm deployment period.




You can select an existing schedule from the **Deployment Time** drop-down list. You can also add a new schedule. For details, see "8.9.4 Schedule".

Step 8 Click **Action** to set alarm action. See "8.4.1 Alarm Actions" for detailed information.

4.8.3 Live View of Call Alarm

Log in to PCAPP. On the **LIVE** page, open a view that contains the call alarm detection channel. The call action is highlighted in red when the alarm is triggered.

Figure 6-107 Live view of call alarm



4.9 Smoking Alarm

An alarm is triggered when the system detects a person smoking. To configure smoking alarm, set smoking detection rules for the visible light channel of a thermal camera.




Smoking alarm is only available with AI by Camera.

4.9.1 Configuring Smoking Alarm

Configure smoking alarm rules.

- Step 1** Click or click on the configuration page, and then select **EVENT**.
- Step 2** In the device tree, select the visible light channel of a thermal camera.
- Step 3** Select **AI Plan > Smoking Alarm**.
- Step 4** Click next to **Enabled** to enable rule configuration.

Figure 6-109 Configure smoking alarm



Step 5 Click and drag to adjust the size of the detection area (yellow area).

Step 6 Set **Sensitivity** and **Min Duration**.

- Sensitivity: The higher the **Sensitivity** is, the easier the call action is detected.
- Min Duration: The minimum duration the call action lasts. If the call action still lasts after the **Min Duration**, the system will trigger an alarm.

Step 7 Click **Deployment Time** to select a schedule from the drop-down list.

System triggers corresponding alarm actions only during the alarm deployment period.



You can select an existing schedule from the **Deployment Time** drop-down list. You can also add a new schedule. For details, see "8.9.4 Schedule".

Step 8 Click **Actions** to set alarm action. See "8.4.1 Alarm Actions" for detailed information.

4.9.2 Live View of Smoking Alarm

Log in to PCAPP. On the **LIVE** page, open a view that contains the smoking alarm detection channel. The smoking action is highlighted in red when the alarm is triggered.

5 General Operations

This chapter introduces general operations such as live view, playback, alarm, AI functions, and IVS.

5.1 Live and Monitor

Click **+**, and then select **LIVE**. The **LIVE** page is displayed.




Move the mouse pointer to the middle of video window and left column.  is displayed. Click the icon to hide the left column. See Figure 5-2.

Figure 5-1 Live (1)




Figure 5-2 Live (2)







Table 5-1 Live page description

No.	Description
1	View zone. Displays the created view and view group. See "5.1.1 View Management" for detailed information.
2	Resource pool. Displays the added remote device list.
3	PTZ zone.
4	Smart preview icons. View face statistics, person statistics, IVS statistics and AI display.
5	Video play window. See "5.1.1.3 View Window".
6	<ul style="list-style-type: none"> ● Click  to take snapshot. ● Click  for full-screen view. ● Click  to go to the VIDEO RECORDING page for recording configuration.

5.1.1 View Management

View is composed of video images of several remote devices. Go to the view panel at the upper-left corner of the **LIVE** page to view or call the view. See Figure 5-3.



- System has created views by default. Create view or view group under the **View**.
- Double-click a view or drag the view to the play panel on the right side. Device begins playing the real-time video from the remote device.
- Click  to select views and its sub-node.

Figure 5-3 View



5.1.1.1 View Group

View group is a group of views. The view group allows you to categorize and manage view. It is easy for you to search and find the view. Create view or view group under the View.



- Device supports maximum 100 view groups.
- The views hierarchy shall not be more than 2. For example, after you create View Group 1 under View, you can create a sub-level View Group 2 under View Group 1. However, you cannot create sub-level group under View Group 2.

Procedure

Step 1 Follow the steps listed below to create a view group.



- Click **View Group** or a created view group, and then click .
- Right-click **View Group** or a created view group, and then select **Add View Group**. System creates one view group.

Figure 5-4 Create view group



Step 2 Set view group name.

- The view group name ranges from 1 to 64 characters. It can contain English letters, numbers and special characters.
- View group is to classify different view groups. We recommend the view group name shall be easy to recognize.

Step 3 Click any blank space on the page.

Device pops up a prompt of success.


Related Operations

After creating view group, view group can be renamed or deleted. See Table 5-2 for detailed information.

Table 5-2 View group

Name	Operation
Rename view group	<ul style="list-style-type: none"> • Select a view group and then click . Set view group name and click any spare panel. • Right-click view group and select Rename. See Figure 5-5. Set view group name and click any spare panel.
Delete View group	<p></p> <p>Once you delete view group, all views under current view group will be deleted at the same time. Please be careful!</p> <ul style="list-style-type: none"> • Select view group and click . • Right-click view group and then select Delete.

Figure 5-5 Rename



5.1.1.2 View

View is a video component of several remote devices. You can drag several remote devices to the same view and when view function is enabled, you can view the real-time video from several remote devices at the same time.

5.1.1.2.1 Creating View

Creating view is to add several associated remote devices to the same View. It is easy to view the real-time video from several remote devices at the same time.

Preparation

Remote device has been added. See "3.4.2 Adding Remote Device" for detailed information.

Create View

Step 1 Follow the steps listed below to create view.




- Select a view group, click , and then select **Add view**.
- Right-click a view group, and then select **Add view**.

Figure 5-6 Edit view (1)




Step 2 Double-click a remote device in resource pool, or drag the remote device to the right panel. After one remote device is added, layout grid is displayed.

- Each layout grid supports one remote device. If you want to add several remote devices, drag the rest remote device to other idle layout grid.
- If the layout grid has added the remote device, drag another remote device to current grid to replace the original one.
- Move the mouse pointer to the orange panel (such as ) of the view window, click the view window, and then drag after you see the arrow icon to adjust view window size.



- Device automatically creates the view grids amount according to the selected remote device amount. Device supports maximum 36 view windows.
- The view window fills in the whole layout grid by default. Right-click to select **Original Scale > ON**, and turn on the **Original Scale**. The device automatically adjusts view window size according to resolution of remote device.
- When adjusting view window position, drag the view window to the layout grid of the green background color. You cannot drag the view window to the grid of red background color.

Figure 5-7 Edit view (2)



Step 3 Set view name.

The view name ranges from 1 to 64 characters. It can contain English letters, number and special character.


Step 4 Click **OK** to save the configuration.

Device pops up a prompt of **Successfully operated**.

Related Operations

After creating view, view can be edited, enabled, renamed or deleted.

Table 5-3 View

Name	Operation
Edit View	Edit remote device in the view, window layout and view name. See "5.1.1.2.2 Editing View" for detailed information.
Enable view	After enabling view, view real-time image of remote device in the view. See "5.1.1.2.3 Enabling view" for detailed information.
Rename view	<ul style="list-style-type: none"> Select a view group and then click . Set view group name and click any spare panel. Right-click view and select Rename. See Figure 5-8. Set view name and click any spare panel.





Name	Operation
Delete view	<ul style="list-style-type: none"> • Delete: Select a view and then click , or right-click view and then select Delete. • Batch delete: Click , select views you want to delete and then click .

Figure 5-8 Menu



5.1.1.2.2 Editing View

In edit view mode, you can perform the following functions:



- Add, or delete the remote device on the view.
- Adjust the view grid display.
- Modify view name.

Step 1 Right-click a view and then select **Edit**.

Figure 5-9 Edit view



Step 2 Edit view as you require.

- Add remote device: Double-click remote device in the resource pool, or drag the remote device to the free layout grid on the right panel.
- Delete remote device: Point to window on the right, and click  at the upper-right corner.
- Move window position: Select and hold on a view window, move it to the proper position and release mouse.
- Change window position: Select and hold on one view window and then drag to another view window.
- Change window size: Move your mouse to the orange panel on the window (such as ). Hold and drag the view window after you see the arrow icon.
- Modify view name: Set view name on



When adjusting view window position, drag the view window to the layout grid of the green background color. You cannot drag the view window to the grid of red background color.

Step 3 Click **OK** to save the configuration.

Device pops up successfully operated.

5.1.1.2.3 Enabling view

Right-click the view and select **Open**, or double-click view. The view window is displayed.

Figure 5-10 View window






When enabling the view, you can change video position, zoom video window.



- When adjusting view window position, drag the view window to the layout grid of the green background color. You cannot drag the view window to the grid of red background color.
- Point to view window. Window task column is displayed to snapshot, enable record and turn off view window. See "5.1.1.3.1 Window Task Column" for detailed information.
- Right-click view window, you can switch bit streams, set digital zoom. See "5.1.1.3.2 Shortcut Menu" for detailed information.


Table 5-4 View function

Name	Description
Exchange window position	Press one view window and drag it to another view window to exchange these view window position.  The exchanging window position operation is valid only once. Disable and then enable view again, the view window restores original position. If you want to change view window position permanently, go to the view edit mode to set. See "5.1.1.2.2 Editing View" for detailed information.
Zoom in video window	<ul style="list-style-type: none"> Once current view window amount is too much (more than 9), click one view window, device displays current view window at the center of the window in the zoom in mode. Click any other blank position, you can view window restores original size. Double-click a view window, device displays view window at one window. Double-click view window again or click any blank position, the view window restores original size.
Add view window	In the resource pool, double-click the remote device or drag the remote device to the right panel, you can add remote device to current view. Drag the remote device to the view window to replace the original remote device.  The modified view layout is valid only for once if you do not click OK . Close and enable view again, the view layout restores original layout.
Close view window	Point to one view window, click  to close the view window. Close view window, device automatically adjusts view layout according to the rest remote device amount and play panel free space.

5.1.1.3 View Window

Right-click the view, select **Open**, or double-click view. The view window is displayed.

Figure 5-11 View window



5.1.1.3.1 Window Task Column

Point to view window. The icons are displayed.

Figure 5-12 View window










Table 5-5 Window task column

Name	Description
Open Manual Video Recording	<p>Click  to start recording manually. Now the icon becomes . Click  to stop recording.</p> <p>System stops recording according to the manual record length settings if you do not click  again to stop.</p> <p>At different interfaces, recording storage path varies.</p> <ul style="list-style-type: none"> ● Local Configurations <ul style="list-style-type: none"> ◇ When USB storage device is connected, recordings are saved in USB storage device. ◇ Otherwise, the recordings are saved in the Device. Query or export manual recording by playback control. See "5.2.1 Playing Back Recorded Video" for detailed information. ● Operate PCAPP. Default storage path of recording is C:/Program Files (x86)/EVS/video. Set storage path.
Snapshot	<p>Click  to snapshot.</p> <p>At different interfaces, snapshot storage path varies.</p> <ul style="list-style-type: none"> ● Local Configurations <ul style="list-style-type: none"> ◇ When USB storage device is connected, snapshots are saved in USB storage device. ◇ Otherwise, the snapshots are saved in the Device. Query or export the snapshots by playback control. See "5.2.3 Playing Back Snapshots" for detailed information. ● Operate PCAPP. Default storage path of snapshot is C:/Program Files (x86)/EVS/pictures. Set storage path.
Close view window	<p>Click  to close view window.</p>

5.1.1.3.2 Shortcut Menu

Right-click the view window. The shortcut menu is displayed.

Figure 5-13 Shortcut menu




Table 5-6 Shortcut menu





Parameters	Description
Stream	Set current window stream. It includes main stream/sub stream 1/sub stream 2.
Bit rate	Displays real-time bit rate on the window or not. See Figure 5-14.
Original Scale	Set video window scale. <ul style="list-style-type: none"> ● ON: System automatically adjusts video window scale according to the resolution. ● OFF: System automatically adjusts video window scale according to the remote device amount and the free space on the playback panel.
Audio	Set audio output. It includes audio 1, audio 2, mixing and off.
Fisheye Dewarp	Set instalaltion methods and display modes of fisheye cameras. For details, see "5.1.1.3.4 Fisheye Dewarp".  This function is only available on fisheye camera.
Smart tracking	Intelligently track targets. For details, see "5.1.1.3.5 Smart Tracking".  This function is only available on the multi-sensor panoramic camera + PTZ camera.
Crowd distribution	Show people numbers and distribution status. For details, see "4.7.3 Live View of Crowd Distribution".  This function is only available on the camera that supports crowd distribution.

Figure 5-14 View window



5.1.1.3.3 Digital Zoom

The digital zoom function allows you to zoom in a specified zone to view the video details.

Log in to PCAPP, double-click a view to open it, and then enable digital zoom through either of the following methods:


- Click the view, scroll the mouse to zoom in or zoom out.
- Click , and then select a zone you want to zoom in on the video window.

Figure 5-15 Digital zoom:




5.1.1.3.4 Fisheye Dewarp

Set the installation method and display mode of fisheye cameras.




- Installation method: Select the installation method according to the actual situation.
- Display mode: Select the display mode of live view.

Step 1 Right-click on the live video, and then select **Fisheye Dewarp**.

Figure 5-16 Fisheye dewarp














Step 2 Select an installation method.

- Click  to select ceiling mount.
- Click  to select wall mount.
- Click  to select ground mount.

Step 3 Select a display mode.

Table 5-7 Display mode

Installation Method	Display Mode	Description
Ceiling/wall/ground mount		The original fisheye image.
Ceiling/ ground mount	 1P+1	Corrected 360°panoramic image + section images.
	 2P	2 corrected 180°images, which consist the 360° panoramic image.
	 1+3	Original image + 3 section images.
	 1+4	Original image + 4 section images.

Installation Method	Display Mode	Description
	 1P+6	Corrected 360°panoramic image + section images.
	 1+8	Original image + 8 section images.
Wall mount	 1P	Corrected 180° image from left to right.
	 1P+3	Corrected 180° image + 3 section images.
	 1P+4	Corrected 180° image + 4 section images.
	 1P+8	Corrected 180° image + 8 section images.

Step 4 Click **OK**.

5.1.1.3.5 Smart Tracking


Track targets manually or automatically. This function is only available on the multi-sensor panoramic camera + PTZ camera.



Make sure that the linked tracking function has been enabled.

Step 1 Right-click on the live video, and then select **Smart Tracking > ON**.

Figure 5-17 Smart tracking



Step 2 Select the tracking method.

- Manual positioning: Click a spot or select a zone on the bullet camera video, and then the PTZ camera will automatically rotate there and zoom in.
- Manual tracking: Click or select a target on the bullet camera video, and then the PTZ camera automatically rotates and tracks it.
- Automatic tracking: The tracking action is automatically triggered by alarms in accordance with the pre-defined rules.



For automatic tracking, make sure that you have set intrusion detection or tripwire rules for the camera. For details, see "4.5.2 Configuring IVS".

5.1.1.3.6 Thermal

On the **LIVE** interface, a thermal camera has 2 channels: Visible light channel and thermal channel. Select the thermal channel, point to any position on the live video, and then you can view the real-time temperature of the position.

Figure 5-18 Thermal



5.1.1.3.7 Talk


The Talk function enables voice interaction between the Device and remote devices, improving the efficiency in handling emergency events.

Step 1 Log in to PCAPP.

Step 2 Open a view on the **Live** page.

Figure 7-19 Talk



Step 3 Click  at the upper-right corner of the view window to enable the Talk function. Click again to disable the function.

5.1.2 Resources Pool

The resource pool displays the added remote device list. The system automatically divides into groups according to device type.

Figure 5-19 Resources pool










Table 5-8 Resources pool description

Operation	Description
Search device	Input keywords at <input type="text"/> , device displays the corresponding remote devices.  Support fuzzy search.

Operation	Description
Filter device	Click  and then select all, online, offline to filter the disqualified remote device.
View device status	Display remote device status on the resources pool. <ul style="list-style-type: none"> ● If the remote device name and icon is black, it means the remote device is online. For example,  IP PTZ Camera. ● If the remote device name and icon is gray, it means the remote device is offline. For example,  IPC . ● If there is an icon  before the remote device, it means remote device is abnormal, alarming, and so on. Point to  , to view the detailed information.
Mouse Operations	<ul style="list-style-type: none"> ● Point to the remote device name, you can view remote device IP address and port number. ● On the Device list, click one remote device and then press Ctrl, click other remote device, you can select several remote devices at the same time. ● On the Device list, select one remote device and then press Shift, click other remote device, select current two remote devices and all remote devices listed between them. ● Right-click a remote device to connect to disconnect it. ● Double-click remote device or drag the remote device to the view window on the right panel, you can enter edit view page. Edit the view. See "5.1.1.2.2 Editing View" for detailed information.

5.1.3 PTZ

Set PTZ functions and perform PTZ control so the PTZ camera can rotate accordingly to monitor all directions.



The PTZ functions might vary depending on the Device models.

Log in to the PCAPP. On the **LIVE** page, PTZ is displayed at the lower-left corner.



The following figure is for reference only. The grey button means that the current function is not supported.

Figure 7-21 PTZ


























Table 7-10 PTZ Icons

Icons	Description
	<p>Press and hold on , and drag it up and down. The higher the value is, the faster the PTZ speed is.</p>
	<p>Control PTZ movement in the following ways.</p> <ul style="list-style-type: none"> ● Press and hold on  to control PTZ top/bottom/left/right/upper-left/upper-right/lower-left/lower-right direction. ● Click the arrows to control PTZ direction.
	<p>Click to enable 3D positioning function.</p>

Icons	Description
	Click to enable auto focus, and then the camera image becomes focused automatically.
	Click to enter the PTZ menu mode. For details, see "7.1.3.1 PTZ Menu Settings".
	Zoom. Click to adjust lens zoom rate of the remote device.
	Focus. Click to adjust lens focus of the remote device.
	Iris. Click it to adjust iris size of the remote device.
	Click to use windshield wiper, light, IR and linear scan, auxiliary commands. <ul style="list-style-type: none">  : Drag the on/off slider to the left or right to enable or disable windshield wiper.  : Drag the on/off slider to the left or right to enable or disable the light.  : Drag the on/off slider to the left or right to enable or disable the IR.  : Drag the on/off slider to the left or right to enable or disable linear scan.  : Set the No. of auxiliary functions. Click  to enable the corresponding auxiliary function.
	Click to enter PTZ calling page.  Go to the remote device to set corresponding PTZ function before you call it. <ul style="list-style-type: none"> Click  to enter the preset page. Click  to enter the cruise page. For details, see "7.1.3.2.2 Setting a Cruise". Click  to enter the pattern page. For details, see "7.1.3.2.2 Setting a Cruise".

5.1.3.1 PTZ Menu Settings

Device displays PTZ main menu on the view window. The PTZ main menu enables you to perform camera settings, PTZ settings, system management, and more. You can use the direction and confirm buttons to set the remote device.

Step 1 Log in to PCAPP.

Step 2 Enable view and then select a remote device on the view.

Step 3 On PTZ panel, click  to open the OSD menu.

Figure 7-22 PTZ menu page



Table 7-11 PTZ menu description

Parameters	Description
Camera	Set remote device image parameters involving picture, exposure, backlight, WB, day and night, focus and zoom, defog, and default.
PTZ	Set remote device PTZ functions such as preset, cruise, scan, pattern, rotation, and PTZ restart.
System	Set remote device PTZ simulator, restore default, manage remote device peripheral device, view remote device software version, PTZ version and more.
Exit	Exit PTZ menu.

Step 4 Set PTZ menu parameters.

- Click ▲ and ▼ to select options .
- Click ► or ◀ to set parameters.
- Click to confirm.

Step 5 Click to exit PTZ menu mode.

5.1.3.2 Configuring PTZ Functions

Control PTZ device to implement corresponding operations.



The PTZ functions might vary depending on the Device models.

5.1.3.2.1 Setting a Preset

A preset is the saved information of a specific position, angle, and focal length of the PTZ camera. You can set a preset so that you can quickly adjust the PTZ to the desired position in the future.

Procedure



- Step 1 Log in to PCAPP.
- Step 2 Select a PTZ camera from the views.
- Step 3 On the PTZ panel, click .

Figure 7-23 Call a preset











- Step 4 Click the direction icons to rotate the camera to a specific position.
- Step 5 Click , enter the name of the new preset, and then click  to save the preset.

Figure 7-24 Add a preset



Step 6 To call the preset, hover over the preset name, and then click .

Related Operations

- Edit a preset:
 - ◇ To edit preset name, double-click the name. The camera rotates to the preset after the double-click.
 - ◇ To modify the preset position, select the preset, and then click , rotate the camera to the desired position, and then click .
 - ◇ To quit, click .
- To delete a preset, select it and then click .
- To refresh presets list, click .

5.1.3.2.2 Setting a Cruise

A cruise is a sequential set of presets. After you call a cruise, the PTZ camera automatically rotates to the presets one by one at the pre-defined interval.

Procedure





- Step 1** Log in to PCAPP.
- Step 2** Select a PTZ camera from the views.
- Step 3** On the PTZ panel, click .
- Step 4** Click , enter the name of the new cruise, and then click  to save.
- Step 5** Click **Add**, select a cruise, and then click .
- Repeat this step to add multiple presets into the cruise.

Figure 7-25 Add a cruise

Cruise1
✕

+ Add

No.	Preset	Stay Time	Operate
1	Preset1 ▼	15 s	🗑️
2	Preset1 ▼	15 s	✅ ❌

Refresh

Step 6 To call the cruise, hover over the cruise name, and then click ▶. To stop the cruise, click ■.

Related_Operations

- Edit a cruise:
 - ◇ To edit cruise name, double-click the name. To quit, click ❌.
 - ◇ To modify the cruise, select the cruise, and then click 📄, modify the settings, and then click ✅.
- To delete a cruise, select it and then click 🗑️
- To refresh cruises list, click 🔄

5.1.3.2.3 Setting a Pattern

A pattern is a recorded series of PTZ operations such as pan, tilt, zoom and focusing. You call a pattern to let the camera repeat the corresponding operations.


Procedure

- Step 1 Log in to PCAPP.
- Step 2 Select a PTZ camera from the views.
- Step 3 On the PTZ panel, click 🔄.
- Step 4 To start recording a pattern, double-click on a pattern name, click **Start Record**, perform a series of PTZ actions as desired, and then click **Stop Record**.



The maximum number of patterns depends on the camera capability. If not limited on the camera, you can config up to 5 patterns by default.

Figure 7-26 Call a pattern



Step 5 To call the pattern, hover over the pattern name, and then click . To stop, click .

Related Operations

- Edit a pattern:
 - ◇ To modify the pattern, select the pattern, and then click . Click **Start Record** and record a new pattern, and then click **Stop Record**.
 - ◇ To quit, click the pattern name.
- To delete a pattern, select it and then click .
- To refresh patterns list, click .

5.1.3.2.4 Setting Linear Scanning

In the linear scanning mode, the camera scans repeatedly to the pre-defined left and then right limit.

Step 1 Log in to PCAPP.

Step 2 Select a PTZ camera from the views.


Step 3 On the PTZ panel, click .

Step 4 Select a linear scanning, and then double-click it or click . Rotate the PTZ to the left until you think it can be the left limit, and then click to save; rotate the PTZ to the right limit, and then click .



The maximum number of linear scanings depends on the camera capability. If not limited on the camera, you can config up to 5 scanings by default.

Figure 7-27 Set a linear scanning



Step 5 To call the linear scanning, hover over the name, and then click . To stop, click .

5.1.3.2.5 Enabling Auxiliary Functions

Enable PTZ windshield wiper, light and IR.

Step 1 Log in to PCAPP.

Step 2 Select a PTZ camera from the views.

Step 3 On the PTZ panel, click .

Figure 7-28 Auxiliary functions



Step 4 Drag the slider to **ON** or **OFF** to enable or disable the function.

- : Windshield wiper. It is available on select models.
- : Light. It is available on select models.
- : IR. It is available on select models.

5.2 Recorded Files

Search or play back the record file or image on the Device. At the same time, you can export record file or image to designated storage path.

5.2.1 Playing Back Recorded Video

Search and playback record file according to remote device, record type, and record time.



Step 1 Click  and then select **SEARCH**.

Figure 5-20 Search



Step 2 Select a remote device, and then click **Record** tab.




Click  to display only channels. Click  to display channels and devices.

Step 3 Select a record type from among **All Record**, **Video Detect**, and **IO Alarm** and **Thermal**.

- All record: Search for all records.
- Video detect: Search for the records of video detection. For setting of video detection record, see "6.4.3.1 Video Detect".
- IO alarm: Search for local alarm linkage records. For setting of local alarm linkage record, see "6.4.3.3 IPC External Alarm".
- Thermal: Search for videos of thermal alarms. For setting of thermal alarm linkage, see "6.4.3.4 Thermal Alarm".


Step 4 Select a stream type from main stream and sub stream.

Step 5 Set search time.

- Method 1: Click the date or time on the time column, change time or date value.
- Method 2: Click the date or time on the time column, use the mouse middle button to adjust time or date value.
- Method 3: Click , set date or time on the schedule, click **OK**.

In the schedule page, if there is a dot under one date (such as ²⁴ ●), the date has records.

Figure 5-21 Schedule page




Step 6 Click **Search**.

The record thumbnail is at the top of the remote device, and the time bar displays the record period (green color means there is a record).



- The selected remote device is on the left panel. Click a remote device, and the record file thumbnail is on the right panel.
- Click ◀ or ▶ to move thumbnail list or hide/display the thumbnail.
- Move the mouse pointer to the thumbnail, you can view remote device name, record start time, and end time of the corresponding record.
- Move the mouse pointer to the thumbnail list. The interface displays ▲▼. Click the icon to hide the thumbnail list. If the thumbnail list is hidden, click ▼▲ to display the thumbnail list.

Figure 5-22 Search result



- Step 7** Drag the thumbnail to the playback window or double-click the thumbnail. Device begins playing the record.





































- The playback window amount depends on the thumbnail amount you can drag or select. System supports maximum 16 windows. System automatically adjusts each window size according to the original scale of playback file.
- The thumbnail with  means system is playing record file of current thumbnail.

Figure 5-23 Search



Table 5-9 Search icons description

Signal Words	Description
	Click to synchronize playback mode. You can use the playback control icon to control several windows, such as fast forward/backward at the same time. Click  to cancel synchronization operation.
	Set a time period. Click  to start playing the videos in the set time period.
	Play back several record files at the same time. Click the icon to switch to time synchronization mode. All other windows play the video file of the same time of current window. Click  to cancel time synchronization.  Click  , system enables synchronization operation function. If you want to cancel synchronization, click  .
	Click to play back video file at slow speed. The slow speed includes $\times 1/2$, $\times 1/4$, $\times 1/8$, and $\times 1/16$. Click the icon once, the playback speed degrades one level.
	Click to switch to frame by frame backward playback.  It is only valid in pause mode.

Signal Words	Description
	Click to play backward. Now the icon becomes  . Click  to stop backward play.
	Click to start playback. Now the icon becomes  . Click  to pause playback video.
	Click to switch to frame by frame playback.  It is only valid in pause mode.
	Click to play back at fast speed. The fast speed includes $\times 1$, $\times 2$, $\times 4$, $\times 8$, and $\times 16$. Click the icon once, the playback speed upgrades one level.
	Displays playback speed. Drag  to the left or right to playback at fast forward or fast backward.
	Click to capture an image.
	Click this icon to tag the current video.
	Click to obtain one part of record, and save it in designated storage path. See "5.2.2 Clipping Recorded Video" for detailed information.
	Click  to mute. The icon becomes  . Click  to unmute.
	Click to play back at full screen.
	Time bar. Displays record type and record file period. <ul style="list-style-type: none"> ● There are two record file bars on the time bar. The top bar is to display record time of selected window. The bottom bar is to display record time of all selected remote devices. ● The time bar adopts color to categorize record type. Green=Regular record. Red=Alarm record. Blank=No record. ●  Time scale is to display record file date and time. System automatically adjusts time scale according to the record playback process. ● On the time bar, you can: <ul style="list-style-type: none"> ◇ Click the time bar and rotate the mouse wheel button to adjust the time accuracy. ◇ Press the time bar and then drag to the left or right to move the time bar to view the hidden record time. ◇ Drag time scale to adjust start time of record playback. ◇ Click or drag the time scale to position where there is a record, system starts playing from the selected time. ◇ Click or drag the time scale to position where there is no record, system stops playing record.

Signal Words	Description
	Shortcut menu: Right-click mouse on the playback window, you can view the shortcut menu. <ul style="list-style-type: none"> ● Zoom: It is to zoom in a specified zone and view the details. See "5.1.1.3.3 Digital Zoom" for detailed information. ● Original scale: Set view window scale. <ul style="list-style-type: none"> ◇ ON: System automatically adjusts video window scale according to the video resolution. ◇ OFF: System automatically adjusts video window scale according to the remote device amount and the free space on the playback panel. ● Audio: Set audio output. ● Fisheye: Set the installation method and display mode of fisheye camera. For details, see "5.1.1.3.4 Fisheye Dewarp".
	Move mouse pointer to the playback window, system pops up task column. Click the icon to close the playback window.

5.2.2 Clipping Recorded Video

Clip one part of the recorded video, and save it in designated storage path.



Connect USB device to the system if you are on the local menu to operate.


Step 1 Click and then select **SEARCH**.

Step 2 Play video file. See "5.2.1 Playing Back Recorded Video".

Step 3 Click .

Video clipping frame appears on the time bar.


Figure 5-24 Video clipping frame



Step 4 Click the record edit column (the blue column on Figure 5-24) and drag to the left or right, to select start time and end time of clipping.

Step 5 Click Save Immediately.

Figure 5-25 Save



Step 6 Click **Browser** to select saving path.

Step 7 Click **OK**.

Save the clipping to designated storage path.

5.2.3 Playing Back Snapshots

Search for and play back image according to remote device, image type, and snapshot time.


Step 1 Click **+** and then select **SEARCH**.

Step 2 Select a remote device, and then click **Image**.




System supports maximum 1 remote device.

Figure 5-26 Image playback (1)




Step 3 Select image type, including video detect, IO alarm and thermal, and then select detection type as needed.

Step 4 Set search time.

- Method 1: Click the date or time on the time column, change time or date value.
- Method 2: Click the date or time on the time column, use the mouse wheel to adjust time or date value.
- Method 3: Click , set date or time on the schedule, click **OK**.


In the schedule page, if there is a dot under one date (such as ²⁴), the date has records.





Figure 5-27 Schedule page



Step 5 Click **Search**.


Figure 5-28 Image thumbnail



- The selected remote device is on the left panel. Click a remote device, and the image thumbnail is on the right panel.
- Click  or  to move thumbnail list, and display the hidden thumbnail.
- Move the mouse pointer to the thumbnail, you can view remote device name, and snapshot time of the corresponding thumbnail.
- Move the mouse pointer to the thumbnail list. The interface displays . Click the icon to hide the thumbnail list. If the thumbnail list is hidden, click  to display the thumbnail list.

Step 6 Drag the thumbnail to the playback window or double-click the thumbnail. Device begins playing the image.

Figure 5-29 Image playback (2)



Move the mouse pointer to the playback window, you can see the following icons.

Table 5-10 Icons

Icon	Description
	Click to switch to the previous image or the next image.
	Switch to the previous or next image or image group. <ul style="list-style-type: none"> When playing one image, click the icon to go to the previous image or the next image. When playing several images at the same time, click the icon to go to the previous group or the next group.
	Click to display at full screen. Click again to cancel full screen.

5.2.4 Exporting File


Export record file or image to the designated storage path.



- The default record file mode is .dav and the image file mode is .jpg.
- Connect USB device to the system if you are on the local menu to operate.

Step 1 Click and then select **SEARCH**.

Figure 5-30 Search (1)



Step 2 Search record file or image.

- 1) Click **Record** or **Image** tab.
- 2) Select a remote device and then set search criteria.
- 3) Click **Query**.

Step 3 Select the record file or image you want to export.

- Move the mouse pointer to the thumbnail and then click to select the thumbnail.
 means checked.
- Click **Cancel** to cancel all record files or images.

Step 4 Select file storage path.


- 1) Click  and then select **Export record** or **Export image**.



The following steps are to export video file. See the actual page for detailed information.

- 2) Click **OK**.

Figure 5-31 Save



- 3) Click **Browser** to select saving path.



For local menu operation, after you set storage path, the **Save** page displays **Format** button. Click **Format** button to clear all data on the USB storage device. The formatting operation will clear all data. Be cautious.


- 4) Click **OK**.

Device goes back to **Save** page.




Step 5 Click **OK**.

The system starts to export files. The file downloading page is displayed.

Figure 5-32 Download




- Click **Pause all** to pause all download tasks. Click **Start all** to resume download tasks.
- Click **Clear completed columns** to delete all downloaded tasks.

- Click  of the corresponding task to pause download task. Click  to resume download.
- Click  of the corresponding task to delete download task.

5.2.5 Video Tag

Tag specific video segments or pictures for the ease of search. For details about viewing tagged files, see "7.1.1 Video Tag Management".

Step 1 Click , and then select **SEARCH**.

Step 2 Search for pictures or videos.

- 1) Click the **Record** or **Image** tab.
- 2) Select a camera, and then set search conditions.
- 3) Click **Search**.



Step 3 Click  at the lower-right corner of the playback window.


Figure 5-33 Tag



Step 4 Enter tag name, and then click **OK**.

5.2.6 Locking Files

Lock specific videos or pictures so they cannot be viewed. A locked file can only be viewed after being unlocked.

- Step 1** Click , and then select **SEARCH**.
- Step 2** Search for pictures or videos.
- 1) Click the **Record** or **Image** tab.
 - 2) Select a camera, and then set search conditions.
 - 3) Click **Search**.
- Step 3** Select the video files to be locked.
- Point to the thumbnail, and then click to select the video.
 - You can click **Cancel** to cancel the selected videos.
- Step 4** Click **Lock**.
- Step 5** (Optional) Click **Unlock** to unlock the locked videos.
You can also unlock videos in **FILE > FILE LOCKED**. See "7.1.2 FILE LOCKED".

5.3 Alarm List



Click  to display alarm list. View alarm device name, alarm time and alarm type.

Figure 5-34 Alarm list









- Number 9 is the number of alarm event to be processed. The value changes according to alarm amount. It displays maximum 200 unprocessed alarm events.
- Click  to lock alarm list. The alarm list is open and cannot hide. Click the icon again to cancel lock function. Move the mouse pointer to other position, and the alarm list displays for a period of time and then automatically hides.
- Click  to confirm alarm event. The confirmed event will be removed from the alarm list.
- Click the alarm event on the alarm list. The device displays the 20 seconds video before and after the alarm event occurred.
 - ◇ Click  to pause play. Now the icon becomes . Click  again to continue to play.
 - ◇ Click **OK and close**, confirm the alarm event and then exit the page.

Figure 5-35 Alarm video



5.4 System Information

View system information including system error, system alarm and system notification.




Click  to display background task list.

Figure 5-36 System information



- Click **All**, **Error**, **Warning**, or **Notification** tab to view the corresponding system information list.
- Click  to clear the corresponding system information.
- Click **Clear** to clear system information under current tab.
For example, click **All** tab and then click **Clear** button to clear all system information. Click **Error** tab and then click **Clear** button to clear all system error information.

5.5 Background Task

View background task running status.



Click , device displays background task list. Click **All**, **Running**, or **Waiting** to view the corresponding background task list.

Figure 5-37 Background task



5.6 Buzzer

View buzzer alarm messages.



Click . The alarm messages are displayed.

Figure 5-38 Buzzer



6 System Configuration

This chapter introduces system configuration functions such as managing remote device, setting network, setting alarm event, setting HDD storage, managing user information, setting device security strategy, and setting system parameters.

6.1 Configuration Page




Click . The following page is displayed.



Figure 6-1 Configuration page




On this page, you can:

- Click the corresponding app icon to go to the corresponding page. The task column displays current running app name. Move the mouse pointer to the app name and then click  to close the app.
- Click **Exit** to exit the page.

6.2 Device Management

Click  or click  on the configuration page, and then select **DEVICE**. The **DEVICE** page is displayed. You can set EVS or remote devices.

- Select the root node  in the resource tree to set EVS name and storage plan.
- Select a remote device in the Device list. Set its property, connection, video, OSD, and storage plan.




Click  or click **Add** to add remote device to the system. See "3.4.2 Adding Remote Device" for detailed information.


Figure 6-2 Device management

Channel No.	State	Channel Name	Address	Regist ID	Port	User Name	Password	Manufacturer	Product Model	Sn	Remote CH...	Oper...
1	●	IPC		--	37777	admin	*****	Private	--		1	
2	●	IPC		--	37777	admin	*****	Private	--		2	
3	●	IPC		--	37777	admin	*****	Private	--		3	
4	●	IPC		--	37777	admin	*****	Private	--		4	
5	●	IPC		--	37777	admin	*****	Private	--		5	
6	●	IPC		--	37777	admin	*****	Private	--		6	
7	●	IPC		--	37777	admin	*****	Private	--		7	
8	●	IPC		--	37777	admin	*****	Private	--		8	
9	●	IPC		--	37777	admin	*****	Private	--		9	
10	●	IPC		--	37777	admin	*****	Private	--		10	
11	●	Onvif		IPC205	0	admin	*****	Register			1	
12	▲	Channel12		--	80	admin	*****	Onvif	--		1	
13	▲	Channel13		--	37777	admin	*****	Private	--		1	

Total 13 item(s) Show up to 50

6.2.1 Viewing Device Information

View information of the Device.

Step 1 Click , and then select **DEVICE**.

Step 2 Select the root node in the resource tree, and then click the **Device Info** tab.

Step 3 Set parameters.

Figure 6-3 Device info

Name

Description

∨ DEVICE INFO

Slot	Mainboard(Slot1)	Slot	Standby Board(Slot2)
Type	EVS	Type	EVS
SN	7 [redacted] AC	SN	7A [redacted] C
Single Board SN	5 [redacted] 27	Single Board SN	7A [redacted] 94
MAC1	b [redacted]	MAC1	24 [redacted]
MAC2	b [redacted]	MAC2	24 [redacted]
MAC3	b [redacted]	MAC3	24 [redacted]
MAC4	b [redacted]	MAC4	24 [redacted]
MAC18	b [redacted]	MAC18	24 [redacted]
System Version	V [redacted] .0.R, Build Date: 2022-04-26 04:01:59	System Version	V4 [redacted] .0.R, Build Date: 2022-04-26 04:01:59
Security Baseline Version	V2.2	Security Baseline Version	V2.2
WEB Version	V4.0.0.148881	WEB Version	V4.0.0.148881
ONVIF Client Version	V2.4.1	ONVIF Client Version	V2.4.1
ONVIF Server Version	21.12(V3.1.0.1207744)	ONVIF Server Version	21.12(V3.1.0.1207744)
Video In/Out	400/512	Video In/Out	400/512
Input bandwidth	819.71Mbps/1024.00Mbps	Input bandwidth	819.71Mbps/1024.00Mbps

Table 6-1 Device info parameters

Parameters	Description
Name	Set device name.
Description	Enter device description.
Device info	Displays device info, including device SN, mainboard SN, MAC, video in/out, input bandwidth, system version, security baseline version, and web version.

Step 4 Click **Save**.

6.2.2 Remote Devices

Add remote devices, change IP addresses and configurations, and export remote device information.



See "3.4.2 Adding Remote Device" for detailed information.

6.2.2.1 Viewing Remote Devices

View connected remote devices. For details about adding devices, see "3.4 Configuring Remote Device".

Step 1 Click or click on the configuration page, and then select **DEVICE**.

Step 2 Select the root node in the resource tree, and then click the **Device List** tab.

Figure 6-4 Device list

Channel No.	State	Channel Name	Address	Regist ID	Port	User Name	Password	Manufacturer	Product Model	Sn	Remote CH.	Oper.
1	●	IPC		--	37777	admin	*****	Private	--		1	
2	●	IPC		--	37777	admin	*****	Private	--		2	
3	●	IPC		--	37777	admin	*****	Private	--		3	
4	●	IPC		--	37777	admin	*****	Private	--		4	
5	●	IPC		--	37777	admin	*****	Private	--		5	
6	●	IPC		--	37777	admin	*****	Private	--		6	
7	●	IPC		--	37777	admin	*****	Private	--		7	
8	●	IPC		--	37777	admin	*****	Private	--		8	
9	●	IPC		--	37777	admin	*****	Private	--		9	
10	●	IPC		--	37777	admin	*****	Private	--		10	
11	●	Onvif		IPC205	0	admin	*****	Register			1	
12	▲	Channel12		--	80	admin	*****	Onvif	--	--	1	
13	▲	Channel13		--	37777	admin	*****	Private	--	--	1	

Step 3 View details of connected devices, including IP address and serial number.

- In the **State** column, indicates that the Device is offline.
- In the **State** column, indicates that the Device is online.
- In the **State** column, indicates that the Device is exception. Point to , and then you are prompted about the details of the exception, such as being uninitialized, device mismatch, and wrong password.

Step 4 (Optional) Click to set searching conditions.

Step 5 (Optional) You can select the uninitialized devices to initialize them. For details, see "3.4.1 Initializing Remote Device".

6.2.2.2 Changing IP Address

Modify IP address of the remote device connected or not connected to the Device.

6.2.2.2.1 Modifying IP of Unconnected Devices



- You can only modify the IP address of initialized devices. For remote device initialization, see "3.4.1 Initializing Remote Device" for detailed information.
- You can only modify the IP address of remote devices connected with private protocol.

Step 1 Click , or click on the configuration page, and then select **DEVICE**.

Step 2 Click or click **Add**, and then select **Smart Add**.

Step 3 Click Start Search.

Figure 6-5 Remote device

Add Device
✕

Smart Add
Manual Add
RTSP
Batch Import

Stop Search
Password
Initialize
Modify IP

<input type="checkbox"/>	(0)	Initialization Sta...	Address	Product Model	Manufacturer	Port	Product Type	Sn	Operate
<input type="checkbox"/>	✓	Initialized	192.168.1.10	IPC-HFW1234	Onvif	80	--	--	
<input type="checkbox"/>	✓	Initialized	192.168.1.11	IPC-HFW1234	Onvif	80	--	--	
<input type="checkbox"/>	✓	Initialized	192.168.1.12	IPC-HFW1234	Onvif	80	--	--	
<input type="checkbox"/>	✓	Initialized	192.168.1.13	IPC-HFW1234	Private	37777	EVS	5K02166YAJ...	
<input type="checkbox"/>	✓	Initialized	192.168.1.14	IPC-HFW1234	Private	37777	EVS	5K02166YAJ...	
<input type="checkbox"/>	✓	Initialized	192.168.1.15	IPC-HFW1234	Private	37777	EVS	4M05A23YAJ...	
<input type="checkbox"/>	✓	Initialized	192.168.1.16	IPC-HFW1234	Private	37777	EVS	4M05A23YAJ...	

Total 7 Item(s) Show up to 50
<< 1/1 >>
GO

Remaining Bandwidth/Total: 362.46 Mbps/ 1024 Mbps
Add
Cancel

Step 4 Select a remote device and then click **Modify IP**.

Figure 6-6 Modify IP

Modify IP address
✕

(1)	Sn	IP Address
	--	10.0.0.1

Static IP Address

Subnet Mask

Gateway

admin

.....

Incremental Value

support Private, Onvif only

Next
Cancel

Step 5 Enter the static IP address, subnet mask, gateway, and incremental value.



- Enter incremental value only when multiple remote devices are modified. If you want to change IP addresses of several devices at the same time, system allocates IP address one by one according to your setting at the fourth bit of the IP address.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. To change IP addresses in batches, system automatically skips the conflicted IP and begins the allocation according to the incremental value.

Step 6 Enter the username and password of remote device.



When you are changing several device IP addresses, make sure that the username and password of these remote devices are the same.

Step 7 Click **Next**.

The modification result is displayed.

Step 8 Click **OK** to complete the modification.

6.2.2.2 Modifying IP of Connected Devices



- You can only modify the IP address of initialized devices. For remote device initialization, see "3.4.1 Initializing Remote Device" for detailed information.
- You can only modify the IP address of remote devices connected through private protocol.
- To modify the IP address of connected devices one by one, see "6.2.2.3.2 Configuring Connection Information".



Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Figure 6-7 Device management

Channel No.	State	Channel Name	Address	Regist ID	Port	User Name	Password	Manufacturer	Product Model	Sn	Remote CH...	Operate
1	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	1	🔒
2	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	2	🔒
3	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	3	🔒
4	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	4	🔒
5	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	5	🔒
6	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	6	🔒
7	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	7	🔒
8	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	8	🔒
9	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	9	🔒
10	●	IPC		--	37777	admin	*****	Private	--	00000000000000000000000000000000	10	🔒
11	●	Onvif		IPC205	0	admin	*****	Register	00000000000000000000000000000000	00000000000000000000000000000000	1	🔒
12	▲	Channel12		--	80	admin	*****	Onvif	--	--	1	🔒
13	▲	Channel13		--	37777	admin	*****	Private	--	--	1	🔒

Step 2 Select a remote device and then click **Modify IP**.

Figure 6-8 Modify IP

Step 3 Enter the IP address, subnet mask, gateway, and incremental value.



- Enter incremental value only when multiple remote devices are modified. If you want to change IP addresses of several devices at the same time, system allocates IP address one by one according to your setting at the fourth bit of the IP address.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. To change IP addresses in batches, system automatically skips the conflicted IP and begins the allocation according to the incremental value.

Step 4 Enter the username and password of remote device.



When you are changing several device IP addresses, make sure that the username and password of these remote devices are the same.

Step 5 Click **Next**.

The result of IP modification is displayed.

Step 6 Click **OK**.

6.2.2.3 Configuring Remote Devices



Set remote device property, connection information, and video parameters.



Different remote devices have different pages. See the actual page for detailed information.

6.2.2.3.1 Viewing Device Property

Set remote device name, and view device information.

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Step 2 Select a remote device on the left panel and then click **Property** tab.

Step 3 Set parameters.



Table 6-2 Property parameters description

Parameters	Description
Name	Set remote device name. Enable Sync to remote device and save the settings to synchronize new name to the remote device.
Description	Input remote device description.
DEVICE INFO	Displays remote device information. It includes remote device type, SN, MAC address, video in/out, audio in/out, alarm in/out, and system version.

Step 4 Click **Save**.

6.2.2.3.2 Configuring Connection Information

Set connection information of remote device, such as IP address and port number.

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Step 2 Select a remote device on the left panel and then click the **Connection** tab.

Step 3 Change IP address.



- 1) Click  of the corresponding address.
- 2) Enter IP address, subnet mask and gateway.
- 3) Click **Test** to test whether the IP address is valid.

Figure 6-9 Modify IP

- 4) Click **OK** to save setting.

Step 4 Change port number.

- 1) Click  of the corresponding port.

The **Modify Port** page is displayed. See Figure 6-10.

Figure 6-10 Port


- 2) Change port number.
- 3) Click **OK** to save setting.

Step 5 Set other parameters.


Table 6-3 Connection parameters description

Parameters	Description
Manufacturer	Displays the connection protocol of the remote device.
User Name	Enter username and password of remote device. The password should consist of 8 to 32 non-blank characters and contain at least two types of characters among uppercase, lowercase, number, and special character (excluding ' " ; : &). Enter a strong password according to the password strength indication.
Password	
Link type	Displays link type of the system and remote device. It is self-adaptive.

Step 6 Click **Save**.



Step 7 (Optional) Click , and then you can go to the web interface of the remote device.



On the local interface of the Device, you cannot click  to go to the web interface of the remote device.


6.2.2.3.3 Configuring Video Parameters

Set different video parameters according to different bit stream types based on the bandwidth.

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Step 2 Select a remote device on the left panel and then click **Video** tab.

Figure 6-11 Video




Step 3 Set main stream, sub stream 1, or sub stream 2.

Step 4 Set general video quality parameters.

Table 6-4 Video parameters description

Parameters	Description
Smart Codec	<p>Enable this function to enhance performance of video compression and thus reduce storage space requirement.</p> <p> This function is only available for main stream.</p>
SVC	<p>Select the checkbox to enable SVC function. Select 1 or 2 from the drop-down list on the right. The default setup is 1, there is no scaled encoding.</p> <p> SVC refers to the scaled video coding. It can split the video stream to basic stream and enhanced scale.</p>
Encode mode	<p>Set video encode mode.</p> <ul style="list-style-type: none"> H.264: It is a highly compressed video encoding or encoding standard. At the same video quality, it has increased the compression rate by 2X compared with the MPEG-2. H.265: It is a new video encode standard coming after H.264. It has improved the complicated relationship among bit stream, encode quality, latch and algorithm on the previous standard. It can get the best encoding.
Resolution	<p>Set video resolution. The higher the resolution is, the better the video quality is.</p> <p> Different series products support different resolutions. See the actual page for detailed information.</p>
FPS	<p>Set the frame amount displayed at each second. The higher the frame rate is, the more vivid and fluent the video is.</p>
Stream mode	<p>Set video bit stream control mode.</p> <ul style="list-style-type: none"> CBR: The bit stream changes slightly. The bit stream is near the value you set here. VBR: The bit stream might change according to the environment.

Parameters	Description
Quality	Set video quality. It includes low, middle, high.  It is null when the stream mode is CBR.
Bitrate	Set video bitrate. <ul style="list-style-type: none"> ● Main stream: In the Bit Rate list, select a value or enter a customized value to change the image quality. The larger the value is, the better the image will become. ● Sub stream: In CBR mode, the bit stream changes around the value you set. In VBR mode, it changes according to the bit stream value, but its max value is near the specified value.
I frame interval	Set the P frame amount between two I frames. Usually we recommend it is the 2X of the frame rate.

Step 5 Enable **Event Video Quality** and set FPS and stream mode.





Event video quality is for main stream only.

Step 6 Click **Save**.


6.2.2.3.4 Configuring OSD

Configure overlay time information, and channel information on the video.

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Step 2 Select a remote device on the left panel and then click **OSD** tab.

Figure 6-12 OSD



Step 3 Enable OSD information according to actual requirements.



- Set device name
 1. Click  to enable OSD of device name.
 2. Click .
 3. Enter device name.

Figure 6-13 Device name

4. Drag the text box to the proper position.
 5. Click to save the OSD information.
- Set time information
 1. Click to enable OSD of time.
 2. Click .

Figure 6-14 Time

3. Drag the text box to the proper position.
 4. Click to save the OSD information.
- Set geographical position
 1. Click to enable OSD of geographical position.
 2. Click .
 3. Enter the geographical position information.



- ◇ Click to adjust the alignment of text boxes.
- ◇ Click to create a text box.
- ◇ Click to delete a text box.

Figure 6-15 Geographical position




4. Drag the text box to the proper position.
 5. Click to save the OSD information.
- Set privacy masking





This function is available only when the camera supports privacy masking.

1. Click to enable privacy masking.

2. Click **Add**, select the masking type and color, and then draw mosaic or color blocks in the image as needed.
3. Drag blocks to the proper position.
4. Click  to save the OSD information.


Step 4 Click **Save**.

6.2.2.3.5 Configuring Audio Parameters

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.


Step 2 Select a remote device on the left panel and then click **Audio** tab.

Figure 6-16 Audio



Step 3 Select an audio output type.

- Lineln: The Device acquires audio signals through external audio device.
- Mic: The Device acquires audio signals through internal mic.

Step 4 Click  to enable **Noise Filter**.

Step 5 Click the **Main Stream**, **Substream1** or **Substream2** tab, and then configure the parameters.

Table 6-5 Audio parameters

Parameter	Description
Compression	The audio encoding mode set here applies to both audio streams and voice talks. We recommend leaving it as default.
Sampling Frequency	The number of samples of a sound that are taken per second. The higher the value, the more accurate the digital representation of the sound can be.



Step 6 Click **Save**.


6.2.2.4 Exporting Remote Devices in Batches

Export the added remote device. When the Device restores factory default settings or information of remote device is lost, export information of remote device to recover quickly.



See "3.4.2 Adding Remote Device" for detailed information.

Step 1 Click , or click  on the configuration page, and then select **DEVICE**.

Step 2 Click  at the lower-left corner.



Click **Download Template** to download template file of the remote device, and add remote device through the template.

Figure 6-17 Export



Step 3 Select encryption or not.

- If you select **Yes**, the system exports encrypted .backup file.
- If you select **No**, the system exports .csv file, which can be opened with Excel. The exported .csv file contains IP address, registration ID, port number, channel number, channel name, manufacturer, username (excluding password), link type, remote channel number, product model and SN of the remote device.




When unencrypted file is exported, keep the file properly to avoid data leakage.

Step 4 Click **OK**.

Step 5 Click **Save**.

File path might be different depending on page operations. See actual pages.

- On PCAPP, click , select **Download** to view file saving path. For details, see "9.3 Viewing Downloads".
- Select file saving path during local operation.



Connect USB device to the system if you are on the local menu to operate.

- During web operations, files are saved under default downloading path of the browser.

6.2.2.5 Importing Remote Devices in Batches

Import devices in batches by using the template.

On the **Device List** page, click **Batch Import** to go to the **Add Device** page. On the **Add Device** page, click the **Import CSV File** tab. For further operation instruction about how to use the CSV file to import devices in batches, see "3.4.2.4 Batch Add".

Figure 6-18 Import in batches

Add Device
✕

Smart Add
Manual Add
RTSP
Batch Import

Choose File

Browse
Import
Download Template

<input type="checkbox"/>	(0) Manufacturer	Address ↕	User Name ↕	Password ↕	Port ↕	Channel No	Remote CH No...	Operate

Total 0 Item(s) Show up to 50

<<
<
1/1
>
>>
GO

Remaining Bandwidth/Total: 375.16 Mbps/ 1024 Mbps

 Overwrite
 ADD

Add
Cancel


6.2.2.6 Connecting Remote Devices

On the **Device** page, view connection status of remote device in the Device list.

When the remote device name and icon is black, SDT5A403 for example, it means the remote device is online. When they are gray, C2 8249 for example, it means the remote device is offline.





- Right-click the offline device, and then select **Connect** to connect the Device.
- Right-click the online device, and then select **Disconnect** to disconnect the Device.
- Right-click the online device, and then select **Open WEB** to go to the web interface of the Device.

Figure 6-19 Device list



6.2.2.7 Deleting Remote Devices



On the **Device** page, delete the registered remote device.

- Delete one by one:
 - ◇ Select a remote device and then click  to delete.
 - ◇ On the **Device List** page, right-click a remote device and then click **Delete**.
 - ◇ On the **Device List** page, select a remote device, and then click .
 - ◇ On the **Device List** page, select a remote device, and then click **Delete**.
- Batch delete:
 - ◇ Click , device list displays checkbox for you to select multiple remote devices. Click  to delete the selected devices.
 - ◇ On the **Device List** page, select multiple remote devices, and then click **Delete**.

6.2.2.8 Configuring Camera Name


You can view and change the name of the connected cameras.

Step 1 Log in to PCAPP.

Step 2 Click , or click  on the configuration page, and then select **DEVICE**.

Step 3 Select the root node in the resource tree and then click the **Camera Name** tab.

Figure 6-20 Camera name



Step 4 Select a channel, enter a new name, and then click **Save**.

6.3 Network Management

Click or click on the configuration page, select **NETWORK**. The **NETWORK** page is displayed. You can set basic network parameters and application.

Figure 6-21 Network management

Enable ⚠ It is recommended that virtual IP address and default NIC IP address should be in the same network segment.

IP Address: Subnet Mask:

Default Gateway:

Slot: Slot1 Mainboard: Slot1 Port Aggregation

NIC	NIC Type	Dhcp	IP Address	Subnet Mask	Mac	Speed	Operate
<input checked="" type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input checked="" type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Manage NIC	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	

DNS Server: IP Type: Obtain DNS server address automatically Use the following DNS server address

Preferred DNS: Alternate DNS:

Default NIC: Default Ethernet:

6.3.1 Basic Network

Set basic network parameters of the Device, such as IP address, port aggregation and port number, to connect with other devices in the network.

6.3.1.1 Configuring IP Address

Set device IP address, DNS server information and other information according to network planning.



Make sure that at least one Ethernet port has connected to the network before you set IP address.

Step 1 Click or click on the configuration page, and then select **NETWORK > Basic Network > TCP/IP**.



Click to view the NIC parameter information.

Figure 6-22 TCP/IP

Enable

IP Address

Subnet Mask

Default Gateway

It is recommended that virtual IP address and default NIC IP address should be in the same network segment.

6

Slot: Slot1 Mainboard: Slot1

NIC	NIC Type	Dhcp	IP Address	Subnet Mask	Mac	Speed	Operate
<input checked="" type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input checked="" type="radio"/> Ethernet Netw...	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	
<input type="radio"/> Manage NIC	Electric Port	No	<input type="text"/>	255.255.255.0	b- <input type="text"/>	10M/100M/1000M...	

DNS Server

IP Type: IPV4

Obtain DNS server address automatically

Use the following DNS server address

Preferred DNS

Alternate DNS

Default NIC

Default Ethernet: Ethernet Network1

Step 2 Click to enable the virtual IP address, and then set the virtual IP address, subnet mask and default gateway.

The main board and standby board have their respective physical IP. After setting the virtual IP, despite the switch between the main and standby boards, you can always log in to the web interface with the virtual IP.



The default virtual IP address is 192.168.0.108. We recommend you set the virtual IP address and the IP address of the default NIC on the same network segment.


Step 3 Select a slot from **Slot1** and **Slot2**.

Step 4 Click of the corresponding NIC.

Figure 6-23 Edit Ethernet network

Step 5 Set parameters.

Table 6-6 TCP/IP parameters description

Parameters	Description
Speed	Current NIC max network transmission speed.
IP Type	Select IPv4 or IPv6.
Use Dynamic IP Address	When there is a DHCP server on the network, check the box to use dynamic IP address, system can allocate an dynamic IP address to the Device. There is no need to set IP address manually.
Use Static IP Address	Check the box to use static IP address. Set static IP address, subnet mask and gateway. Set a static IP address for the Device.
MTU	Set NIC MTU value. The default setup is 1500 Byte. We recommend you check the MTU value of the gateway first and then set the Device MTU value equal to or smaller than the gateway value. Reduce the packets slightly and enhance network transmission efficiency.  Changing MTU value might result in NIC reboot, network offline and affect current running operation. Please be careful!

Step 6 Click **OK**.

Go back to **TCP/IP** page.

Step 7 Set DNS server information.

You can select to get DNS server manually or input DNS server information.



This step is compulsive if you want to use domain service.

- Check the box to auto get DNS server address, device can automatically get the DNS server IP address on the network.

- Check the box to use the following DNS server addresses, and then enter primary DNS and alternate DNS IP address.

Step 8 Set default NIC.

Select default NIC from the drop-down list.



Make sure that the default NIC is online.

Step 9 Click **Save**.

6.3.1.2 Port Aggregation

Bind multiple NIC to create one logic NIC and use one IP address for peripheral device. The bonded NIC can work as the specified aggregation mode to work. It enhances network bandwidth and network reliability.

System supports configuring load balance, fault tolerance, and link aggregation. See Table 6-7.

Table 6-7 Aggregation mode description

Aggregation mode	Description
Load balance	<p>Device has bonded several NICs at the same time and use one IP address to communicate with the external device. The bonded NICs are working together to bear the network load.</p> <p>The load balance mode adds the network throughput data amount and enhances network flexibility and availability. In this mode, the network is offline once all NICs break down.</p>
Fault-tolerance	<p>In this mode, device has bonded several NICs and set one NIC as the main card and the rest NICs are the alternative NICs. Usually, only the main NIC card is working. System can automatically enable other alternate cards to work when the main card breaks down.</p> <p>Fault-tolerance is a network mode to enhance NIC reliability. In this mode, the network is offline once all NICs break down.</p>
Link aggregation	<p>Device has bonded several NICs and all NICs are working together to share the network load. System allocates data to each NIC according to your allocated strategy. Once the system detects that one NIC breaks down, it stops sending data with this NIC, and then system transmits the data among the rest NICs. System calculates transmission data again after malfunctioning NIC resumes work.</p> <p>In this mode, the network is offline once all bonded NICs are malfunctioning.</p> <p>Make sure that the switch supports link aggregation and you have set the link aggregation mode.</p>

6.3.1.2.2 Binding NIC

System supports load balance, fault-tolerance, and link aggregation. Select bind mode according to your actual requirements.

Step 1 Click or click on the configuration page, and then select **NETWORK > Basic Network > TCP/IP**.

Step 2 Bind NICs.

1) Click **Port Aggregation**.

Figure 6-24 Port aggregation

Port Aggregation						
NIC	NIC Type	Dhcp	IP Address	Subnet Mask	Mac	Speed
<input checked="" type="checkbox"/> Ethernet Network1	Electric Port	No	<input type="text" value="192.168.1.101"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive
<input checked="" type="checkbox"/> Ethernet Network2	Electric Port	No	<input type="text" value="192.168.1.102"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive
<input type="checkbox"/> Ethernet Network3	Electric Port	No	<input type="text" value="192.168.1.103"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive
<input type="checkbox"/> Ethernet Network4	Electric Port	No	<input type="text" value="192.168.1.104"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive
<input type="checkbox"/> Manage NIC	Electric Port	No	<input type="text" value="192.168.1.105"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive

2) Select the NICs you want to bind.

3) Select an aggregation mode.

4) Click **Port Aggregation**.



The setting page varies depending on the aggregation mode you have selected. Figure 6-25 is the load balance setting page.

Figure 6-25 Edit load balance

Edit Load-Balance(Ethernet Network1+2) ✕

Speed

IP Type

Use Dynamic IP Address

Use Static IP Address

Static IP Address

Subnet Mask


Gateway

MTU (1500-7200)

NIC	Mac	Speed
Ethernet Network1	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive
Ethernet Network2	<input type="text" value="08:00:00:08:00:08"/>	10M/100M/1000MSelf-Adaptive

5) Set parameters.

Table 6-8 TCP/IP parameters description

Parameters	Description
Speed	Maximum network transmission speed of current NIC.
IP Type	Select IPv4 or IPv6.
Use Dynamic IP Address	When there is a DHCP server on the network, check the box to use dynamic IP address. System can allocate a dynamic IP address to the Device. There is no need to set IP address manually.
Use Static IP Address	Check the box to use static IP address. Set static IP address, subnet mask and gateway. Set a static IP address for the Device.
MTU	<p>Set NIC MTU value. The value is 1500 bytes by default.</p> <p>We recommend you check the MTU value of the gateway first and then set the Device MTU value equal to or smaller than the gateway value. Reduce the packets slightly and enhance network transmission efficiency.</p> <p></p> <p>Changing MTU value might result in NIC reboot, network offline and affect current running operation. Please be careful!</p>

6) Click **OK**.



Step 3 Click **Save**.

Step 4 Click **OK** to save the configuration.

The binding card information becomes activated after reboot operation.


6.3.1.2.3 Cancelling Binding NIC

Cancel port aggregation and allow the bonded NICs to work as independent card.

Step 1 Click  or click  on the configuration page, and then select **NETWORK > Basic Network > TCP/IP**.

Step 2 Select a bound NIC.

Figure 6-26 Confirm



- Step 3** Click **OK**.
System splits the bonded NIC.



After splitting NIC binding, the first NIC reserves the IP address configured during binding, while the rest NICs restore default IP addresses.

6.3.1.3 Setting Port Number



- Step 1** Click , or click  on the configuration page, and then select **NETWORK > Basic Network > Port**.

Figure 6-27 Port

Step 2 Set parameters.



Log in again after modifying parameters except **Max Connection**.

Table 6-9 Connection setting parameters description

Parameters	Description
Max Connection	The allowable maximum clients accessing the Device at the same time, such as web, PCAPP, and Platform. Select a value between 1 and 128. The default value setting is 20.
TCP Port	Set according to the actual requirements. The default value is 37777. The value ranges from 1025 to 65535.
RTSP Port	Set according to the actual requirements. The default value is 554. The value ranges from 1 to 65535.
HTTP Port	Set according to the actual requirements. The default value is 80. The value ranges from 1 to 65535. If the value you set is not 80, please add the port number after the IP address when you are using browser to login the Device.
HTTPS Port	Set according to the actual requirements. The default value is 443. The value ranges from 1 to 65535.
UDP Port	Set according to the actual requirements. The default value is 37778. The value ranges from 1025 to 65535.

Step 3 Click **Save**.

System reboots corresponding service of the port.

6.3.2 Network Apps



Set device network parameters, so that system can connect to other devices.

6.3.2.1 P2P

P2P is a peer to peer technology. You can scan the QR code to download cellphone APP without DDNS service or the port mapping or installing the transmission server. After register the Device to the APP, you can view the remote video, playback record file and so on.





- Make sure that the system has connected to the network. Otherwise, the P2P function is null.
- When using the P2P function, we will collect device information such as IP address, MAC address, name and serial number. The collected information is only used for remote access.

Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > P2P**.

The **P2P** page is displayed. Scan the QR code on the actual page.

Figure 6-28 P2P



Step 2 Click  to enable P2P function.

Step 3 Click **Save**.

After the configuration, you can register a device to the APP to view remote video, playback record file, and so on. See corresponding cellphone APP for detailed information.



After successfully connected to the P2P, the status displayed as **Success**.

6.3.2.2 DDNS

After setting DDNS parameters, when IP address of EVS changes frequently, the system dynamically updates the relation between domain name and IP address on DNS server. You can use domain name to remotely access EVS, without need to note down IP address.

Preparation

Confirm whether EVS supports the DDNS Type and log in the website provided by the DDNS service provider to register the information such as domain from PC located in the WAN.



After you have registered and logged in the DDNS website successfully, you can view the information of all the connected devices under this username.

Procedure



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Basic Network > DDNS**.

Figure 6-29 DDNS

Step 2 Click  to enable DDNS function.



After enabling DDNS function, the third-party server might collect your device information. Pay attention to privacy security.

Step 3 Set the corresponding parameters.

Table 6-10 DDNS setting parameters description

Parameters	Description
DDNS Type	Name and address of DDNS service provider.
Server Address	<ul style="list-style-type: none"> ● DynDNS DDNS: members.dyndns.org ● NO-IP DDNS: dynupdate.no-ip.com ● CN99 DDNS: members.3322.org
Domain	The domain name for registering on the website of DDNS service provider.
Username	Enter the username and password obtained from DDNS service provider. You need to register (including username and password) on the website of DDNS service provider.
Password	
Update Circle	Enter the amount of time that you want to update the DDNS.
Current WAN IP	Displays the WAN IP address of EVS.
Status	Displays DDNS registration result or update status.

Step 4 Click **Save**.

After successful configuration, enter domain name in address bar of the browser or PCAPP, and press Enter key to access the EVS.

6.3.2.3 Email

Configure email information, and enable alarm linkage email. When NVR has alarm events, the system automatically sends emails to the user.



Device data will be sent to specific servers after the email function is enabled. Be cautious.



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > Email**.

Figure 6-30 Configuring email

Step 2 Click to enable the email function.

Step 3 Set parameters.

Table 6-11 EMAIL parameter description



Parameters	Description
Email Server	Select email server type, including Customize , Gmail , Hotmail , and Yahoo .
Server Address	Enter email server address.
Encryption	Select encryption type of email server, including NONE , SSL , and TLS . You are recommended to select TLS. The other encryption methods might not be safe.
Port	Enter the port number of email server.
User name and password	Enter the configured username and password of email server.

Step 4 Add the information of email receiver.

- 1) Click **Add**.
- 2) Enter a receiver email address.

Figure 6-31 Email address



- 3) Click **Add** or  to add other receiver email address.
 - Click  to delete the added receiver.
 - Select a receiver. The **Delete** button is displayed. Click **Delete** button to delete the selected receiver.

Step 5 Click **Save**.

Step 6 (Optional) Test the email sending function.

- 1) In **Test Mail**, select or enter a receiver email address.
- 2) Click **Send**.
 - When the configuration is correct, the system pops up a message of success, and the receiver will receive the test mail.
 - Otherwise, the system pops up a message of failure, and the receiver will not receive the test mail.

6.3.2.4 SNMP

After setting SNMP (Simple Network Management Protocol) and successfully connecting devices through relevant software tools such as MIB Builder, and MG-SOFT MIB Browser, you can directly manage and monitor devices on software tools.



- Install SNMP device monitoring and management tools, such as MIB Builder and MG-SOFT MIB Browser.
- Obtain the MIB file corresponding to the current version from technical support.



Step 1 Click , or click  on the configuration page, and then select **NETWORK >Network Apps > SNMP**.

Figure 6-32 SNMP (1)

The screenshot shows the SNMP configuration page. At the top, there is a 'SNMP' header with a dropdown arrow. Below it, the 'Enable' checkbox is checked. The 'SNMP Version' dropdown menu is set to 'SNMP V1/V2'. The 'Port' field contains the number '161'. The 'Read Community' and 'Write Community' fields are empty. The 'Trap Server' field is empty. The 'Trap Port' field contains '162' and has a small note '(1-65535)' next to it. In the bottom right corner, there is a warning icon with the number '0' next to it.

Step 2 Click to enable the function.

Step 3 Select SNMP version.

- If you have selected SNMP V1/V2, see Figure 6-32.



SNMP V1/V2 has security risks. You are recommended to use SNMP V3.


- If you have selected SNMP V3, see Figure 6-33.

Figure 6-33 SNMP (2)

Step 4 Set parameters. For Trap server address, enter the IP address of the PC that has MG-SOFT MIB Browser. Keep the other parameters as default.

Table 6-12 SNMP parameters

Parameters	Description
Port	Listening port of agent programs on the Device.
Read Community	Read or Write Community supported by the agent programs.
Write Community	The name can only contain numbers, letters, underscores, and middle lines.
Trap Server	The destination address of Trap information sent by the agent program.
Trap Port	The destination port of Trap information sent by the agent program.
Read Only User	Set the username the read-only user. The read-only user can only have the read-only permission. The name can only contain numbers, letters, and underscores.
Read Authentication Type	You can select MD5 or SHA. It is MD5 by default.
Read Authentication Password	The password must contain at least 8 digits.
Read Encryption Type	CFB-AES by default.

Parameters	Description
Read Encryption Password	The password must contain at least 8 digits.
Read/Write User	The username is <i>private</i> by default. If you log in using this username, you have the read-and-write permission.  The name can only contain numbers, letters, and underscores.
R/W Authentication Type	You can select MD5 or SHA. It is MD5 by default.
R/W Authentication Password	The password must contain at least 8 digits.
R/W Encryption Type	CFB-AES by default.
R/W Encryption Password	The password must contain at least 8 digits.

Step 5 Click **Save**.

6.3.2.5 Register

Register the Device on designated proxy server, and client software visits the Device through the proxy server.



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > REGISTER**.

Figure 6-34 Register



Step 2 Click  to enable the function.

Step 3 Set parameters.

Table 6-13 Register

Parameters	Description
IP Type	Select IP address of server for registration.
Server	In the Server box, enter the IP address of server for registration.
Port	Enter the port number of the server for registration.
Device ID	Enter Device ID to identify EVS uniquely. Device ID shall be consistent with server configuration.

Step 4 Click **Save**.

6.3.2.6 UPnP

Through the UPnP (Universal Plug and Play) protocol, you can establish a mapping relationship between the LAN and the WAN, the WAN user can use the WAN IP address to directly access the Device in the LAN.



Device services and ports will be mapped to the public network after UPnP is enabled. Be cautious.



- Make sure that your PC has UPnP network services installed.
- Log in to the router and set the WAN port IP address of router.
- Enables the UPnP function on the router.
- Connect the Device to the router LAN (Local Area Network, LAN) port.
- Select **NETWORK > Basic Network > TCP/IP**, and then set the IP address to be the private-network IP of the router, or select DHCP to automatically obtain the IP address.



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > UPnP**.

Figure 6-35 UPnP

Port Mapping

State Search...

LAN IP






WAN IP

Port Mapping List

Service Name	Protocol	Internal Port	External Port	Operate
HTTP	TCP	80	8080	
TCP	TCP	37777	37777	
UDP	UDP	37778	37778	
RTSP	TCP	554	554	
RTSP	UDP	554	554	
SNMP	UDP	161	161	
HTTPS	TCP	443	443	

Step 2 Set parameters.

Table 6-14 UPnP parameters

Parameters	Description
Port Mapping	Click  to enable UPnP.
State	The status of port mapping.
LAN IP	The LAN IP address of router.  The IP address is automatically obtained after the mapping succeeds.
WAN IP	The WAN IP address of router.  The IP address is automatically obtained after the mapping succeeds.
Port Mapping List	The list is consistent with the UPnP port mapping list on the router. <ul style="list-style-type: none"> ● Internal Port: The EVS port to be mapped on the router. ● External Port: The WAN port of the internal port.  <ul style="list-style-type: none"> ● When setting the external port, use the ports between 1024 and 5000, and do not use the well-known ports 1 to 255 and the system ports 256 to 1023, so as to avoid conflicts. ● When there are multiple devices within the LAN, properly plan the port mapping to avoid conflicts of WAN ports. ● When making a port mapping, make sure that the port you are mapping is not occupied or restricted. ● The TCP/UDP WAN and LAN ports must be consistent and cannot be modified.
Modification	Click  , and then you can modify the external port.

Step 3 Click **Save**.

Enter `http://WAN IP: WAN port number` in the browser to access the Device with the corresponding port number in the router network.

6.3.2.7 Multicast

When multiple users are viewing live video of the same device at the same time, it might cause failure due to limited bandwidth. To solve this problem, you can set a multicast IP address (224.0.0.0–239.255.255.255) for the Device.



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > Multicast**.

Figure 6-36 Multicast

Step 2 Click to enable multicast.

Step 3 Set parameters.

Table 6-15 Parameters


Parameters	Description
IP Address	Set the multicast IP address of the Device (224.0.1.0–239.255.255.255).
Port	Set the multicast port (1025–65000).

Step 4 Click **Save**.

After configuring the multicast address and port, you can log in to the web interface or PCAPP client through the multicast protocol.

Take PCAPP for example. On the login interface of PCAPP, select **Multicast** as the login type. The PCAPP client will automatically obtain the multicast address and join the multicast group. After login, you can view live videos through multicast protocol.

Figure 6-37 Log in through multicast



6.3.2.8 Alarm Center

You can configure the alarm center server to receive the uploaded alarm information.



Make sure that alarm center server is deployed.



Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > Alarm Center**.

Figure 6-38 Alarm center

Step 2 Click to enable alarm center.

Step 3 Configure the parameters.



Table 6-16 Alarm center parameters

Parameter	Description
IP Type	Select the IP type of the alarm center server.
Server Address	The IP address and communication port of the alarm center server.
Port	
Auto Report Plan	Select time cycle and specific time for uploading alarm.

Step 4 Click **Save**.

6.3.2.9 Route Table

Configure the route table so that the system can automatically calculates the best path for data transmission.

Step 1 Click , or click  on the configuration page, and then select **NETWORK > Network Apps > Route Table**.

Step 2 Click **Add**.

Figure 6-39 Add route table

Add
✕

NIC Ethernet Network1

No. 1

IP Section . . .

Subnet Mask . . .

Gateway . . .

OK
Cancel

Step 3 Enter the information.

Step 4 Click **OK**.

6.4 Event Management

Click or click on the configuration page, select **EVENT**.

On the page, configure alarm event, including alarm event of EVS and remote device.

- Select the root node in the resource tree on the left to set alarm event of the Device. See "6.4.2 Local Device" for detailed information.
- Select remote device in the device tree on the left, to set alarm event of this remote device. See "6.4.3 Remote Device" for detailed information.



- The alarm event might be different depending on the model you purchased.
- means that the corresponding alarm event has been enabled.
- means that AI by Camera has been enabled.

Figure 6-40 Event management

DEVICE INFO		Face	Video Metadata	Irs	Vehicle	Crowd Dis...	Call Detec...	Smoking D...	People Co...
Channel No.	State	Channel Name	Address/Regist ID						
1		27	10.172.160.135						
2		Channel2	10.172.162.51						
3		IPC	10.172.19.189						

6.4.1 Alarm Actions

System can trigger the corresponding actions when an alarm occurs.



The supported actions might be different depending on the model you purchased.

On the alarm configuration page, click **Actions** to display actions. See Table 6-17 for detailed information. Configure actions according to your actual need.


- After setting actions, click **Save** on the page.
- After enabling actions, click  to disable the corresponding actions.

Table 6-17 Actions description

Actions	Description	Preparation
Record	The system links the selected remote device to record when there is a corresponding alarm event.	Remote device, such as IPC, has been added. See "3.4.2 Adding Remote Device" for detailed information.
Buzzer	The system activates a buzzer alarm when there is a corresponding alarm event.	—
Log	The system notes down the alarm information in the log when there is a corresponding alarm event.	—
Email	The system sends alarm email to all added receivers when there is corresponding an alarm event.	Email configuration has been completed. See "6.3.2.3 Email" for detailed information.
Snapshot	The system takes snapshots of the linked channel when there is corresponding alarm event.	—
Preset	The system links the selected remote device to rotate to the designated preset point when there is a corresponding alarm event.	PTZ device has been added, and preset point has been added. See "3.4.2 Adding Remote Device" for detailed information.
Remote Device Alarm Output Settings	When there is an alarm, system can trigger the corresponding device to generate alarm.	IPC has been added, and IPC is connected with alarm output device. See "3.4.2 Adding Remote Device" for detailed information.
Access	When there is an alarm, system can trigger the corresponding access control device to open door and close door.	See "3.4.2 Adding Remote Device" for detailed information.
Smart Tracking	Alarm is triggered when a tripwire or intrusion behavior is detected. If smart tracking action is configured, the PTZ camera automatically rotates to the target view to track it.	See "6.4.1.10 Smart Tracking".
Report Alarm	When an alarm occurs, the system reports the alarm to alarm center.	Alarm center has been enabled. For details, see "6.3.2.8 Alarm Center".

Actions	Description	Preparation
Audio and Light Alarm	When an alarm occurs, the system associates with the remote device to perform audio and light actions.	The camera that supports this function has been connected. For details, see "6.4.1.12 Audio and Light Alarm".

6.4.1.1 Record


Enable record control function. The system links the selected remote device to record when there is corresponding alarm event.



Make sure that the remote device, such as IPC, has been added. See "3.4.2 Adding Remote Device" for detailed information.

Step 1 Click **Actions**, and then select **Record**.

Figure 6-41 Record



Step 2 Set the time length of recording after the event moment.

Step 3 (Optional) Repeat Step 1–Step 2 to link multiple remote devices to record.

6.4.1.2 Buzzer

The system activates a buzzer alarm when there is corresponding alarm event.

Click **Actions** and select **Buzzer** to enable this function.

Figure 6-42 Buzzer



6.4.1.3 Log

Enable the log function. The system notes down the alarm information in the log when there is corresponding alarm event.

Click **Actions** and select **Log** to enable this function.

Figure 6-43 Log





When log function is enabled, after an alarm is triggered, click **+** on **LIVE** page, select

MAINTAIN > Log > Event.

6.4.1.4 Email

Enable email function. The system sends alarm email to all added receivers when there is corresponding alarm event.



Make sure that the Email configuration has been completed. See "6.3.2.3 Email" for detailed information.

Click **Actions** and select **Email** to enable this function.

Figure 6-44 Email



6.4.1.5 Preset

Set preset function. The system links the selected remote device to rotate to the designated preset point when there is corresponding alarm event.



Make sure that the PTZ device has been added, and preset has been added. See "3.4.2 Adding Remote Device" for detailed information.

Step 1 Click **Actions** and select **Preset**.

Figure 6-45 Preset



Step 2 Select PTZ device, and enter preset number.

Step 3 (Optional) Repeat Step 1–Step 2, and link multiple PTZ devices to turn to designated presets.

6.4.1.6 Snapshot

Set the snapshot linkage action for alarms, so that once an alarm happens, it will trigger a snapshot of the alarm.

Click **Actions**, and then select **Snapshot**.

Figure 6-46 Snapshot action

6.4.1.7 Remote Device Alarm Out

Set remote device alarm output. System can trigger the corresponding alarm output device when an alarm occurs.



Make sure that the remote device has been added, and the remote device is connected with alarm output device. See "3.4.2 Adding Remote Device" for detailed information.

Step 1 Click **Actions** and select IPC Alarm Out.

Figure 6-47 Remote device alarm output settings

Step 2 Select a remote device and alarm output port.

You can select multiple alarm output ports.

Step 3 (Optional) Repeat Step 1–Step 2, and link multiple remote alarm output devices.

6.4.1.8 Access

Set access control function. When there is an alarm, system can trigger the corresponding access control device to open door and close door.



Make sure that access control device has been added. See "3.4.2 Adding Remote Device" for detailed information.

Step 1 Click **Actions** and select **Access**.

Figure 6-48 Access

Step 2 Select access control device.



Not all models support this function.

Step 3 (Optional) Repeat Step 1–Step 2, and link multiple access control devices.

6.4.1.9 Voice Prompt

Set voice prompt function. When there is an alarm, system can play the selected audio file.

Step 1 Click **Actions** and select **Voice Prompt**.

Figure 6-49 Voice prompt



Step 2 In the **File Name** list, select the audio file that you want to play for this configured period.

Step 3 Set delay time.

- Play times: Select **Play Times** and enter the times to play the file. After the alarm event is ended, system will continue to play the voice file according to the play times.
- Duration: Select **Duration** and enter the delayed play duration. After the alarm event is ended, system will continue to play the voice file according to the duration.

6.4.1.10 Smart Tracking

Alarm is triggered when a tripwire or intrusion behavior is detected. If smart tracking action is configured, the PTZ camera automatically rotates to the target view to track it.



- Smart tracking is only available for AI by Camera.
- Smart tracking is only available on the multi-sensor panoramic camera + PTZ camera.

On the event configuration page, select **Actions > Smart Tracking** to enable the action.

6.4.1.11 Report Alarm

Click **Actions** and then select **Report Alarm** to enable this function. Where there is an alarm, the system reports the alarm to alarm center.



Make sure that alarm center has been enabled. For details, see "6.3.2.8 Alarm Center".

6.4.1.12 Audio and Light Alarm

Set audio and light alarm for IVS detection. When there is an alarm, the system associates with the remote device to perform audio and light actions.



Audio and light alarm is available when AI by camera is used for IVS detection and the camera supports this function.

Step 1 Click **Actions** and select **Camera Audio** and **Remote Warning Light**.

Figure 6-50 Camera audio

Figure 6-51 Remote warning light

Step 2 Configure the parameters.

Table 6-18 Audio and light alarm parameters

Parameter		Description
Camera Audio	File Name	Select the audio file to be played when an alarm is triggered.
	Play Mode	Set the play times of audio file.
Remote Warning Light	Mode	Select Flicker or Always on .
	Flicker Frequency	When Flicker is selected as Mode , set the flicker frequency.
	Duration	Set how long the warning light flickers or keeps on after an alarm is triggered.

6.4.2 Local Device

Set EVS alarm event, including abnormal event, device offline alarm, AI plan, and local device alarm.

6.4.2.1 One-click Disarming


Disarm alarm linkage actions as needed to avoid interference caused by alarms.

Step 1 Click or click on the configuration page, and then select **EVENT**.

Step 2 Select the root node in the device tree.

Step 3 Select **Overview > Disarming**.

Figure 6-52 Disarming



Step 4 Click to enable disarming.

Step 5 Cancel selecting alarm linkage actions as needed. The actions are selected by default.

Step 6 (Optional) Configure disarming by period.

- 1) Click to enable disarming by period.
- 2) Click **Add Schedule** to specify disarming schedule. The alarm linkage actions remain armed during unscheduled periods.
- 3) Click **Apply**.



After disarming by period is enabled, one-click disarming is disabled automatically.

Step 7 Configure sync disarming configuration with channels.

- 1) Click the drop-down list in the **Sync Disarm Config with Channels** section. The devices that support one-click disarming or disarming by period are displayed.
- 2) Select the device that you want to synchronize the disarming configuration with.

Step 8 Click **Save**.



6.4.2.2 Abnormal Event

Set the alarm mode when an abnormal event occurs.

The Device supports HDD, storage error, network, fan and power fault alarm.

Table 6-19 Abnormal event description

Name	Description
No HDD	System triggers an alarm when there is no HDD. It is enabled by default.
Disk health exception	System triggers an alarm when HDD malfunctions. It is enabled by default.

Name	Description
Storage error	System triggers an alarm in case of HDD error, RAID degrade, RAID broken, and storage pool error. It is enabled by default.
Storage full	System triggers an alarm when the used storage space reaches the pre-defined threshold. It is disabled by default.  The alarm is valid only when the storage mode is set as Stop on the Local Hard Disk page.
Storage pool error	System triggers an alarm when an error occurs in the storage pool.
RAID exception	System triggers an alarm in case of RAID exception. It is disabled by default.
Low quota space	System triggers an alarm when the quota space is insufficient, It is enabled by default.
Video frame loss	System triggers an alarm when the frame loss occurs in the recorded video. It is enabled by default.
IP conflict	System triggers an alarm when its IP address conflicts with IP address of other device in the same LAN. It is enabled by default.
MAC conflict	System triggers an alarm when its MAC address conflicts with MAC address of other device in the same LAN. It is enabled by default.
Lock in	System triggers an alarm when an account login error has reached the threshold. At the same time, system locks current account. It is disabled by default.  Go to the Security page to set account error threshold. See "6.7.3 Safety Protection" for detailed information.
Security exception	System triggers an alarm when a security exception occurs. It is enabled by default.
Fan speed alarm	When EVS fan speed is abnormal, system triggers an alarm. It is enabled by default.
Power fault	System triggers an alarm when EVS power supply is abnormal. It is disabled by default.
Share service	System triggers an alarm when share service is abnormal. It is enabled by default.
Temperature	System triggers an alarm when the temperature of the Device lower than 0 °C or higher than 95 °C. It is enabled by default.
SSD health exception	System triggers an alarm when an error occurs on the SSD.


Here we use no HDD for example. For other events, the setting steps are similar. See the actual page for detailed information.


Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select the root node in the device tree.

Step 3 Select **Abnormal Event > No HDD**.

Figure 6-53 No HDD





Step 4 Click  to enable no HDD alarm function.

Step 5 Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.

Step 6 Click **Save**.

6.4.2.3 Offline Alarm


Set EVS network offline alarm. If you have not set offline alarm for a specified remote device, once the remote device is disconnected from the system, system adopts EVS alarm strategy to trigger an alarm.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select the root node in the device tree on the left.

Step 3 Select **Device Offline > Device Offline**.

Figure 6-54 Offline alarm



Step 4 Click  to enable device offline alarm.

Step 5 Click **Deployment Time** to select schedule from the drop-down list.

After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.

Step 6 Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.

Step 7 Click **Save**.

6.4.2.4 Configuring AI Plan

Configure AI detection result display strategy of EVS. If you have not set AI display settings for current remote device, the remote device inherits AI display mode of EVS.

6.4.2.4.1 Viewing AI Plan

After adding remote device, on EVS, obtain AI detection type and status of the remote device.

On the **EVENT** page, select the root node in the device tree on the left. Select **AI Plan > AI Plan**. The **AI Plan** page is displayed. See Figure 6-55.

After installing the AI module, and the remote device supports AI detection, and you have enabled the AI detection function, you can view channel name of the remote device on the corresponding AI detection panel.





 indicates that AI by Camera is enabled.

Figure 6-55 AI plan





6.4.2.4.2 Setting AI Display

Set the property that shall be displayed in rule box and feature property panel. View AI detection result through smart preview, and support to display face, human and vehicle.




Take the procedure of configuring face detection AI display as an example. For other AI detection functions, the procedures are similar.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select the root node in the device tree on the left.

Step 3 Select **AI Plan > AI Display > Face**.


Figure 6-56 Face



Step 4 Configure display filter information.

After setting filter criteria, only the qualified detection result will be displayed. For example, enable Age, and then select youth from the drop-down list. The tracking box and the features panel only display the human face of the youth age.


- 1) Click to enable corresponding filter type.
- 2) Set display filter criteria.

Click  to set the filter color.

Step 5 Click in the right of **Show Tracking Box** to enable.

After enabled, when the system detects face or human, tracking box will be shown beside the face or human in the view window.

Figure 6-57 Tracking box



Step 6 Click in the right of **Features Panel** to enable, and select the features that shall be displayed on the **LIVE** page.

After enabled, there is a features panel on the right side of the view window. See Figure 6-58.



- Drag  to adjust features panel transparency. The higher the value, the more transparent the features panel.
- System supports maximum 4 features. System has checked four features by default. To select other features, cancel the selected features, and then select the ones you need.
- Click to display the features panel on the **LIVE** page, including face detection panel and face DB panel.

Figure 6-58 Features panel



Step 7 Click **Save**.

6.4.3 Remote Device

Set alarm actions of remote device, including video detection alarm, offline alarm and AI plan of remote device.



The parameters might be different depending on the model you purchased.

6.4.3.1 Video Detect

Video detection function adopts the PC visual, image and graphical processing technology to analyze the video image and check there is considerable changes on the video. Once there are considerable video changes (such as there is any moving object, or the video is blurred), system triggers corresponding alarm event.

6.4.3.1.1 Configuring Video Motion


After analyzing video, system can generate a video motion alarm when the detected moving target reaches the sensitivity you set here.


Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select remote device in the device tree on the left.

Step 3 Select **Video Detect > Video Motion**.


Figure 6-59 Video motion



Step 4 Click  to enable video motion detection.

Step 5 Set parameters.

Table 6-20 Motion detect parameters description

Parameters	Description
Debouncing	System only records one alarm event during the debouncing period.
Exclude PTZ control	After enabling exclude PTZ control, system does not trigger an alarm when you are manually control the PTZ.  It is for PTZ camera only.

Step 6 Set motion detection region.

System supports maximum four detection zones. After setting, once there is an alarm from any of these four zones, the remote device triggers an alarm.






- 1) Click motion detection zone icon .
- 2) On the surveillance video, press and hold on the left button of mouse to select detection zone.
 - Select the motion detect zone you have drawn. Click  to delete the zone.
 - Click  to clear the zone you have drawn.
- 3) Set parameters.

Table 6-21 Description of zone parameters

Parameters	Description
Name	Set detection zone name to distinguish different zones.

Parameters	Description
Sensitivity	Drag  to set sensitivity. The higher the sensitivity is, the easier it is to trigger an alarm. At the same time, the false alarm rate increases as well. Usually we recommend the default value.
Threshold	Drag  to adjust threshold. Once the detected percentage (the percentage of target to detection zone) is equivalent to or larger than the specified threshold, system triggers alarm. For example, the threshold is 10. Once the detected target occupies the 10% of the detection zone, system triggers an alarm.

Step 7 Click **Deployment Time** to select schedule from the drop-down list.

After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.



- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.

Step 8 Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.

Step 9 Click **Save**.

6.4.3.1.2 Tampering


Once something tampers the surveillance video, and the output video is in one color, the system can generate an alarm.


Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select remote device in the device tree on the left.

Step 3 Select **Video Detect > Tampering**.

Figure 6-60 Tampering



- Step 4** Click  to enable tampering alarm.
- Step 5** Click **Deployment Time** to select schedule from the drop-down list.
After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.
- Click **View Schedule** to view detailed schedule settings.
 - If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.
- Step 6** Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.
- Step 7** Click **Save**.

6.4.3.2 Offline Alarm

When the remote device and the EVS are disconnected, system can trigger an alarm.






- Step 1** Click , or click  on the configuration page, and then select **EVENT**.
- Step 2** Select a remote device in the device tree on the left.
- Step 3** Select **Device Offline > Device Offline**.



Figure 6-61 IPC offline



- Step 4** Click  to enable offline alarm.
- 
- The device offline alarm is enabled by default. You can skip this step.
- Step 5** Click **Deployment Time** to select schedule from the drop-down list.
After setting deployment period, system triggers corresponding operations when there is a device offline alarm in the specified period.
- Click **View Schedule** to view detailed schedule settings.
 - If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.
- Step 6** Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.
- Step 7** Click **Save**.

6.4.3.3 IPC External Alarm

Set IPC alarm input event, so that when there is an alarm input to the IPC, IPC uploads the alarm to the Device. If the camera has multiple IO channels, you can set the alarm input event for each of them as you might need.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select a remote device in the device tree on the left.

Step 3 Select **External Alarm > IO1**.

The **IO1** page is displayed. See Figure 6-62.

Figure 6-62 IO1

Step 4 Click  to enable the alarm.

Step 5 Set parameters.

Table 6-22 Local alarm parameters description

Parameters	Description
Name	In the Alarm name box, enter a name for the alarm.
Type	Select alarm input device type. Both NO and NC are supported.
Debouncing	The system records only one event during this period.

Step 6 Click **Deployment Time** to select schedule from the drop-down list.

After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.

Step 7 Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.

Step 8 Click **Save**.

6.4.3.4 Thermal Alarm




- Alarm types vary depending on the models of thermal cameras.
- Make sure that configurations of thermal detections such as fire detection and temperature detection have been done on the thermal camera.

Supports the following thermal camera alarms.

Table 6-23 Thermal alarms

Function	Description
Fire alarm	When the thermal camera detects a fire, the alarm signal is transmitted to the EVS device, which performs an alarm linkage action.
Temperature alarm	When the thermal camera detects that the temperature is above or below the threshold value, the alarm signal is transmitted to the EVS device, which performs an alarm linkage action.
Temperature difference alarm	When the thermal camera detects a temperature difference greater than the set value, the alarm signal is transmitted to the EVS device, and the EVS device will perform an alarm linkage action.
Hot spot alarm	When the maximum temperature detected by the thermal camera is higher than the set value, the alarm signal is transmitted to the EVS device, and the EVS device will perform an alarm linkage action.
Cold spot alarm	When the lowest temperature detected by the thermal camera is below the set value, the alarm signal is transmitted to the EVS device, and the EVS device will perform an alarm linkage action.

This section uses the procedure of configuring fire alarm as an example. The procedures are similar.

Step 1 Click , or click  on the configuration page, and then select **EVENT**.

Step 2 Select the root node in the device tree on the left.

Step 3 Select **Thermal Alarm > Fire Alarm**.

Step 4 Click **Deployment Time** to select schedule from the drop-down list.



After setting deployment period, system triggers corresponding operations when there is a motion detection alarm in the specified period.

- Click **View Schedule** to view detailed schedule settings.
- If the schedule is not added or the added schedule does not meet actual needs, click **Add Schedule**. See "6.9.3 Schedule" for detailed information.

Step 5 Click **Actions** to set alarm actions. See "6.4.1 Alarm Actions" for detailed information.

Step 6 Click **Save**.

6.5 Storage Management

Click  or click  on the configuration page, select **STORAGE**. Manage storage resources (such as recording file) and space, so you can use and improve utilization ratio of storage space.








The system supports pre-check and routine inspection function, displays health status on the Storage page, so you obtain real-time status of device and avoid data loss.

- Pre-check: During device operation, the system automatically detects disk status in case of change (start, and insert the disk).
- Routine inspection: The system carries out routine inspection of the disk continuously. During device operation, the disk might go wrong due to service life, environment and other factors.

6.5.1 Local Hard Disk

The local hard disk refers to the HDD installed on the system. On this page, you can view HDD space (free space/total space), temperature (centigrade/Fahrenheit), HDD information and so on.


Click  or click  on the configuration page, and then select **STORAGE > Storage Resource > Local Hard Disk**. There is a corresponding icon near the HDD name after you create the RAID and hot spare HDD.

- : RAID HDD.
- : Global hot spare HDD.
- : Invalid HDD of RAID group.



Slight difference might be found on the user interface.

Figure 8-65 HDD



6.5.1.1 Viewing S.M.A.R.T

S.M.A.R.T is Self-Monitoring Analysis and Reporting Technology. It is a technical standard to check HDD drive status and report potential problems. System monitors the HDD running status and compares with the specified safety value. Once the monitor status is higher than the specified value, system displays alarm information to guarantee HDD data security.



Check one HDD to view S.M.A.R.T information at one time.

On the **Local Hard Disk** page, select a HDD, and then click **S.M.A.R.T**. The **S.M.A.R.T** page is displayed. Check whether the HDD status is **OK** or not. If there is any problem, fix it in time.

Figure 8-66 S.M.A.R.T

Sn	Note	Value	Worst	Boundary	Original Data	State
1	Read Error Rate	117	99	6	135185072	Better
3	Spin Up Time	97	97	0	0	Better
4	Start/Stop Co...	100	100	20	780	Better
5	Reallocated S...	100	100	36	0	Better
7	Seek Error Rate	67	60	30	17203264542	Better
9	Power On Ho...	98	98	0	2426	Better
10	Spin-up Retry...	100	100	97	0	Better
12	Power On/Of...	100	100	20	752	Better
184	End-to-End F...	100	100	99	0	Better

6.5.1.2 Format



- Formatting HDD will clear all data on the HDD. Be careful!
- Hot spare HDD cannot be formatted.

To format the selected HDDs, enter the **Local Hard Disk** page, select one or more HDD(s), and click **Format**.

6.5.1.3 File System Repair


Once you cannot mount the HDD or you cannot properly use the HDD, you can try to use the **File System Repair** function to fix the problem.

Enter the **Local Hard Disk** page, select one or more HDD(s) you cannot mount, and click **File System Repair**, you can repair the selected file system of the corresponding HDD(s). The repaired HDD can work properly or to be mounted.

6.5.1.4 Viewing RAID Group

Click or click on the configuration page, and then select **STORAGE > Storage Resource > Local Hard Disk > RAID Group**. You can view free space, RAID type, working mode and status of RAID group.

Figure 8-68 RAID group



- Click next to the RAID name to display the RAID member list, and then you can view RAID member details.
- Point to the **Status** column, and then click to display the **Details** page and view RAID group details.

6.5.2 RAID

RAID (Redundant Array of Independent Disks) is a data storage virtualization technology that combines multiple physical HDD components into a single logical unit for the purposes of data redundancy, performance improvement, or both.



- The Device supports RAID0, RAID1, RAID5, RAID6, RAID10, RAID50 and RAID60. See "Appendix 2 RAID" for detailed information.
- You are recommended to use enterprise HDD when you are creating RAID, and use surveillance HDD for single-HDD mode.

6.5.2.1 Creating RAID

RAID has different levels such as RAID5, and RAID6. Different RAID levels have different data protection, data availability and performance levels. Create RAID according to your actual requirements.



Creating RAID operation will clear all data on these HDD. Be careful!





Step 1 Click , or click  on the configuration page, and then select **STORAGE > Storage Resource > RAID > RAID**.

Figure 8-69 RAID (1)



Step 2 Click **Add**.

Figure 8-70 Create RAID (1)




Step 3 Set RAID parameters.

Select RAID creation type according to actual situation. It includes **Manual RAID** and **Auto RAID**.

Manual RAID: System creates a specified RAID type according to the selected HDD amount.

- 1) Select **Manual RAID**.
- 2) Select HDD you want to use.
- 3) Set parameters.

Table 8-24 Manual creation parameters description

Parameters	Description
Storage Device	Select storage device of the HDD and select the HDD you want to add to the RAID.  Different RAID types need different HDD amounts.
RAID	Select a RAID type you want to create.
Working Mode	Set RAID resources allocation mode. The default setup is self-adaptive. <ul style="list-style-type: none"> Self-adaptive means the system can automatically adjust RAID synchronization speed according to current business load. When there is no external business, the synchronization speed is at high speed. When there is external business, the synchronization speed is at low speed. Sync first: Allocate resources to RAID synchronization first. Business first: Allocate resources to business first. Load-Balance: Allocate resources to business and RAID synchronization equally.
Name	Set RAID name.

Auto: System creates RAID5 according to the HDD amount.

1) Select **Auto**.

Figure 8-71 Create RAID (2)

Estimated Space: 0

2) Set parameters.

Table 8-25 Auto parameters description

Parameters	Description
Storage Device	Select storage device of the HDD.
Working mode	<p>Set RAID resources allocation mode. The default setup is self-adaptive.</p> <ul style="list-style-type: none"> Self-adaptive means the system can automatically adjust RAID synchronization speed according to current business load. When there is no external business, the synchronization speed is at high speed. When there is external business, the synchronization speed is at low speed. Sync first: Allocate resources to RAID synchronization first. Business first: Allocate resources to business first. Load-Balance: Allocate resources to business and RAID synchronization equally.

Step 4 Click **Next**.

Step 5 Confirm the information.



If the input information is wrong, click **Back** to set RAID parameters again.

Step 6 Click **Create**.

System begins to create RAID. It displays RAID information after creation.

Figure 8-74 RAID (2)

Name	Space	RAID Type	Working Mode	State
RAID_1	-/931.52GB	RAID5	Self Adaptive	Active Degraded Recovering

Related Operations

After creating RAID, view RAID disk status and details, clear up RAID, and repair file system.

Table 8-26 RAID operation

Name	Operation
View RAID HDD status	View RAID HDD space and status.
View RAID details	Click to view RAID detailed information.



Name	Operation
File System Repair	<p>Once you cannot mount the RAID or you cannot properly use the RAID, you can try to use repair file system function to fix.</p> <p>Enter RAID page, select one or more RAID(s) you cannot mount, click File System Repair, you can repair the selected file system of the corresponding RAID(s). The repaired RAID can work properly or to be mounted.</p>
Modify Working Mode	<p>Select one or more RAID(s), and then click Working Mode to modify the working mode.</p>
Format RAID	<p>Enter RAID page, select one and more RAID groups. Click Format to format the selected RAID.</p> <p></p> <p>Formatting RAID is to clear all data on the RAID and cancel the RAID group. Please be careful.</p>
Delete RAID	<p>Enter RAID page, select one and more RAID groups. Click Delete to delete the selected RAID.</p> <p></p> <p>Deleting RAID is to clear all data on the RAID and cancel the RAID group. Please be careful.</p>

Figure 8-75 RAID details

Details
×

Name	RAID0_1
Drive Letter	/dev/md0
RAID Group	Host:HDD3,HDD7
RAID Type	RAID0
Space	<u>10.91TB/10.91TB</u>
Working Mode	--
State	Active

Sync Speed	0.00%
Speed	0.00MBps
Remaining Time	0.00Min

Close

6.5.2.2 Creating Hot Spare HDD

When an HDD of the RAID group is malfunctioning, the hot spare HDD can replace the malfunctioning HDD.



Step 1 Click , or click  on the configuration page, and then select **STORAGE > RAID > Hot spare**.

Figure 8-76 Hot spare (1)



Step 2 Click **Add**.

Figure 8-77 Global hot spare





Figure 8-78 Private hot spare




Step 3 Select hot spare creation type.

- Global hot spare: Create hot spare for all RAID.
- Private hot spare: Select **Private Hot spare** and **Add** it to a RAID group. The private hot spare HDD is for a specified RAID group.

Step 4 Select one or more HDD(s) and then click **Next**.

Figure 8-79 Confirm info



Step 5 Confirm info.




Click **Back** to select hot spare HDD(s) again if you want to change settings.

Step 6 Click **Create** to save settings.

System displays the added hot spare HDD information.

Figure 8-80 Hot spare (2)



Select a hot spare HDD and then click **Delete**, it is to delete hot spare HDD.

6.5.3 Network Hard Disk

Network hard disk is a network-based online storage service that stores device information in the network hard disk through the iSCSI protocol.

6.5.3.1 iSCSI Application

View network hard disk usage, including remaining capacity, and hard disk status.




Click , or click  on the configuration page, and then select **STORAGE > Storage Resource > Network Hard Disk > iSCSI Application**.

Figure 6-63 iSCSI application



- Select a network hard disk, and then click **Format** to format the disk. Formatting your hard disk will erase all data from your hard disk, so do it carefully.
- Click the **HDD Operation** column, and then you can select an HDD operation permission type.
 - ◇ Read/Write: Read, edit, add, and delete data of this disk.
 - ◇ Read Only: One can only read data of this disk.

6.5.3.2 iSCSI Management

Set up the network disk through iSCSI and map the network disk to the Device so that the Device can use the network disk for storage.



- iSCSI is a networked storage technology that runs SCSI protocols on the IP network.
- The network disk mapped to the Device cannot be used to create a RAID.
- Make sure that service has been enabled on the iSCSI server and the server has provided the shared file directory.




Step 1 Click , or click  on the configuration page, and then select **STORAGE > Network Hard Disk > iSCSI Management**.

Figure 6-64 Network hard disk



Step 2 Click  .

Figure 6-65 Add iSCSI

Step 3 Set parameters.

Table 6-24 Network hard disk parameters

Parameters	Description
Server IP	Enter iSCSI server IP address.
Port	Enter iSCSI server port number. It is 3260 by default.
Anonymous	If iSCSI server has no permission limitation, you can select anonymous login.
Username	If access permission has been limited when creating the shared file directory on the iSCSI server, you need to enter username and password.
Password	
Storage Directory	Click Search Directory to select the storage directory. The storage directory is generated when the shared file directory is being created on the iSCSI server. Each directory is an iSCSI disk.

Step 4 Click **OK**.

The added network disk is displayed.



- Click to delete a disk; click **Refresh** to refresh the disk list.
- On the **Disk Group** page, you can configure network disk groups.

6.5.4 FTP/SFTP

Configure FTP/SFTP server for video and picture storage. This section uses configuring SFTP as an example.



- FTP is unencrypted transmission, while SFTP is encrypted transmission. You are recommended to use SFTP.
- When creating SFTP user, you need to configure write permission of SFTP folder. Otherwise, you cannot upload files.
- You need to purchase or download SFTP tool and install it on your PC.




Step 1 Click , or click  on the configuration page, and then select **STORAGE > SFTP**.

Figure 6-66 SFTP

Step 2 Click to enable SFTP.

Step 3 Set parameters.

Table 6-25 SFTP parameters

Parameters	Description
Server IP	SFTP server IP address.
Port	It is 22 by default.
User Name	The username and password of the SFTP server.
Password	 You can keep the username as anonymous , so as to log in in an anonymous way.

Parameters	Description
Remote Directory	Enter the SFTP directory. <ul style="list-style-type: none"> The system automatically establishes folders according to the IP, time, and channel information if you leave the directory empty. Enter the directory name, and then the system creates a folder accordingly under the root directory of SFTP and generates different folders according to the IP, time, and channel information.
File Size	Set the size of the file to be uploaded. <ul style="list-style-type: none"> If the to-be-uploaded file is larger than the threshold, the system uploads only part of it (the same size with the threshold). If the to-be-uploaded file is smaller than the threshold, the system uploads the whole of it. If the threshold you have set is 0, the system uploads the whole of the file.
Image Upload Interval	Set the upload interval of images.
Channel	Set the channel number of the video file.
Weekday	Select the day, the time period, and file type (event file or regular file). The system uploads files in the time periods as you have set.
Period	
Test	Click Test to test the SFTP connection.

Step 4 Click **Save**.

6.6 Video Recording

6.6.1 Storage Mode

Allocate disks or RAID groups to different disk groups, and store video and image to specified disk group.





6.6.1.1 Setting Disk Group

Disk and created RAID group are allocated to group 1 by default. You can allocate disk and RAID group to other groups according to your actual needs.

The default number of disk group is the same as the maximum number of HDD that EVS supports.


Step 1 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode > Disk Group**.



- The value (such as ) next to the group name refers to the number of HDD and RAID group in the disk group. If instead,  is displayed, it means no available HDD or RAID group in the disk group, but there is video or image stored in the disk group.
-  indicates picture storage.  indicates video storage.

Step 2 Click a disk group.

Figure 8-84 Disk group



Step 3 Select HDD or RAID group from **Disks**, and then drag the HDD or the RAID group to another disk group.

Disk grouping takes effect immediately.



Select **All** to select all the HDDs and RAID groups of the disk group.

After configuring disk groups, you can also view which disk group the selected disk, video or picture belongs to.

Table 8-28 Disk group functions

Function	Description
View the disk group of a disk, video or picture	Click Disk No. <input type="text" value="Please select disk"/> , select a disk or RAID group, and then click Query to search for the disk group that the selected disk or RAID group belongs to.
View disk groups of video or image	Select Video or Image from Type <input type="text" value="Type"/> , and then click Query to search for disk groups of the selected type.

6.6.1.2 Setting Video/Image Storage

Videos/images of all channels are stored in disk group 1 by default. You can store the videos/images in different disk groups according to actual needs. Two methods are available to set video/image storage.



This section uses storing video for example. To store images, the procedure is similar.

6.6.1.2.1 Method 1: Selecting Disk Group




Step 1 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode > Video**.

Figure 8-85 Video



Step 2 Select filtering way from the **Batch Process** drop-down list.

- By Channel Name: Select channel according to the channel name.
- By Logical Channel No.: Select channel that is connected to EVS. In this case, **Start Channel No.** and **End Channel No.** need to be configured.

Step 3 In the **Select Disk Group** drop-down list, select target disk group.





In the drop-down list, only disk group with available HDD or RAID group is displayed.

Step 4 Click **OK**.

Disk grouping takes effect immediately.

6.6.1.2.2 Method 2: Dragging Channel

Step 1 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode > Video**.


Step 2 Click a disk group.

The linked channels of the disk group are displayed in **Device List**.



- Only disk group with available HDD or RAID group or linked channel is displayed.
- The value (such as **1**) next to the group name refers to the number of HDD and RAID group in the disk group. If instead, **!** is displayed, it means no available HDD or RAID group in the disk group, but there is video or image stored in the disk group.

Figure 8-86 Device list



Step 3 (Optional) Click to enable load balance, and then the icon turns into blue. To disable it, click it again, and then the icon turns into gray.

- After load balance is enabled, if one disk group has no usable disk, the video of all channels that belong to this disk group will be stored into all the usable disk groups.
- When load balance is not enabled, if one disk group has no usable disk, the video of all channels that belong to this disk group will be stored in another usable disk group.

Step 4 Select a channel from the Device list, and drag the channel to the target disk group. Disk grouping takes effect immediately.

6.6.1.3 Enabling Quota Mode


Enable quota mode to set the storage quota for each device.

Step 1 Click , or click on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode > Disk Group**.

Step 2 Click to enable quota mode.

Step 3 On the **Video** tab, click in the Device list to set the video quota for a device. Set the storage capacity and reference bit rate, and then the system calculates record duration.

Figure 6-67 Edit video quota



Storage Capacity GB

Reference Bit Rate Kbps

Record Duration days

OK Cancel



Step 4 On the **Image** tab, click  in the Device list to set the quota for a device. Set the storage capacity and reference bit rate, and then the system calculates the number of images that can be stored.

Figure 6-68 Edit image quota



Storage Capacity GB

Pic Size KB

Number of Images Image(s)

OK Cancel

Step 5 On the **Quota** tab, you can view the total and used quota of each device.

Figure 6-69 Quota information

Device List(512)								Export
<input type="checkbox"/>	Channel No	Camera Name	IP Address	Image Quota (GB)	Used Capacity Of Picture (GB)	Video Quota (GB)	Used Capacity Of Recorded Video (GB)	
<input type="checkbox"/>	1	3		20	0	1	0	
<input type="checkbox"/>	2	IPC		0	0	0	0	
<input type="checkbox"/>	3	218		0	0	0	18.13	
<input type="checkbox"/>	4	camera4		0	0	0	0	
<input type="checkbox"/>	5	1		0	0	0	0	
<input type="checkbox"/>	6	camera6		0	0	0	0	
<input type="checkbox"/>	7	camera7		0	0	0	0	
<input type="checkbox"/>	8	camera8		0	0	0	0	
<input type="checkbox"/>	9	camera9		0	0	0	0	
<input type="checkbox"/>	10	camera10		0	0	0	0	
<input type="checkbox"/>	11	1		0	0	0	49.75	
<input type="checkbox"/>	12	14		0	0	0	34.58	
<input type="checkbox"/>	13	camera13		0	0	0	0	
<input type="checkbox"/>	14	camera14		0	0	0	0	
<input type="checkbox"/>	15	camera15		0	0	0	0	
<input type="checkbox"/>	16	camera16		0	0	0	0	
<input type="checkbox"/>	17	camera17		0	0	0	0	



Total 512 items Show up to 100

6.6.2 Recording Schedule


Configure recording modes and schedules for channels.

6.6.2.1 Recording Mode


Configure recording modes for channels.

Step 1 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Schedule**.

Step 2 Find the camera for which you want to configure a recording schedule, select the recording methods for the stream types.

-  means that the type is selected.
- **Substream1** and **Substream2** cannot be enabled at the same time.
- Auto: Records automatically according to the schedule.
- Manual: Records around the clock and does not respond to the recording schedule.
- Close: No recording and does not respond to the recording schedule.

Step 3 Select a recording method.

Step 4 (Optional) click  to disabled the recording schedule configuration of the selected channel

Step 5 Click **Save**.

Figure 8-87 Recording mode

DEVICE INFO		Record Mode									Time plan			
Channel No.	Channel Name	Main Stream			Substream1			Substream2			General	Record Events	Pre-Record (Second)	Setting
		Auto	Manual	Close	Auto	Manual	Close	Auto	Manual	Close				
1	27	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0	
2	Channel2	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0	
3	IPC	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0	

6.6.2.2 Recording Schedule

Configure video and picture recording schedules so the Device records and captures pictures as configured in the specified period.

Step 1 Click , or click on the configuration page, and then select **STORAGE > VIDEO RECORDING > Schedule**.

Step 2 Click , set a recording schedule, and then click **OK**.

Figure 8-88 Set a recording schedule

Setting

Channel No 1

General Default Schedule + Add Schedule

Record Events Pre-Record Second (0-30)

ANR Min (1-10080)

Record Stream Main Stream Substream1 Substream2

Instant Record Duration Min (1-30)



Manual Snap Image(s) (1-5) Interval Second

Event Snap Interval Second (1-3600)

Copy to

Table 6-26 Parameters of recording schedule

Parameter	Description
General	Select the checkbox and then click the drop-down list to select a schedule to enable the function. The Device records video according to the selected schedule. If the schedule is not added or the added schedule does not meet actual needs, click Add Schedule . See "6.9.3 Schedule" for detailed information.

Parameter	Description
Record Events	Enable Record Events and then set the pre-recording time. When an alarm triggers linkage recording, the Device records the video according to the pre-recording time. For example, if the pre-recording time is 10 seconds, the Device starts recording 10 seconds before the event occurs.
Pre-Record	
ANR	Automatic Network Replenishment. When ANR is enabled (by clicking ), the Device will download videos recorded by IPC and stored on camera SD card during network disconnection. Enter the time length of the video to be downloaded from IPC. The Device will download only the defined length of video even if the disconnection is longer.  To use this function, make sure that the SD card is installed and recording enabled on the camera.
Record Stream	Select stream types and recording modes.
Instant Record Duration	The duration of instant recording. After starting instant recording on the LIVE page, if you do not stop recording, it will automatically stop after the defined duration.
Manual Snap	The number of image captures.
Event Snap	The number of images for each manual capture action. Enter a value to specify the number of seconds between each image.
Copy to	Copy the current settings to other channels.

Step 3 Click **Save**.



6.6.3 Basic

Configure the storage mode when the disk space is used up and the automatic deletion of expired files.

6.6.3.1 Setting Storage Mode

Configure the storage mode when there is no more disk space available.

Step 1 Log in to PCAPP.

Step 2 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode**.

Step 3 Set storage mode when the HDD free space is less than the acceptable threshold.

The acceptable threshold for storage space is 4% of the total space within the range of 150 GB to 200 GB.

- **Overwrite:** When HDD free space is less than the acceptable threshold, the Device continues to record and the new videos overwrite the oldest files.



Data will be overwritten in the **Overwrite** mode. Back up in time.

- **Stop:** When HDD free space minus the acceptable threshold is less than the defined free space alarm rate of the total space, an alarm is triggered and the Device continues recording until the HDD free space is less than the acceptable threshold.



Figure 6-70 Storage mode

Step 4 Click **Save**.

6.6.3.2 Setting Automatic File Deletion

You can enable the Device to automatically delete files older than a certain number of days.

Step 1 Log in to PCAPP.

Step 2 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Storage Mode**.

Step 3 Set automatic file deletion.

- **Never:** The Device does not delete files automatically.
- **Customize:** The Device automatically deletes files older than the configured number of days.



The deleted files cannot be recovered.

Figure 6-71 Delete expired files



Step 4 Click **Save**.

6.6.4 Record Transfer

When the Device and an IPC are disconnected, the IPC continues to record and stores the recording in the SD card. After the network is recovered, the Device will download the recording during the disconnection from the IPC.

Two ways for record transfer after the network recovers.

- Automatic download: After the network recovers, the Device automatically downloads the recording in the set time period.
- Manual download: If ANR is not enabled when you set the recording schedule, after the network recovers, the Device can not automatically download the recording during the disconnection, but the user can manually create the download task.

Step 1 Click , or click  on the configuration page, and then select **STORAGE > VIDEO RECORDING > Record Transfer**.

Step 2 Click **Add**.

Figure 8-90 Add

Step 3 Select **By Channel Name** or **By Channel No.** in the **Batch Process** drop-down list.

Step 4 Set time period of the video to be searched.

Step 5 Click **OK**.

The transfer progress is displayed.



Select a transfer task, click **Delete** to delete it. A task in progress cannot be deleted.

6.7 Security Strategy


Click  or click  on the configuration page, select **SECURITY**.

Set security strategy to guarantee device network and data safety. It includes HTTPS, set host IP access rights, enable network security protection.



HTTPS function is for web interface and PCAPP only. See the actual interface for detailed information.

Figure 6-72 Security center



6.7.1 HTTPS

HTTPS can use the reliable and stable technological means to guarantee user information and device security and communication data security. After installing the certificate, you can use the HTTPS on the PC to access the Device.



You are recommended to enable HTTPS service. Otherwise, you might risk data leakage.

6.7.1.1 Installing Certificate

There are two ways to install the certificate.



- Manually create a certificate and then install.
- Upload a signature certificate and then install.

6.7.1.1.1 Installing the Created Certificate

Install the created certificate manually. It includes creating the certificate on the Device, downloading and installing the certificate on the PC.



- Create and install root certificate if it is your first time to use HTTPS or you have changed device IP address.
- After creating server certificate and installing root certificate, download and install root certificate on the new PC, or download the certificate and then copy to the new PC.

Step 1 Click , or click  on the configuration page, and then select **SECURITY > Credential**.

Step 2 Create certificate on the Device.

- 1) Click **Create certificate**.

Figure 6-73 Create certificate

- 2) Set country, IP/domain, valid date and so on.




- Country, IP/domain, and valid date are required items. Other items are optional.
- IP/domain shall be the Device IP or the domain.

- 3) Click **OK**.

System begins to install certificate, and then displays certificate information after the installation.

Step 3 Download certificate.


- 1) Click  **Download**.
- 2) Click **Save File** to select file saved path.
- 3) Click **Save**.
System begins downloading certificate file.

Step 4 Install root certificate on the PC.

- 1) Double-click the certificate.
System displays **Open file-security warning** page.
- 2) Click **Open**.
- 3) Click **Install Certificate**.
- 4) Follow the prompts to import the certificate.
System goes back to **Certificate** page.

Step 5 Click **OK** to complete certificate installation.

Figure 6-74 Installed certificate



6.7.1.1.2 Installing Signature Certificate

Upload signature certificate to install.

Preparation

Before installation, make sure that you have obtained safe and valid signature certificate.

Procedure




Step 1 Click , or click  on the configuration page, and then select **SECURITY > Credential**.

Figure 6-75 Credential



Step 2 Click **Install Signature Certificate**.

Step 3 Click **Browse** and then select certificate and credential file.

Step 4 Click **Install**.

System begins to install certificate, and then displays certificate information after the installation.

Step 5 Install the root certificate on the PC.



This root certificate is the one obtained with signed certificate.

6.7.1.2 Enabling HTTPS

After you install the certificate and enable HTTPS function, you can use the HTTPS on the PC to access the Device.

Step 1 Click or click on the configuration page, and then select **SECURITY > Credential**.


Step 2 Click to enable HTTPS function.

Step 3 Click to enable **Compatible with TLSv1.1 and earlier versions**.



TLS (Transport Layer Security) provides privacy and data integrity between two communications application programs.

Figure 6-76 Credential



Step 4 Click **Save**.

After you successfully save the settings, you can use HTTPS to access the web interface.

Open the browser and then enter https://IP address:port, press Enter, and the login page is displayed.



- IP address is device IP or the domain name.
- Port refers to device HTTPS port number. If the HTTPS port is the default value 443, just use https://IP address to access.

6.7.1.3 Uninstalling the Certificate

Uninstall the certificate.



- You cannot use the HTTPS function after you uninstall the certificate.
- The certificate cannot be restored after being uninstalled. Be cautious.




Step 1 Click , or click  on the configuration page, and then select **SECURITY > Credential**.

Figure 6-77 Uninstall



Step 2 Click **Uninstall**.

Step 3 Click **OK** to uninstall the certificate.

6.7.2 Configuring Access Permission

Set the specified IP addresses to access the Device, to enhance device network and data security.




Step 1 Click , or click  on the configuration page, and then select **SECURITY > IP Filter**.

Figure 6-78 IP Filter



Step 2 Select IP access rights.

- Allow all access: It is to allow all IP addresses in the same IP segment to access the Device.
- Reject access list: It means the IP address in the list cannot access the Device.
- Allow access list: It means the IP address in the list can access the Device.

Step 3 Add IP host.





The following steps are to set reject access list or allow access list.

- 1) Click **Add**.

Figure 6-79 Add

- 2) Select **Add Type**, and set IP address or MAC address of IP host.
 - Single IP: Enter host IP address.
 - IP segment: Enter IP segment. It can add multiple IP addresses in current IP segment.

- MAC: Enter MAC address of IP host.
- 3) Click **OK** to add the IP host.
System displays added IP host list.
- 
- Click **Add** to add more IP hosts.
 - Click  to edit the IP host.
 - Select an IP host and then click **Delete** to delete.

Step 4 Click **Save**.

6.7.3 Safety Protection

Set the login password lock strategy once the login password error has exceeded the specified threshold. System can lock current IP host for a period of time.





Step 1 Click , or click  on the configuration page, and then select **SECURITY > Safety Protection**.

Figure 6-80 Safety protection (1)




Step 2 Click  to enable security protection function.

- Remote: When you are using web interface, PCAPP to access the Device remotely, once the login password error has exceeded the threshold, system locks the IP host for a period of time.

- Local: When you are accessing local menu of the Device, once the login password error has exceeded the threshold, system locks the account for a period of time.

Step 3 Set lock strategy according to the actual situation.

Step 4 Click **Save**.

Once the IP host has been locked, you can view the locked IP host on the list. Select an IP host and then click **Unlock**, or click the  of the corresponding IP host to unlock.

Step 5 (Optional) Click **Login lock event** to go to the **Event** page where you can select **Abnormal Event > Lock** in to configure a **Lock in** event.

6.7.4 Enabling System Service Manually

Enable system services for third-party access.





Step 1 Click , or click  on the configuration page, and then select **SECURITY > System Service**.






Figure 6-81 System service



Step 2 Enable or disable system service according to your actual situation.

Table 6-27 System service

System service	Description
SSH	<p>After enabling this function, you can access EVS through SSH protocol to carry out system debugging and IP configuration. This function is disabled by default.</p> <p></p> <p>You are recommended to disable this function. Otherwise there might be security risks.</p>

System service	Description
Mobile Phone Push	After enabling this function, you can access EVS with mobile phone client, to receive information from EVS.  You are recommended to disable this function. Otherwise there might be security risks.
CGI Enable	After this function is enabled, third-party platform can connect EVS through CGI protocol.  You are recommended to disable this function. Otherwise there might be security risks.
ONVIF Enable	After this function is enabled, other devices can connect EVS through ONVIF protocol.  You are recommended to disable this function. Otherwise there might be security risks.
Run Log	After enabling it, you can view system running logs in Intelligent Diagnosis > Run Log .
Password Expires in	Configure the password expiration interval. The Device prompts you to change the password when the password expires.
Audio/Video Transmission Encryption	When this function is enabled, stream transmission will be encrypted.  You are recommended to enable this function. Otherwise you might risk data leakage.
RTSP over TLS	Enable this function to encrypt stream transmission.  You are recommended to enable this function. Otherwise you might risk data leakage.
Private Protocol Authentication Mode	Select a private protocol authentication mode between security mode and compatible mode. Security mode is recommended.

Step 3 Click **Save**.

6.7.5 Configuring Firewall

Enhance network and data security by prohibiting Ping and half-connection.

- **PING Prohibited**: When **PING Prohibited** is enabled, the Device does not respond to Ping requests.
- **Anti Half Connection**: When **Anti Half Connection** is enabled, and the Device can provide service normally under half-connection attack.




Step 1 Click  or click  on the configuration page, and then select **SECURITY > Firewall**.

Figure 6-82 Firewall



Step 2 Click to enable PING Prohibited or Anti Hal Connection.


Step 3 Click **Save**.

6.7.6 Configuring Time Synchronization Permission

Configure permissions of time synchronization actions from other devices or servers.

Step 1 Click or click on the configuration page, and then select **SECURITY > Synch Time**.

Figure 6-83 Sync time



Step 2 Click to enable time synchronization restriction.


Step 3 Click the **Allowlist** or **Blocklist** tab.

- Hosts in the allowlist have the permission to synchronize time of the Device.
- Hosts in the blocklist cannot synchronize time of the Device.

Step 4 On the **Allowlist** page or the **Blocklist** page, add hosts.

1) Click **Add**.

Figure 6-84 Add a host







2) Select an IP version, and then enter an IP address.

3) Click **OK**.

Step 5 Click **Save**.

You can also perform the following functions.

Table 6-28 Other functions

Function	Description
Edit IP address	Click  to edit IP address.
Delete IP address	Click  to delete a host from the list.
Configure IP address permission	Click the corresponding  of each host, so as to enable the allowlist or blocklist configuration for the host. Click  to disable the allowlist or blocklist configuration for the host.

6.8 Account Management

Device account adopts two-level management mode: user and user group. You can manage their basic information. To conveniently manage the user, we recommend the general user authorities shall be lower than high-level user authorities.



- To ensure device safety, enter correct login password to operate on the **Account** page (for example, add or delete user).
- After a correct login password is entered on Account page, if you do not close Account page, you can do other operations directly. If you close the page and enter it again, you shall enter the correct login password again.

6.8.1 User Group

Different users might have different authorities to access the Device. You can divide the users to different groups. It is easy for you to maintain and manage the user information.

- System supports maximum 64 user groups. User group name supports maximum 64 characters.
- System has two default user groups (read-only): admin and ONVIF.
- Create new user group under the root.

Adding User Group

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.


Step 2 Select the root node in the device tree on the left and then click  at the lower-left corner.

Figure 6-85 Input password

Step 3 Enter current user's login password, and then click **OK**.

Figure 6-86 User group property

Step 4 Set parameters.


Table 6-29 User group

Parameters	Description
Name	Set user group name. The name should consist of 1 to 64 characters and contain English letters, number and special characters.
Group name	Displays user group organization node. System automatically recognizes the group name.
Description	Enter user group description information.
User list	Displays user information of current group.

Step 5 Select user authority.

- 1) Click **Authority** tab.

Figure 6-87 Authority



2) Set user group authorities according to actual situation.

- : means it has the corresponding authority.
- Check the box at the top of the authority list (such as (0) Authority Control) to select all authorities of current category.

Step 6 Click **Save**.

Deleting user group



- Before you delete a user group, delete all users of current group first. User group cannot be restored after being deleted. Be cautious.
- Admin and ONVIF user cannot be deleted.

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.


Step 2 Select user group and click .

Figure 6-88 Enter password

Step 3 Enter current user's login password, and then click **OK**.

The following prompt page is displayed.

Step 4 Click **OK**.

6.8.2 Device User

The device user is to access and manage the Device. System default administrator is admin. It is to add a user and then set corresponding authorities, so that the user can access the resources within its own rights range only.



User authorities adopt the user group authorities settings. It is read-only.

Procedure

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.


Step 2 Select admin user group or other newly added user group, and then click  at the lower-left corner.

Figure 6-89 Enter password

Step 3 Enter current user's login password, and then click **OK**.

Figure 6-90 Property


Step 4 Set parameters.

Table 6-30 User management

Parameters	Description
Name	Set username. The name ranges from 1 to 31 characters. It can contain English letters, numbers and special characters (_ @ .).
Group name	Displays user organization node. System automatically identifies it.
Password	In the new password box, enter the new password and enter it again in the Confirm Password box.
Confirm Password	The password should consist of 8 to 32 non-blank characters and contain at least two types of characters among uppercase, lowercase, number, and special character (excluding ' " ; : &). Usually we recommend the strong password.
Description	Describe the user.

Step 5 (Optional) Click the **Authority** tab to view user authority.

Figure 6-91 Authority



Step 6 Click **Save**.



Related Operations

After adding a user, you can modify user information or delete the user. For details, see Table 6-31.



The user with account management authority can change its own and other users' information.

Table 6-31 User operation

Name	Operation
Edit user information	Select a user from user list. The Property page of the user is displayed, and the user's login password and description information can be modified.
Delete User	<p>Select a user from user list, and then click  to delete.</p> <p></p> <ul style="list-style-type: none"> Before deleting online user, shield the user first. For details, see "8.6 Network Care". User information cannot be restored after being deleted. Be cautious.

6.8.3 Password Maintenance

Maintain and manage user's login password.

6.8.3.1 Changing Password

Change user's login password.

Changing Password of the Current User



Step 1 Click  at the upper-right corner, and then select **Change Password**.

Figure 6-92 Change password

Step 2 Enter old, new and confirmed password.



When you enter a character that is not allowed,  appears and the character will be deleted automatically.

Step 3 Click **OK**.

Changing Password of Other User



Only **Admin** account supports this function.

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.

Step 2 Select a user.

Figure 6-93 Property

Step 3 Click .

Figure 6-94 Input password

Step 4 Enter current user's login password, and then click **OK**.

Figure 6-95 Change password

Step 5 Enter old, new and confirmed password.



Step 6 Click **OK**.

6.8.3.2 Resetting Password

You can use email address to reset password once you forgot it.

Enable password reset


Enable the password reset function, and then leave an email address for password reset.

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.

The **Account** page is displayed.

Step 2 Select the root node in the device tree on the left.

The **Password Reset** page is displayed.

Step 3 Click  to enable the password reset function.

Step 4 Enter an email address for resetting password.

Step 5 Click **Save**.


Reset password



- Make sure that the password reset function is enabled.
- Make sure that the email address for password reset is set.

Step 1 Go to the login page of the Device.


Figure 6-96 Login



Step 2 Click **Forgot Password?**.

- If you have not set the email address information, you cannot reset password. Contact your technical support for help.
- If you have set the email address information, the following prompt is displayed.


Figure 6-97 Prompt



Step 3 Click **OK**.

The QR code page is displayed.

Figure 6-98 Scan QR code



Step 4 Follow the on-screen instructions to obtain the security code. Enter the security code that you received in the security code box.



- You can get security codes twice by scanning the same QR code. If you need to get the security code once again, refresh the page.
- Use the security code to reset the password within 24 hours; otherwise the security code becomes invalid.

Step 5 Click **Next**.

The new password setting page is displayed.

Figure 6-99 New password setting

Step 6 Set parameters.

Table 6-32 Description of password parameters

Parameters	Description
User	The default username is admin.
Password	In the New Password box, enter the new password and enter it again in the Confirm Password box.
Confirm Password	The password should consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special characters (excluding ' " ; : & and space). Enter a strong password according to the password strength indication.

Step 7 Click **Confirm Modify**.

You can log in with the new password.



6.8.4 ONVIF

When the remote device is connecting with the Device through ONVIF protocol, use the verified ONVIF account.



- System adopts three ONVIF user groups (admin, user and operator). You cannot add ONVIF user group manually.
- You cannot add user under ONVIF group directly.

Adding ONVIF User

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.

Step 2 Select user group under ONVIF.

Figure 6-100 ONVIF

User Name	Password	Description
admin	--	--
user	--	--
operator	--	--



Step 3 Click  at the lower-left corner of the **Property** page.

Figure 6-101 Input password

Step 4 Enter the login password of current user, and then click **OK**.

Figure 6-102 ONVIF property



Step 5 Set parameters.

Table 6-33 ONVIF parameters description

Parameters	Description
User Name	Set ONVIF username. The name ranges from 1 to 31 characters. It can contain English letters, number and special character (_ @ .).
Group name	Displays user organization node. System automatically identifies it.
Password	Set ONVIF user password. The password should consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special characters (excluding ' " ; : & and space).
Confirm Password	
Description	Enter ONVIF user description information.

Step 6 Click **Save**.

Delete ONVIF User




Deleting the admin account is not supported.

Step 1 Click , or click  on the configuration page, and then select **ACCOUNT**.

Step 2 Select an ONVIF user and click .

Figure 6-103 Input password



Step 3 Enter current user's login password, and then click **OK**.
The following prompt page is displayed.

Step 4 Click **OK**.

6.9 System Configuration


Click or click on the configuration page, select **SYSTEM**. The **SYSTEM** page is displayed.
Set system basic settings, such as general parameters, time, display parameter, schedule, and voice.

6.9.1 Setting System Parameters

Set system language, standard, user logout time, virtual keyboard, and mouse moving speed.

Step 1 Click , or click on the configuration page, and then select **SYSTEM > General > System**.


Figure 6-104 Configuresystem settings



Step 2 Set parameters.

Table 6-34 System parameters description

Parameters	Description
Language	Set system language.

Parameters	Description
Standard	Select video standard. <ul style="list-style-type: none"> • PAL is mainly used in China, Middle East and Europe. • NTSC is mainly used in Japan, United States of America, Canada and Mexico.  <p>As a technical standard of processing video and audio signals, PAL and NTSC mainly differ in encoding, decoding mode and field scanning frequency.</p>
User Logout Time	Set automatic logout interval for log-time inactivity. After auto logout, the user needs to log in again to operate. If you set as No Logout , system does not automatically log out.
Sync Remote Device	Click <input type="checkbox"/> to enable the function. If enabled, the language, standard and time settings configured here will be synchronized to all the connected remote devices.
Standby Board Real-Time Transmission Service	After enabling this function, when the client requests real-time streams, streams will be transferred from the standby board first, and the pre-record of the standby board is enabled automatically to ensure data integrity during main/sub switch.

Step 3 Click **Save**.

6.9.2 System Time

Set system time, and enable NTP function according to your need. After enabling NTP function, device can automatically synchronize time with the NTP server.



Step 1 Click , or click  on the configuration page, and then select **SYSTEM > General > Time**.

Figure 6-105 Time

Time and Time Zone

Date
2019.12.30

Time
16:04:57

Time Manual Setting

Date/Time

Sync with Internet Time Server

Server

Auto Sync Time Interval

Time and Date Format

Time Zone

AutoTimeSynchronization

DST

Enable

Type Date Week

Start

End

Step 2 Set parameters.

Table 6-35 System parameters description

Parameters	Description
Time	<p>Set system date and time. You can set manually or set device to synchronize time with the NTP server.</p> <ul style="list-style-type: none"> ● Manual Setting: Select Manual Setting and then set the actual date and time in the following two ways. <ul style="list-style-type: none"> ◇ Click , and then set the time and date in the calendar. ◇ Click Sync to synchronize device time with your PC. ● When using IE11, Google Chrome75 or Firefox61 and later versions, on the web interface of the Device, click Sync to synchronize both device time and time zone with the PC. ● When using earlier versions of browser, on the web interface of the Device, click Sync to synchronize only device time with PC. ● Sync with the Internet Time Server: Check the box and then enter NTP server IP address or domain, and then set Auto Sync Time Interval.
Time and Date Format	Set time and date display format.
Time Zone	Set device time zone.

Parameters	Description
Auto Time Synchronization	After enabling this function, EVS detects system time of remote device once in every interval. When time of remote device is inconsistent with EVS time, EVS will calibrate the time of remote device automatically.

Step 3 (Optional) Set DST.



DST is a system to stipulate local time, in order to save energy. If the country or region where the Device is located follows DST, you can enable DST to ensure that system time is correct.

- 1) Click to enable DST.
- 2) Select DST mode. It includes **Date** and **Week**.
- 3) Set DST start time and end time.

Step 4 Click **Save**.

6.9.3 Schedule


Set schedule. When you are configuring alarm, record arm/disarm period, system can call the schedule directly. System only triggers the corresponding operations during the specified schedule.



Default schedule has been created by default. Default schedule is **Always Effective**, and cannot be modified or deleted.

Step 1 Click or click on the configuration page, and then select **SYSTEM > Schedule > Schedule**.

Figure 6-106 Schedule



Step 2 Add schedule.

- 1) Click .

The **Add Schedule** page is displayed.

Figure 6-107 Adding schedule

- 2) Set schedule name.
- 3) Click **OK** to save the configuration.



Step 3 Set valid time period. It includes **Always Effective** and **Customize**.

Step 4 Set validity period of schedule.




- The step is for customized mode only.
- Each calendar supports maximum 50 validity periods.
- The blue area on the time bar means the validity period.

On the time bar, you can:

- Click the blue area, and  is displayed. Drag  to adjust the start time and end time of validity period.
- Press the any blank space on the time bar, and drag to the right to add a validity period.
- Click **Clear** to clear all validity periods of current schedule.
- Select a validity period, and then click **Delete** to delete the period.

Step 5 Click **Save**.




Select an added schedule, and then click  to delete.

6.10 Network Storage

Network storage is a storage technology based on IP network. After you create a storage pool, you can share your storage directory with other devices through iSCSI.

Figure 6-108 Configuring network storage



6.10.1 Creating Storage Pool

Storage pool is a logical storage space after the storage device is virtualized. It is managed by the system, and can be composed of multiple actual disks or RAID. Network storage is one of the major means to realize storage virtualization.



Creating storage pool will format the disk.



Step 1 Click , or click  on the configuration page, and then select **Network Storage > Storage Pool**.

Figure 6-109 Storage pool



Step 2 Click **Add**.

Figure 6-110 Create storage pool

Create Storage Pool
✕

Pool Name

Device Name	Total Space	State	Type	Health Status
/dev/md0	58.08TB	Normal	RaidVolume	-
/dev/md1	29.04TB	Normal	RaidVolume	-
/dev/md2	29.04TB	Normal	RaidVolume	-
/dev/md3	58.08TB	Normal	RaidVolume	-
/dev/md4	36.3TB	Normal	RaidVolume	-

OK
Cancel

Step 3 Name the pool, and then select a disk or RAID group.



By default, in the **Device Name** column, "sd x " (x ranges from a to z) is a disk, such as /dev/sda, and "md x " (x is number) is a RAID group, such as /dev/md0.

Step 4 Click **OK**.

The confirmation dialogue box is displayed.

Step 5 Click **OK**.

The system starts to create storage pool.



- To delete a pool, click .
- To refresh the storage pool list, click **Refresh**.

6.10.2 Managing Share Account

Use share account to access the shared folder.

Step 1 Click , or click on the configuration page, and then select **Network Storage > Share Account**.

Figure 6-111 Share account




Step 2 Click **Add**.

Figure 6-112 Add user

Step 3 Set parameters.

Table 6-36 Parameters description

Parameters	Description
User Name	Name the user.
Service Type	You can select ISCSI, FTP/SAMBA, ISCSI/FTP/SAMABA.
Password	Set a password for the user.
Confirm password	 The password shall be 12-digit if the service type is iSCSI.
Remark	Set the remark information for identifying the user.

Step 4 Click **OK**.

6.10.3 Configuring Share Folder

Configure the share folders that other users can access remotely.



Step 1 Click , or click  on the configuration page, and then select **Network Storage > Share Folder**.

Figure 6-113 Share folder



Step 2 Click **Add**.

Figure 6-114 Add (iSCSI)

Add ✕

Directory Name

Pool Name Free Space 0

Share Capability GB

Block Size

Description

Share Type

Cache Type

<input type="checkbox"/>	(0) Share User	Read/Write Authority

Step 3 Set parameters.

Table 6-37 Parameters description

Parameters	Description
Directory Name	Name the folder.
Pool Name	Select a pool. The available free space of the selected pool is displayed beside the pool name.
Share Capacity	Set the space of the folder.

Parameters	Description
Block Size	Set the block size of the folder, such as 512 Byte, 1024 Byte, 2048 Byte and 4096 Byte. You need to set block size when the service type is iSCSI.
Descriptipon	(Optional) Describe the folder for the ease of identifying it.
Share Type	You can only select iSCSI.
Cache Type	Set the cache strategy of the share folder, including Write-back and Direct-write . <ul style="list-style-type: none"> • Direct-write: Write data directly into be disk and refresh the cache data. You are recommended to select direct-write when you have less data to store and have a high requirement for data integrity. • Write-back: Write data into the cache, and then store it into the disk when the cache is full or system is available. You are recommended to select write-back when you have much more data to store and have a low requirement for data integrity. You need to select the cache type when the service type is iSCSI.

Step 4 Click **OK**.




- The system forces to disable automatic maintenance the first time you create a share folder, or when you create a folder when automatic maintenance is enabled automatically. Once you have configured network storage, you can manually enable automatic maintenance. For details, see "8.7.3 Automatic Maintenance".
- Click to delete a share folder; click to edit a share folder; click **Refresh** to refresh the current configuration.
- Modifying cache type takes effect after the Device restarts.

6.10.4 Configuring Share Control

Users can access the share folders only when the share service is enabled.

Step 1 Click or click on the configuration page, and then select **Network Storage > Share Control**.

Figure 6-115 Share control



Step 2 Click to enable share service; click to disable share service.

Step 3 Click OK.

6.10.5 Configuring FTP Parameters

Configure FTP parameters to store videos and images to FTP server.

Step 1 Click or click on the configuration page, and then select **Network Storage > FTP Parameters**.

Figure 6-116 FTP parameters

Rate(Mbps)	<input type="text" value="16300"/>	(1-16383)
Connection Limit per IP	<input type="text" value="20"/>	(1-20)
Max Connection	<input type="text" value="100"/>	(1-100)

Rate(Mbps) : The max transmission speed of single FTP connection.
 Connection Limit per IP : The allowed number of concurrent connections for each IP.
 Max Connection : The allowed max number of connections.

Step 2 Configure the parameters.

Table 6-38 Parameters description

Parameters	Description
Rate (Mbps)	The maximum transmission speed of single FTP connection.
Connection Limit per IP	The allowed number of concurrent connections for each IP.
Max Connection	The allowed maximum number of connections.

Step 3 Click **OK**.

7 System Management

This chapter introduces system management operations including file management, maintenance, and task management.


7.1 File Management

This section introduces the management of tags, locked files and watermark.

7.1.1 Video Tag Management




Step 1 Click , and then select **FILE > Tag Management > Tag Management**.

Figure 7-1 Tag management



Step 2 Select a channel, set start time and end time, and then click **Search**.

The tags during the set time period are displayed.


- Click  to view the corresponding video.
- Click  to edit the tag.
- Click  to delete the tag.
- Select multiple tags and click **Delete** to delete the tags in batches.
- Click **Refresh** to video the latest tags.

7.1.2 FILE LOCKED

View the locked video files, and you can unlock them.

Step 1 Click , and then select **FILE > FILE LOCKED > FILE LOCKED**.

Figure 7-2 FILE LOCKED



Step 2 Select a channel, set start time and end time, and then click **Search**.
The locked files are displayed.


- Click to view the video of the locked file.
- Click **Refresh** to view the latest locked files.
- Click to unlock a file.
- Select multiple files and click **Unlock** to unlock the files in batches.

7.1.3 Watermark Verification

Verify whether a video file is tempered.

Step 1 Click , and then select **FILE > Watermark > Watermark**.

Figure 7-3 Watermark



Video File:

Watermark Info:

Tampere Watermark Info

Sn	Error Type	Watermark Time
12		

Step 2 Click **Browse** to select a video file.

Step 3 Click **Verify**.

- Normal
If the verification result is normal, the correct watermark is displayed.
- Exception
If the verification result is abnormal, the abnormal watermark and its type are displayed.

7.2 Task Management

Configure intelligent analysis tasks for metadata of recorded videos. After the intelligent analysis task is completed, you can view the metadata video on the playback page.

Step 1 Click , and then select **TASK**.

Figure 7-4 Task management

<input type="button" value="+ Create"/> <input type="button" value="▶ Start"/> <input type="button" value=" Pause"/> <input type="button" value="🗑 Delete"/> <input type="button" value="📅 Execution Period"/> <input type="text" value="Task Name"/>						
<input type="checkbox"/>	scution Order	Task Name	Device Name	Channel No	State ▾	Operate
<input type="checkbox"/>	1	15	15	1	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	2	67	67	2	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	3	36	36	3	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	4	67	67	4	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	5	IPC	IPC	5	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	6	1	1	6	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	7	95	95	7	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	8	81	81	8	Completed	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	9	camera1	camera1	9	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	10	15	15	1	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	11	67	67	2	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	12	36	36	3	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	13	67	67	4	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	14	IPC	IPC	5	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	15	1	1	6	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇
<input type="checkbox"/>	16	95	95	7	Error	▶ 🗑 ⬇ 📅 ⬆ ⬇

Total 250 item(s) Show up to 20 1/13 GO

Step 2 Click **Create**.





In the device tree,  indicates that the camera has been configured with intelligent analysis task.

Figure 7-5 Create a task




Step 3 Select a channel from the resource tree.

Step 4 Select a task type in the **Task Type** drop-down list.








- 1) Click the task type cell. The following dialogue box is displayed.

Figure 7-6 Task type



- 2) Select a task type.

Table 7-1 Task type description

Rule Name	Operations
People	<ul style="list-style-type: none"> Click  next to Enabled to enable human detection as well as face detection. Click  next to Face to disable face detection.  <p>You can only enable face detection after human detection has been enabled.</p>
Vehicle	Click  to enable vehicle detection.
Non-Motor Vehicle	<ul style="list-style-type: none"> Click  next to Enabled to enable non-motor vehicle detection as well as face detection. Click  next to Face to disable face detection.  <p>You can only enable face detection after non-motor vehicle detection has been enabled.</p>

3) Click **OK**.















Select multiple channels, click **Unified Configuration**, and then you can configure tasks in batches.

Step 5 Select start time and end time.

Step 6 Click **Apply**.

After creating the tasks, you can perform the following operations.

Table 7-2 Task operations

Function	Operation
	Click  to start a task.
	Click  to delete a task.
	Click  to download the task video.
	Click  to play back video of the task.
	Click  to increase the priority of the task.
	Click  to lower the priority of the task.
Start	Select tasks, and then click Start to start the tasks in batches.
Pause	Select tasks, and then click Pause to pause the tasks in batches.
Delete	Select tasks, and then click Delete to delete the tasks in batches.
Execution Period	Select one or more tasks, click Execution Period , and then select a time period. Tasks automatically run during this time period.

7.3 Backup

You can back up files to USB storage devices such as USB flash drive.



Step 1 Click , and then select **BACKUP**.

Figure 7-7 Backup



Step 2 Select a channel from the resource tree on the left.

Step 3 Select a file type.

- Record
 - 1) Select record types including **All**, **Video Detect**, and **IO Alarm**.
 - 2) Select a stream type including **Main Stream** and **Sub Stream**.
 - 3) Set the time period.
- Image
 - 1) Select a snapshot type from **IO Alarm** and **Video Detect**., and then select detection type as needed.
 - 2) Set the time period.

Step 4 Click **Search**.

Step 5 Select a searched file, and then click **Remote Backup**.

Figure 7-8 Remote backup

Remote Device
✕

Device

Type

Name	BUS Type	Free Space/Total	RemoteDirectory	Process

- Step 6** Click **Query** to search for connected third-party storage devices.
- Step 7** Select a storage device, and then in the **Type** box, select a target format for the file.
- Step 8** (Optional) Click **Format** to format the selected storage device. The formatting operation will clear all data of the storage device. Be cautious.
- Step 9** Click **Start** to start backing up the file.
- Step 10** (Optional) You can select a searched file, and then click **Download** to download it.

7.4 AI Report

Click , select **AI REPORT** and then you can view in-area people counting report and queue people counting report.



When viewing the report of a camera, make sure that people counting rules have been configured on it. For details, see "4.3 People Counting".

7.4.1 In-area People Counting Report

Step 1 Click , select **AI REPORT > AI REPORT > In Area People Counting Report**.

Figure 7-9 In-area people counting report

Choose Device: 4(1D01D77PAW00124)

Statistics Type: People Counting

Strand Time: 5s 30s 60s

Time Period: Daily | Monthly | Yearly

Date: 2019 - 10 - 23

OK

Step 2 Select a device to be searched. You can only select AI fisheye camera.

Step 3 Select a statistics type.

- People counting: Select **People Counting**, and then select the strand time (5 s, 30 s, 60 s).
- Average strand time: The report shows the average strand time during different time periods.

Step 4 Select a time period type from **Daily**, **Monthly**, and **Yearly**, and then set the corresponding date, month or year.

Step 5 Click **OK**.

Figure 7-10 People counting report




Figure 7-11 Average strand time report



Related Operations

- Click Area1 Area2 Area3 Area4 to select the areas of which you need to view the reports. The ordinate of the report displays different areas in different colors, showing the number of people in different areas or the average strand time.
- For people counting report, click Strand Time 5s 30s 60s to select a strand time. The report shows the people numbers of which the strand time is greater or less than the selected strand time.
- Point to the report, and then the report shows the details at that time point.
- Drag the gray scroll bar under the ordinate to view the statistics for different time periods.
- Click to view the line chart.
- Click to view the bar chart.
- Click to export the report.

7.4.2 Queue People Counting Report

Step 1 Click and then select **AI REPORT > AI REPORT > Queue People Counting**.

Figure 7-12 Queue people counting

Step 2 Select a device to be searched. You can only select AI fisheye camera.



Step 3 Select a queue time.

Step 4 Select a time period type from **Daily**, **Monthly**, and **Yearly**, and then set the corresponding date, month or year.

Step 5 Click **OK**. The report is displayed.

Figure 7-13 Queuing people counting report



- The ordinate of the report displays different areas in different colors, showing the number of people in different areas or the average dwell time.
- Point to the report, and then the report shows the details at that time point.
- Drag the gray scroll bar under the ordinate to view the statistics for different time periods.
- Click  to view the line chart.
- Click  to view the bar chart.

8 System Maintenance

On the **MAINTAIN** page, you can operate and maintain the Device working environment to guarantee proper operation.

8.1 Overview

Select **MAINTAIN > Overview**.

Figure 8-1 Overview




Table 8-1 Overview

No.	Function	Description
1	Overview	View device version details and online users. Click Refresh to refresh the data.
2	Remote Device	View the connection and idle status of remote devices <ul style="list-style-type: none"> Click Jump To to go to the DEVICE page for detailed information. Click Refresh to refresh the data.
3	RAID Status	View RAID status. <ul style="list-style-type: none"> Click Jump To to go to the STORAGE page for detailed information. Click Refresh to refresh the data.
4	Record Status	View recording status of remote devices. <ul style="list-style-type: none"> Click Jump To to go to the VIDEO RECORDING page for detailed information. Click Refresh to refresh the data.
5	Ethernet Card Status (Mbps)	View NIC status. <ul style="list-style-type: none"> Click Jump To to go to the TCP/IP page for detailed information. Click Refresh to refresh the data.

No.	Function	Description
6	Disk	<ul style="list-style-type: none"> ● Display the status of the front panel and rear panel. View status of disk, mainboard, and power. <ul style="list-style-type: none"> ◇ Disk status <ul style="list-style-type: none"> ● indicates that the disk is online. ● indicates that the disk is abnormal. ● indicates a warning disk issue. ● indicates that disk is not connected. ◇ Power status <ul style="list-style-type: none"> ● indicates that power is normal. ● indicates that power is abnormal. ● indicates that power is not connected. ◇ Mainboard status <ul style="list-style-type: none"> ● indicates that mainboard is normal. ● indicates that mainboard is abnormal. ● indicates that mainboard is not connected. ● Click Device Positioning, and then the Device positioning indicator flashes. In this way, you can quickly find the Device. ● Click Refresh to refresh the data.

8.2 System Information

You can view device information and legal information.

8.2.1 Viewing Device Information

View device information such as input bandwidth, system version, and web version.

Click  on the **LIVE** page, and select **MAINTAIN > System Info > Device Info**.

8.2.2 Viewing Legal Information


View device software license, privacy policy, and open-source software note.

Click  on the **LIVE** page, and select **MAINTAIN > System Info > Legal Info**.

8.3 System Resources

Select **MAINTAIN > System Resources > Device Resource**, and then you can view resource status including CPU and memory usage, power status, cabinet temperature and fan speed.

Figure 8-2 System resources



- Click to filter the search conditions.
- Click **Refresh** to refresh the data.

8.4 Logs

The logs record all kinds of system running information. Check the log periodically and fix the problems in time to guarantee system proper operation.

Log Classification

Search for system log, user log, event log, and link log.

Table 8-2 Log description

Log	Type
System log	Search for system log. It includes logs of system running status, file management, hot spare, hardware detect and scheduled task.
User operation log	Search for user operation log. It includes user operation and user configuration log.

Log	Type
Event log	Search for alarm event log. It includes logs of area people counting, camera external alarm, call detection, cold spot, crowd distribution map, device offline, disk health exception, fan speed alarm, fire, hot spot, IO alarm, IP conflict, IPC offline, lock in, low quota space, MAC conflict, no HDD, people counting, people stranding detection, power fault, queue people No. alarm, queue time alarm, SSD health exception, security exception, share service, smoking detection, storage error, storage full, storage pool error, tampering, temperature alarm (thermal), temerature contrast alarm, temperature (CPU), version exception, video frame loss, video motion, and RAID exception.
Link log	Search for device link log. You can search or export link log including user login/logout, session hijack, session blast and remote device.

Log Search

The following steps are to search for system log. See the actual page for detailed information.

Step 1 Select **MAINTAIN > Log > System**.

Step 2 Set search criteria such as system log level, type and date.

Step 3 Click **Search**.


Figure 8-3 System log


Type	Level	Time	Description
SyncSystemTime	Notice	2019-12-30 16:00:00	OnTime:2019-12-30 15:59:59; NewTime:2019-12-30 16:00:00; IP Address:171.35.0.46;
SyncSystemTime	Notice	2019-12-30 15:41:46	OnTime:2019-12-30 15:46:19; NewTime:2019-12-30 15:41:46; IP Address:171.35.0.46;
SyncSystemTime	Notice	2019-12-30 15:40:43	OnTime:2019-12-30 15:36:09; NewTime:2019-12-30 15:40:43; Record Type:Web3.0; IP Address:10.172.33.11;
Task is passed.	Notice	2019-12-30 13:48:42	Task Name:svrsvs, 11;
Task is started.	Notice	2019-12-30 13:36:45	Task Name:svrsvs, 11;
Task is passed.	Notice	2019-12-30 13:36:17	Task Name:svrsvs, 11;
Task is started.	Notice	2019-12-30 13:35:55	Task Name:svrsvs, 11;
Task is passed.	Notice	2019-12-30 13:33:48	Task Name:svrsvs, 11;
Task is started.	Notice	2019-12-30 13:33:22	Task Name:svrsvs, 11;
SyncSystemTime	Notice	2019-12-30 12:52:02	OnTime:2019-12-30 12:52:01; NewTime:2019-12-30 12:52:02; IP Address:171.35.0.46;
StartUp	Error	2019-12-30 12:51:22	Flag ExitPowerFail;
Abort	Error	2019-12-30 12:51:22	Time:2019-12-30 12:50:15;
SyncSystemTime	Notice	2019-12-30 12:47:48	OnTime:2019-12-30 12:47:46; NewTime:2019-12-30 12:47:48; IP Address:171.35.0.46;
StartUp	Error	2019-12-30 12:46:58	Flag ExitPowerFail;
Abort	Error	2019-12-30 12:46:58	Time:2019-12-30 12:45:52;
SyncSystemTime	Notice	2019-12-30 09:53:19	OnTime:2019-12-30 09:53:23; NewTime:2019-12-30 09:53:19; IP Address:171.35.0.46;
SyncSystemTime	Notice	2019-12-29 16:00:00	OnTime:2019-12-29 15:59:57; NewTime:2019-12-29 16:00:00;

Related Operations

Search for, export and clear log.

Table 8-3 Log operation

Name	Operation
Export log	Click  to export log information to local PC or USB storage device. You can select whether to encrypt the exported log information.

Name	Operation
Clear log	Click Clear all to clear all system logs.  You will be unable to track the system error reason if you clear log.

8.5 Intelligent Diagnosis

8.5.1 Run Log



View system running logs for troubleshooting.




Make sure that you have enabled **Run Log** in **SECURITY > System Service**. Otherwise there is no log data.

Select **MAINTAIN > Intelligent Diagnosis > Run Log**.

Figure 8-4 Logs

<input type="checkbox"/> (0)	No.	Type	File Name	Operate
<input type="checkbox"/>	1	core	coredump/core-20191021142751@_JVSS2.000.0000002.0.R_172.12.1.101_123456789012345.gz	  0
<input type="checkbox"/>	2	core	coredump/core-20191021001805@_JVSS2.000.0000002.0.R_172.12.1.101_123456789012345.gz	
<input type="checkbox"/>	3	core	coredump/core-20191019220041@_JVSS2.000.0000002.0.R_172.12.1.101_123456789012345.gz	

- Click  to export a log.
- After selecting multiple logs, click **Export** to export them in batches.

8.5.2 One-click Export

Export the diagnosis data for troubleshooting when the Device is exception.

Step 1 Select **MAINTAIN > Intelligent Diagnosis > One-click Export**.

Figure 8-5 One-click export



Step 2 Click **Generate Diagnosis Data** to generate diagnosis data.

Step 3 Click **Export** to export the diagnosis result.

8.5.3 One-click Diagnosis


You can check the configuration and status of the Device through one-click diagnosis for better use of the Device.

Step 1 Select **MAINTAIN > Intelligent Diagnosis > One-click Diagnosis**.

Step 2 Click **Diagnose**.

The results are displayed.

Figure 8-6 Diagnosis results



Step 3 For each diagnosis item, click **Details** to view detailed information.

8.6 Network Care

8.6.1 Online User

Search for remote access network user information or you can block a user from access for a period of time. During the block period, the selected user cannot access the Device.



Cannot block yourself or block admin.

Step 1 Select **MAINTAIN > Network Care > Online User**.



The list displays the connected user information.

Figure 8-7 Online user

<input type="checkbox"/>	User Name	Type	Login Time	IP	MAC	Link Type	Duration	Operate
<input type="checkbox"/>	admin	SDK	2018-11-20 17:00:29			TCP	79min	

Total 1 item(s) Show up to 20

Step 2 Block user.

- Block: Click corresponding to the user.
- Batch block: Select multiple users you want to block and then click **Block**.

Figure 8-8 Block

Block Time: 30 Min

OK Cancel

Step 3 Set block period. The default period is 30 minutes.


Step 4 Click **OK** to save the configuration.

8.6.2 Packet Capture

Packet capture is the practice of intercepting a data packet that is crossing or moving over a specific computer network. The captured packet is stored temporarily for analysis. The packet is inspected to help diagnose and solve network problems and determine whether its structure follows network security policies.

Step 1 On the **LIVE** page, click , and select **MAINTAIN > Network Care > Packet Capture**.



Figure 8-9 Packet capture



Step 2 In the **Network Test** section, enter the target address, and then click **Test**.


After testing is completed, the test result is displayed. You can check the evaluation for average delay, packet loss, and network status.

Step 3 (Optional) When operating on the local interface, connect a USB storage device to the Device, select the USB device, and then click **Browse** to select the saving path.

Step 4 In the **Packet Capture** section, click  to start capturing the packets of the corresponding NIC, and then click  to stop.



- You cannot capture packets of several NICs at the same time.
- During packet capturing, you can go to other pages for operation and go back to the **Packet Capture** page later to stop packet capturing.

Step 5 (Optional) When operating on the web or PCAPP, click  to download the captured packet.

8.7 Device Maintenance

Device maintenance is to reboot device, restore factory default setup, or upgrade system and so on. Clear the malfunction or error during the system operation and enhance device running performance.

8.7.1 Upgrading Device

Upgrade the system version.

8.7.1.1 Upgrading the Device


Import the upgrade file to upgrade device version. The upgrade file extension name shall be .bin.



- During upgrading, do not disconnect from power and network, and reboot or shut down the Device.
- Make sure that the upgrade file is correct. Improper upgrade file might result in device error!

Step 1 Select **MAINTAIN > Device Maintain > Update > Host**.

Figure 8-10 Upgrade host



Step 2 Click **Browse** to select an upgrade file.

Step 3 Click Upgrade Now.

Step 4 Click **OK**.

The system starts upgrading. Device automatically reboots after successfully upgraded.

8.7.1.2 Upgrading Cameras

Import the upgrade file to upgrade a camera.



Make sure that you have got the upgrade file and placed it in the correct directory.


Step 1 Select **MAINTAIN > Device Maintain > Update > Camera Update**.

Step 2 Select a camera, and then click **File upgrade**.



Stop recording on the camera first; otherwise the upgrade might fail.

Figure 8-11 Upgrade



Step 3 Click **Browse** to select an upgrade file.

Step 4 Click Upgrade Now.

8.7.2 Default


When the system runs slowly and has configuration errors, try to solve the problems by restoring the default settings.



All configurations are lost after factory default operation.

Step 1 Select **MAINTAIN > Device Maintain > Default**.


Figure 8-12 Default



Step 2 Select a method.


- Click **Default**.

Figure 8-13 Prompt (1)



- Click **Factory Default**.

Figure 8-14 Prompt (2)



Step 3 Click **OK**.

System begins to restore default settings. After successfully restored default settings, system prompts to restart the Device.

8.7.3 Automatic Maintenance

If the Device has run for a long time, you can set to automatically reboot the Device at idle time.

Step 1 Select **MAINTAIN > Device Maintain > Auto Maintain**.

Figure 8-15 Auto Maintain




Step 2 Set auto reboot time and.

Step 3 Enable **Emergency Maintenance**.

When the Device has an upgrade power outage, running error and other problems, and you cannot log in, you can enable **Emergency Maintenance** to restart, clear configuration, and upgrade.

Step 4 Click **Save**.

Figure 8-16 Emergency maintenance



8.7.4 IMP/EXP

Export device configuration file to local PC or USB storage device, to backup it. When the configuration is lost due to abnormal operation, import the backup configuration file to restore system configurations quickly.


Select **MAINTAIN > Device Maintain > IMP/EXP**.

Figure 8-17 IMP/EXP



Export Configuration File

Click **Export** to export configuration file to local PC or USB storage device. File path might vary depending on interface operations.

- On PCAPP, click , and then select **Download content** to view file saving path. For details, see "9.3 Viewing Downloads".
- During web operations, files are saved under default downloading path of the browser.

Import Configuration File

Step 1 Click **Browse** to select the configuration file.

Step 2 Click **Import**.

After the configuration file is imported successfully, the Device will reboot automatically.

8.8 Disk Maintenance

Check the status of HDD to handle exceptions in time.

8.8.1 S.M.A.R.T Detection

Run S.M.A.R.T detection on the storage devices.

Step 1 Select **MAINTAIN > Disk Maintenance > S.M.A.R.T Detection**.

Figure 8-18 S.M.A.R.T Detection

Storage Device	Name	Drive Letter	BUS Type	Usage Time/Hours	Temperature/°C	Reallocated Sectors C...	Pending Sector Count	Version	Error Type	Health Status
Host	HDD4	/dev/hda	SATA	31041	26	2	0	TN02	N/A	Better

Step 2 Set the detection period.

Step 3 Click **OK**.

8.8.2 Health Monitoring

Select **MAINTAIN > Disk Maintenance > Health Monitoring**, and then you can view the status of external HDD.




The function only supports HDDs provided by Dahua.

8.8.3 SSD Health Detection

On the **LIVE** page, click **+**, and select **MAINTAIN > Disk Maintenance > SSD Health Detection**, and then you can view the storage allocation and remaining P/E cycle of SSD.

Figure 8-19 SSD health detection



8.8.4 Firmware Update

Import update file to update HDD.


Step 1 Select **MAINTAIN > Disk Maintenance > Firmware update**.

Figure 8-20 Firmware update

Download Template Import Firmware Info Detect Firmware Firmware Update									
<input type="checkbox"/>	Storage Device	Name	Drive Letter	BUS Type	Model	Sn	Version	Latest Version	Upgrade State
<input type="checkbox"/>	Host	HDD1	/dev/sda	SATA	ST6000NM01151Y2110	██████████	SN05	SN05	--
<input type="checkbox"/>	Host	HDD2	/dev/sdt	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD3	/dev/sdp	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD4	/dev/sdj	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD5	/dev/sdb	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD6	/dev/sdc	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD7	/dev/sdo	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD8	/dev/sdl	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD9	/dev/sdh	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD10	/dev/sdd	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD11	/dev/sdn	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD12	/dev/sdx	SAS	ST4000NM001B	W-██████████	NDA1	--	--
<input type="checkbox"/>	Host	HDD13	/dev/sdg	SAS	ST6000NM020B	W-██████████	EOA1	--	--

Total 24 Item(s) Show up to 20

Step 2 Click **Download Template** to download update template.

Step 3 Click , select **Download**, and then open and fill in the downloaded template.

Step 4 Select an HDD, click **Import Firmware Info**, click **Browse** to choose the template to be imported, and then click **Import**.

Step 5 Click **Firmware Update** to update firmware information.

9 PCAPP Introduction

After installing PCAPP, system supports to access the Device remotely to carry out system configuration, function operations and system maintenance.



For details about installing PCAPP, see "3.3.1 Logging in to PCAPP Client".

9.1 Page Description



Double-click  on the PC desktop. System displays PCAPP at full screen by default. Click  to display the task column.

Figure 9-1 EVS task column













Table 9-1 Icons

Icons	Description
	Address bar: Enter the IP address of remote device.
	Enter device IP address and then click the button to go to the login page.
	Now the icon turns into  . Click to refresh the page.
	Click to view history login record, view downloads, set compatibility mode and view EVS version information.
	Click to minimize PCAPP.
	Click to maximize PCAPP.
	Click to display PCAPP at full screen.
	Click to close PCAPP.


9.2 History Record

Click , and then select **History**.


The **History** page is displayed. See Figure 9-2. You can view history access record and clear buffer.

- Click **Clear History** to clear all history records.
- Click **Clear Buffer** to clear buffer data, and reboot PCAPP.

Figure 9-2 History record



9.3 Viewing Downloads

To view and clear history downloads, click , and then select **Download**. The **Downloads** page is displayed. See Figure 9-3.

- Double-click file name to open it.
- Click **Displayed in Folder** to open the folder where the file is located.
- Click **Clear Downloads** to clear history download records.

Figure 9-3 Downloads



9.4 Configuring PCAPP

When PC theme is not Areo, video of PCAPP might not be displayed normally. It is suggested that PC theme should be switched to Areo, or compatibility mode of PCAPP should be enabled.


Switching PC Theme



This section uses Windows 7 as an example.

Right-click any blank position on PC desktop, select **Personalize**, and then switch to Aero theme. See Figure 9-4. Restart the PCAPP before the Aero theme takes effect.

Figure 9-4 PC theme



Enabling Compatibility Mode




Click , and select **Settings**. The **Settings** page is displayed. Select **Compatibility Mode**. Restart PCAPP before the compatibility mode takes effect.

Figure 9-5 Setting



Enabling Hardware Acceleration


Click , and select **Settings**. The **Settings** page is displayed. Select **Enable hardware acceleration (it will take effect after video is opened again)**.

The live view becomes much more fluent when this function is enabled.

9.5 Viewing Version Details

Click , and then select **About**. The **About** page is displayed. View PCAPP version information.


Figure 9-6 About



10 Log Out, Reboot, Shut Down, Lock

Log out, reboot, shut down and lock out the Device.

Figure 10-1 User operation



Log Out

Click , and then select **Log Out**.

Reboot

Click , and then select **Reboot**. System pops up confirm dialogue box. Click **OK** to reboot.

Shut Down



Unplugging the power cable might result in data (record and image) loss.


- Mode 1 (recommended): Click , and then select **Shutdown**. System pops up confirm dialogue box and then click **OK** to shut down.
- Mode 2: Use power on-off button on the Device.
 - ◇ 8-HDD series product: Press power on-off button on rear panel.
 - ◇ Other series products: Press the power on-off button on the Device for at least 4 seconds.
- Mode 3: Unplug the power cable.

Lock

Click , and then select **Lock** to lock the client. The locked client cannot be operated.

To unlock the client, click anywhere on the client, and then the **Unlock** dialogue box is displayed. Enter the username and password, and then click **OK**. You can also click **Switch User** to switch to another user account.

Figure 10-2 Unlock the client

A screenshot of a software dialog box titled "Unlock". The dialog box has a title bar with the text "Unlock" and a close button (an 'x' icon) in the top right corner. Below the title bar, there are two input fields. The first is labeled "User Name" and contains the text "admin" next to a user icon. The second is labeled "Password" and contains the text "Password" next to a lock icon and a visibility toggle icon (an eye). At the bottom of the dialog box, there are three buttons: "Switch User", "OK" (highlighted in blue), and "Cancel".

Appendix 1 Particulate and Gaseous Contamination Specifications

Appendix 1.1 Particulate Contamination Specifications

The following table defines the limitations of the particulate contamination in the operating environment of the device. If the level of particulate contamination exceeds the specified limitations and result in device damage or failure, you need to rectify the environmental conditions.

Appendix Table 1-1 Particulate contamination specifications

Particulate contamination	Specifications
Air filtration	Class 8 as defined by ISO 14644-1.
Conductive dust	Air must be free of conductive dust, zinc whiskers, or other conductive particles.
Corrosive dust	Air must be free of corrosive dust. Residual dust present in the air must have a deliquescent point less than 60% relative humidity.

Appendix Table 1-2 ISO 14644-1 cleanroom classification

Class	Maximum particles/m ³					
	≥ 0.1 μm	≥ 0.2 μm	≥ 0.3 μm	≥ 0.5 μm	≥ 1 μm	≥ 5 μm
-						
Class 1	10	2	-	-	-	-
Class 2	100	24	10	4	-	-
Class 3	1000	237	102	35	8	-
Class 4	10000	2370	1020	352	83	-
Class 5	100000	23700	10200	3520	832	29
Class 6	1000000	237000	102000	35200	8320	293
Class 7	-	-	-	352000	83200	2930
Class 8	-	-	-	3520000	832000	29300
Class 9	-	-	-	-	8320000	293000

Appendix 1.2 Gaseous Contamination Specifications

Usually indoor and outdoor atmospheric environments contain a small amount of common corrosive gas pollutants. When these mixed or single corrosive gas pollutants react with other environmental factors such as temperature or relative humidity in the long term, the device might suffer from a risk

of corrosion and failure. The following table defines the limitations of the gaseous contamination in the operating environment of the device.

Appendix Table 1-3 Gaseous contamination specifications

Gaseous contamination	Specifications
Copper coupon corrosion rate	< 300 Å/month per Class G1 as defined by ANSI/ISA71.04-2013
Silver coupon corrosion rate	< 200Å/month per Class G1 as defined by ANSI/ISA71.04-2013

Appendix Table 1-4 ANSI/ISA-71.04-2013 classification of reactive environments

Class	Copper Reactivity	Silver Reactivity	Description
G1 (mild)	< 300 Å/month	< 200 Å/month	Corrosion is not a factor in determining equipment reliability.
G2 (moderate)	< 1000 Å/month	< 1000 Å/month	Corrosion effects are measurable and corrosion might be a factor.
G3 (harsh)	< 2000 Å/month	< 2000 Å/month	High probability that corrosive attack will occur.
GX (severe)	≥ 2000 Å/month	≥ 2000 Å/month	Only specially designed and packaged devices are expected to survive.

Appendix 2 RAID

RAID is an abbreviation of Redundant Array of Independent Disks. It combines several independent HDDs (physical HDD) to form a HDD group (logic HDD) to provide more storage capacity and data redundancy.

RAID Level

RAID level refers to the way that the disk array is organized. Different RAID levels have different data protection, availability and performance.

Appendix Table 2-1 RAID level

RAID Level	Description	Min. HDD Needed
RAID 0	RAID 0 is called striping. RAID 0 is to save the continued data fragmentation on several HDDs. It can process the read and write at the same time, so its read/write speed is N (N refers to the HDD amount of the RAID 0) times as many as one HDD. RAID 0 does not have data redundant, so one HDD damage might result in data loss that cannot be restored.	2
RAID 1	It is also called mirror or mirroring. RAID 1 data is written to two HDDs equally, which guarantee the system reliability and can be repaired. RAID 1 read speed is almost close to the total volume of all HDDs. The write speed is limited by the slowest HDD. At the same time, the RAID 1 has the lowest HDD usage rate. It is only 50%.	2
RAID 5	RAID 5 is to save the data and the corresponding odd/even verification information to each HDD of the RAID 5 group and save the verification information and corresponding data to different HDDs. When one HDD of the RAID 5 is damaged, system can use the rest data and corresponding verification information to restore the damaged data. It does not affect data integrity.	3
RAID 6	Based on the RAID 5, RAID 6 adds one odd/even verification HDD. The two independent odd/even systems adopt different algorithm, the data reliability is very high. Even two HDDs are broken at the same time, there is no data loss risk. Comparing to RAID 5, the RAID 6 needs to allocate larger HDD space for odd/even verification information, so its read/write is even worse.	4
RAID 10	RAID 10 is a combination of the RAID 1 and RAID 0. It uses the extra high speed efficient of the RAID 0 and high data protection and restores capability of the RAID 1. It has high read/write performance and security. However, the RAID 10 HDD usage efficiency is as low as RAID 1.	4

RAID Level	Description	Min. HDD Needed
RAID 50	RAID50 is a combination of the RAID5 and RAID0. It has higher fault-tolerance. There is no data loss even one HDD in the set malfunctions.	6
RAID 60	RAID60 is a combination of the RAID6 and RAID0. It has higher fault-tolerance and read performance. There is no data loss even two HDDs in one set malfunctions.	8
SRAID	Based on RAID 5, SRAID, or super RAID, features quick synchronization, reconstructing while writing, partial reconstruction, reconstruction without restart and so on. SRAID promises higher security and and better performance.	3
JRAID	JRAID adopts erasure coding and has higher storage redundancy than RAID 5 and RAID 6. With up to eight redundant disks, JRAID features higher security.	3

RAID Capacity

See the sheet for RAID space information.

Capacity N refers to the mini HDD amount to create the corresponding RAID.

Appendix Table 2-2 RAID capacity

RAID Level	Total Space of the N HDD
JRAID	$(N-2) \times \text{min}(\text{capacityN})$
SRAID	$(N-1) \times \text{min}(\text{capacityN})$
RAID0	The total amount of current RAID group
RAID1	$\text{Min}(\text{capacityN})$
RAID5	$(N-1) \times \text{min}(\text{capacityN})$
RAID6	$(N-2) \times \text{min}(\text{capacityN})$
RAID10	$(N/2) \times \text{min}(\text{capacityN})$
RAID50	$(N-2) \times \text{min}(\text{capacityN})$
RAID60	$(N-4) \times \text{min}(\text{capacityN})$

Appendix 3 Glossary

FTP	File Transfer Protocol (FTP) is a protocol of the TCP/IP protocol group. It transfers file from one PC to another, without consideration of the location, connection type, and operation system of the PC.
iSCSI	Internet Small Computer System Interface (iSCSI) is an internet protocol standard in Ethernet, and an SCSI instruction set for hardware to be used in IP protocol layer. Briefly, iSCSI can realize SCSI protocol in the IP network, so router option is available in high-speed 1000M Ethernet.
LAN	Local Area Network (LAN) is a computer network that interconnects computers within a limited area (such as an office building or a school).
NFS	Network File System (NFS) is a distributed file system protocol. It allows a client computer to access files or peripheral devices of another PC. It is mainly used in UNIX-like platforms.
MTU	Maximum Transmission Unit (MTU) is the size of the largest protocol data unit that can be communicated in a single network layer transaction.
SAMBA	It is a free software that can realize Server Messages Block (SMB) on Linux and Unix systems. It consists of server and client.
SATA	Serial Advanced Technology Attachment (SATA) is a serial HDD interface that can realize serial data transmission. The current released Serial ATA 2.0 enjoys maximum theoretical transfer speed of 300MB/s.
SATA HDD	HDD that adopts SATA standard. Some leading manufacturers such as Seagate, Western Digital, and Hitachi are offering SATA HDDs.
SMART	Self-Monitoring Analysis and Reporting Technology (SMART) is an automatic monitoring and alarming system of HDD status. It monitors and records the HDD through monitoring instructions in the HDD, and compares the monitoring results with the pre-defined security value of the manufacturer. If the monitoring situation is about to exceed or already exceeded the pre-defined value, an alarm will be triggered, and small-scale repair will be initiated. This helps ensure the security of HDD data.
TCP	Transmission Control Protocol (TCP) is a transmission-layer communication protocol that provides reliable and ordered delivery of a stream of bytes.
UDP	User Datagram Protocol (UDP) is a connectionless communication protocol used for processing data packets.
WAN	Wide Area Network (WAN) is a computer network that extends over a large geographical distance. It connects physically disparate LANs and computer systems for the purpose of resource sharing.
Storage Pool	It is a virtual logic device. It can consist of several HDDs and RAID groups. It is a main way to realize virtual storage.
Synchronization	After creating RAID1 or RAID5, and before using it, the system needs to read and write the HDD at a fixed speed and adopts an algorithm to calculate. This process is called synchronization. During synchronization, the system performance speed is very low.

Shared Directory	Local PC access the top path of the shared storage space. You can create, remove, authenticate and set valid user at the storage device. User is only allowed to operate folder and file performance in the under-layer. According to different share protocols, it can be divided into SAMBA share folder, NFS share folder and FTP share folder.
Working Status	It is for RAID6/RAID5/RAID1. It is the RAID status after it completes synchronization operation. When the RAID group is in working status, on the Storage > RAID interface, the RAID device status is "clean".
Degraded Status	It is a status after you remove one disk from RAID1/RAID5 (working status) or remove two disks from RAID6. The status shows "degraded".
Manageable Status	It is a device status when controller configure device by web. Actually, when there is no error or damage, the Device shall always be in manageable status.
Ready Status	It is a device status when controller access HDD by network. The system is ready to use after you configure correctly in accordance with the Manual. Some non-device error (such as configuration error, hot swap error) might result in device failure. You can configure again to boot up the Device. But data loss might occur during this process.

Appendix 4 Cybersecurity Recommendations

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations from Dahua on how to create a more secured security system.

Mandatory actions to be taken for basic device network security:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords.

- The length should not be less than 8 characters.
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols.
- Do not contain the account name or the account name in reverse order.
- Do not use continuous characters, such as 123, abc, etc.
- Do not use overlapped characters, such as 111, aaa, etc.

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your device (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the device is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your device network security:

1. Physical Protection

We suggest that you perform physical protection to device, especially storage devices. For example, place the device in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable device (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The device supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and We recommend you keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers between

1024–65535, reducing the risk of outsiders being able to guess which ports you are using.

6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. MAC Address Binding

We recommend you bind the IP and MAC address of the gateway to the device, thus reducing the risk of ARP spoofing.

8. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

9. Disable Unnecessary Services and Choose Secure Modes

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

10. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

11. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check device log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

12. Network Log

Due to the limited storage capacity of the device, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

13. Construct a Safe Network Environment

In order to better ensure the safety of device and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.
- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.

- Enable IP/MAC address filtering function to limit the range of hosts allowed to access the device.

More information

Please visit Dahua official website security emergency response center for security announcements and the latest security recommendations.

ENABLING A SAFER SOCIETY AND SMARTER LIVING

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Address: No.1199 Bin'an Road, Binjiang District, Hangzhou, P. R. China | Website: www.dahuasecurity.com | Postcode: 310053

Email: overseas@dahuatech.com | Fax: +86-571-87688815 | Tel: +86-571-87688883