



Feature:

- * With network expansion function.
- * With power supply function.
- * Connect the controller and the unit. The last unit is connected back to the controller to realize the loop redundancy function.
- * When the loop detection is disconnected, the ACTIVE indicator light is on.
- * When the loop detection is closed, the ACTIVE indicator light is off.
- * Self-checking function. When self-checking internal faults, the ERROR indicator light is on, and it goes out when the fault is restored or there is no fault.
- * It can be connected to a power adapter for power supply.

Specification:

Model	TS-0321
Power consumption	2.5W
Supply voltage/current	36V/2A
Connection method	Special cable (6-PIN aviation wire)
Color	Silver
Weight	610g
Size	180*111*40mm
Operating temperature	0~60°C
Ambient humidity	20%~80% relative humidity, no condensation