D-Link®
Building Networks for People

Wireless N300 Nano USB Adapter
Беспроводной USB-адаптер N300
Бездротовий USB-адаптер N300
Сымсыз USB-адаптер N300

DWA-131

Quick Installation Guide
Краткое руководство по установке
Короткий посібник зі встановлення
Орнату бойынша қысқаша нұсқаулық

ENGLISH

PACKAGE CONTENTS

- **DWA-131 Wireless USB Adapter**

If any of these items are missing from your packaging, please contact your reseller.

INSTALLATION

1. Download the required driver on the DWA-131 description page from the www.dlink.com website.
2. Insert the DWA-131 into any available USB port of your powered on PC.
3. If the "Driver Software Installation" dialog box appears, press "Cancel" / "Close".
4. Open a folder with the required driver and run the "setup.exe" file to install the driver.

SETUP AND CONFIGURATION PROBLEMS

1. **What should I do, if I've forgotten my wireless encryption key?**
   The wireless encryption key is configured at the Wireless Access Point or Router. If you are unable to obtain your encryption key, the only solution would be to reconfigure your Access Point/Router to use a new encryption key. Please contact your Wireless Access Point/Router manufacturer.

2. **Why can't I get a wireless connection?**
   - Check that your DWA-131 is plugged in properly to the USB port or try to plug the DWA-131 into another USB port if it is available.
   - Ensure that the wireless settings on the DWA-131 match the settings on your Access Point/Router. Please check and confirm your settings for

     Wireless Network Name (SSID)
     Wireless Encryption Key
     Wireless Security Method (e.g. WEP, WPA2)

     to check whether a Wireless connection has been made, in the Windows System Tray (bottom right).

   - Check that your Internet is working fine on existing computers.
   - Ensure that you have followed and completed the software installation process, otherwise, please reinstall the software.