
FusionServer G5500 V7 Server

Technical White Paper

Issue 06

Date 2025-03-04





Copyright © XFUSION INTERNATIONAL PTE. LTD. 2025. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of XFUSION INTERNATIONAL PTE. LTD.

Trademarks and Permissions

CFUSION and other xFusion trademarks are trademarks of XFUSION INTERNATIONAL PTE. LTD. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between xFusion and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

XFUSION INTERNATIONAL PTE. LTD.

Website: https://www.xfusion.com

About This Document

Overview

This document describes the appearance, features, performance parameters, and hardware and software compatibility of the server, so that users can have an in-depth and detailed understanding of it.

Intended Audience

This document is intended for presales engineers.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description		
▲ DANGER	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.		
<u></u> ⚠ WARNING	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.		
⚠ CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.		
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.		
□ NOTE	Supplements the important information in the main text.		
Reini NOTE	NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.		

Change History

Issue	Date	Description	
06	2025-03-04	Added related content for the 10 x 3.5" Drive Configuration.	
05	2024-07-30	 Updated 6.2 Environmental Specifications. Added information about the configuration with 9 x 3.5" drives + 8 x dual-width GPUs + 1 x PCIe passthrough board and the configuration with 12 x 3.5" drives + 8 x dual-width GPUs + 1 x PCIe switch board. 	
04	2024-07-10	Updated 1 Product Overview, 5.2.2 Indicators and Buttons, 5.4.1 DDR5 Memory and 6.1 Technical Specifications.	
03	2024-04-30	Updated 2 Features, 4 Logical Structure, 5.4.1 DDR5 Memory and 6.1 Technical Specifications.	
02	2023-11-30	 Added 11 Waste Product Recycling. Updated 5.6.1 OCP 3.0 NICs. Updated A.4 Nameplate. 	
01	2023-10-09	This issue is the first official release.	

Contents

About This Document	ii
1 Product Overview	1
2 Features	2
3 Physical Structure	5
4 Logical Structure	
5 Hardware Description	16
5.1 Front Panel	
5.1.1 Appearance.	
5.1.2 Indicators and Buttons	
5.1.3 Ports	
5.2 Rear Panel	
5.2.1 Appearance	
5.2.2 Indicators and Buttons	
5.2.3 Ports	32
5.3 Processors	33
5.4 Memory	34
5.4.1 DDR5 Memory	34
5.4.1.1 Memory Identifier	34
5.4.1.2 Memory Subsystem Architecture	35
5.4.1.3 Memory Compatibility	37
5.4.1.4 DIMM Installation Rules.	38
5.4.1.5 Positions of Memory Modules	39
5.4.1.6 Memory Protection Technologies	40
5.5 Storage	41
5.5.1 Drive Configuration and Drive Numbering	41
5.5.1.1 24 x 3.5" Drive Configuration	42
5.5.1.2 20 x 2.5" Drive Configuration	46
5.5.1.3 9 x 3.5" Drive Configuration	48
5.5.1.4 12 x 3.5" Drive Configuration	49
5.5.1.5 10 x 3.5" drive configuration	51
5.5.2 Drive Indicators	53

5.5.3 RAID Controller Card	55
5.6 Network	55
5.6.1 OCP 3.0 NICs	55
5.7 I/O Expansion	56
5.7.1 PCIe Cards	56
5.7.2 PCle Slots	56
5.7.3 PCIe Slot Description	62
5.8 PSUs	75
5.9 Fan Modules	76
5.10 Boards	77
5.10.1 Mainboard	78
5.10.2 Drive Backplane	83
5.10.3 Fan Board	86
5.10.4 PSU Backplane	87
5.10.5 PCle Switch Board	
5.10.6 PCle Pass-Through Board	
5.10.7 M.2 SSD Adapter Board	93
6 Product Specifications	94
6.1 Technical Specifications	94
6.2 Environmental Specifications	100
6.3 Physical Specifications	102
7 Software and Hardware Compatibility	104
8 Safety Instructions	105
8.1 Security	
8.2 Maintenance and Warranty	108
9 System Management	110
10 Certifications	112
11 Waste Product Recycling	113
A Appendix	114
A.1 Chassis Label Information	
A.1.1 Chassis Head Label	
A.1.1.1 Nameplate	
A.1.1.2 Certificate	
A.1.1.3 Quick Access Label	117
A.1.2 Chassis Internal Label	118
A.1.3 Chassis Tail Label	
A.2 Product Serial Number	
A.3 Operating Temperature Limitations	121
A.4 Nameplate	122
A.5 RAS Features	122

A.6 Sensor List.	123
A.7 FAQs About Optical Modules	129
B Glossary	131
B.1 A-E	131
B.2 F-J	
B.3 K-O	132
B.4 P-T	
B.5 U-Z	134
C Acronyms and Abbreviations	135
C.1 A-E	135
C.2 F-J	
C.3 K-O	138
C.4 P-T	138
C.5 U-7	140


Product Overview

The FusionServer G5500 V7 server is a heterogeneous computing server that is optimized in HPC as well as data training and inference for deep learning for scenarios such as AI, HPC, cloud computing, and big data analytics. It supports multiple types of heterogeneous processors and applies to both enterprise and public cloud deployments.

This product is a 4U AI server that features supreme computing performance, flexible scalability, and balanced storage.

◯ NOTE

For details about the G5500 V7 nameplate, see A.4 Nameplate.





2 Features

Performance

- The server supports the fourth-generation Intel® Xeon® Scalable processors (Sapphire Rapids) and the fifth-generation Intel® Xeon® Scalable processors (Emerald Rapids). Each processor provides up to 64 cores and 128 threads, up to 385 W TDP per processor, a maximum of 4.2 GHz turbo frequency, 2 MB L2 cache and 5 MB L3 cache per core, and four groups of 20 GT/s UPI interconnect links between the processors, delivering supreme processing performance.
- The server supports up to 32 DDR5 RDIMMs with a maximum speed of 5600 MT/s registered dual-inline memory modules (RDIMMs) deliver up to 8192 GB total memory capacity (calculated using the maximum capacity of a single memory module: 256 GB). The memory modules feature high speed and availability.

Scalability

- Flexible drive configurations cater to a variety of business requirements and ensure high elasticity and scalability of storage resources.
- Supports a maximum of 24 x 3.5" SAS/SATA front drive slots, eight of which can host 3.5" NVMe drives.
- Supports a maximum of 12 x 2.5" NVMe drives and 8 x 2.5" SAS/SATA drives.
- Supports a maximum of 14 x PCle x16 standard expansion slots, 10 of which support FHFL dual-width GPUs and four of which support HHHL NICs.
- Supports three OCP 3.0 NICs. OCP1 supports PCIe 5.0 x16 (x8 + x8) bandwidth. Only multi-host is supported, but single-host is not supported. Supports flexible configuration of GE/10GE/25GE/100GE NICs. OCP1/OCP3 supports notification hot swap.

◯ NOTE

The hot swap of the OCP NIC depends on the OS driver. Ensure that the system enters the OS state and the OCP hot swap-related drivers have been loaded.

Two M.2 modules can be configured.

Availability and Serviceability

Carrier-class components with process expertise ensure high system reliability.

- The server supports hot-swappable SAS/SATA drives. SAS/SATA drives support RAID 0, 1, 1E, 10, 5, 50, 6, and 60, depending on the RAID controller card used. It also uses a supercapacitor to protect the RAID cache data against power failures.
- The RAID controller card supports Intel VROC (VMD NVMe RAID) for RAID management of NVMe drives. Different VROC keys can be configured to support multiple RAID levels.
- The panel provides UID or Healthy LED indicators and a fault diagnosis LED indicator. The iBMC WebUI displays key component status, enabling technical experts to quickly locate faulty or potentially faulty components, which simplifies maintenance, speeds up troubleshooting, and improves system availability.
- The panel provides the iBMC direct connect management port to support local iBMC O&M, improving O&M efficiency.
- The server provides four hot-swappable PSUs in 2+2 or 3+1 redundancy mode and six or eight hot-swappable fan modules in N+1 redundancy mode, improving system availability.
- The onboard Intelligent Baseboard Management Controller (iBMC) can continuously monitor system parameters, trigger alarms, and take recovery measures to minimize shutdown.

Manageability and Security

- The built-in iBMC monitors system operating status and provides remote management.
- A password is required for accessing the BIOS, ensuring system boot and management security.
- The Network Controller Sideband Interface (NC-SI) feature allows a network port
 to simultaneously serve as a management port and a service port. The NC-SI
 feature is disabled by default and can be enabled or disabled on the iBMC or
 BIOS.

NOTE

The service port with NC-SI enabled supports the following configuration:

- Configuring any network port on the OCP 3.0 NIC or PCIe NIC (with NC-SI enabled).
- If the standard PCle card supports the NC-SI function, it can be installed in slot 18 only.
- Enabling, disabling, and setting a virtual local area network (VLAN) ID for this port.
 The VLAN ID is 0 and disabled by default.
- Configuring IPv4 addresses (IPv4 address, subnet mask, and default gateway) and IPv6 addresses (IPv6 address, prefix length) for this port.
- The integrated Unified Extensible Firmware Interface (UEFI) improves setup, configuration, and update efficiency and simplifies fault clearance.
- The lockable server chassis panel ensures local data security.
- Chassis cover opening detection is supported to enhance physical security.
- Intel Execute Disable Bit (EDB) function prevents certain types of malicious buffer overflow attacks when working with a supported OS.
- Intel[®] Trusted Execution Technology prevents malicious software attacks based on hardware, prevents the firmware on the device from being maliciously modified, and prevents unauthorized boot block execution.


- Intel[®] Software Guard Extensions (SGX) technology allows applications to run in their own independent space without being affected by other software running in the system, thereby enhancing security.
- The secure boot based on the chip root of trust (RoT) implements level-by-level verification starting from the hardware RoT and builds a complete secure boot chain.
- The trusted platform module (TPM) and trusted cryptography module (TCM) provide advanced encryption functions, such as digital signatures and remote authentication.
- The following requirements in NIST SP 800-147B are met:
 - The BIOS firmware digital signature update mechanism is supported. During the upgrade, the digital signature is verified to prevent unauthorized BIOS firmware upgrade.
 - The flash security protection mechanism is supported to prevent unauthorized modification of the flash memory in the OS.

Energy Efficiency

- The server supports 80 PLUS Platinum/Titanium PSUs of different energy efficiency levels. The PSU efficiency reaches 96% at 50% load.
- Active/standby power supply and HVDC power supply are supported, improving the efficiency of the power supply system.
- Efficient voltage regulator-down (VRD) power supplies for boards minimize the energy loss from DC-to-DC power conversion.
- Area-based Proportional-Integral-Derivative (PID) intelligent fan speed adjustment and intelligent CPU frequency scaling optimize heat dissipation and reduce overall system power consumption.
- The improved thermal design with energy-efficient fans ensures optimal heat dissipation and reduces system power consumption.
- The server is protected with power capping and power control measures.
- Staggered spinup of drives reduces the server boot power consumption.

3 Physical Structure

Figure 3-1 Physical structure of a server with 24 x 3.5" drives (example)



1	PCIe switch board	2	GPU
3	PSUs	4	Power adapter board
5	Chassis	6	GPU beam
7	Supercapacitor	8	Air duct
9	Cable management arm (CMA)	10	M.2 SSD
11	PCle plug-in RAID controller card	12	Riser card of a PCle plug- in RAID controller card

13	Intrusion sensor	14	Fan board
15	24 x 3.5" drive backplane	16	Left mounting ear plate
17	3.5" drives	18	Fan modules
19	Right mounting ear plate	20	Fan module frame
21	Cable management arm (CMA)	22	CPU
23	CPU heat sinks	24	Mainboard
25	Memory modules	26	TPM/TCM
27	BMC card	28	OCP cards
29	NIC riser modules	-	-

4 Logical Structure

24 x 3.5" SAS/SATA Drive Backplane, Supporting 8 x NVMe Drives RJ 45 UART UART вмс VGA VGA USB2.0 2"PCle 3.0 x1 2*USB2.0 SMLink eSPI SPI MUX BIOS ROM SPI VROC CONN PCH USB2.0 x1 Built-in USB TPM/TCM USB3.0 x2 Rear USB3.0 USB3.0 x2 Front USB3.0 SLOT19 PCIE5.0x16 PCIE5.0x8 PCIE5.0x16 PCIE5.0x16 PCIE5.0x8 PCIE5.0x8 DMI X4 _ сно _ CH0 -PE1 PE2 PEO PE2 DMI PE0 UPI2.0 PE1 _ CH1 -— CH1 -— CH2 — — CH3 — UPI2.0 - CH2 -- CH3 CPU1 CPU2 UPI2.0 - CH4 -— CH5 -UPI2.0 - CH6 - CH6 -PE3 PE4 PE3 PE4 _ CH7 -_ CH7 _ PCIE5.0x16 PCIE5.0x16 PCIE5.0x16 PCIE5.0x16 PCle5.0 SW1 PCIe5.0 SW2 PCIE5.0x16 SLOT3 GPU SLOT5 GPU SLOT12 GPU SLOT14 GPU Single/dual root switch module

Figure 4-1 Logical structure 1 (configuration with 24 x 3.5" drives + 8 x dual-width GPUs + 1 x PCle switch board)

12*2.5 NVMe+8*2.5 SAS/SATA Drive Backplar RJ 45 UART вмс VGA VGA 2°USB2.0 e SPI SMLink BIOS ROM 2*M.2 VROC CONN PCH USB2.0 x1 Built-in USB TPM/TCM USB3.0 x2 Reat USB3.0 Front USB3.0 PCIE5.0x8 PCIE5.0x8 PCIE5.0x16 DMI X4 PE2 PE1 PE2 DMI — CH1 — – CH1 – CH2 -UPI2.0 — CH2 — – CH3 – CPU1 CPU2 CH4 -— СН4 — — CH5 — UPI2.0 - CH6 -- CH6 -PE3 PE4 PCIE5.0x16 PCIE5.0x16 UBC PCIe5.0 SW1 PCIe5.0 SW2 PCIE5.0x8 SLOT7 GPU Front 2 x GPU Rise SLOT25 GPU SLOT23 GPU Single/dual root switch module

Figure 4-2 Logical structure 2 (configuration with 20 x 2.5" drives + 10 x dual-width GPUs + 1 x PCle switch board)




Figure 4-3 Logical structure 3 (configuration with 24 x 3.5" drives + 8 x dual-width GPUs pass-through board)




Figure 4-4 Logical structure 4 (configuration with 9 x 3.5" drives + 8 x dual-width GPU pass-through + 1 pass-through board)

 $12 \times 3.5^{\circ}$ SAS/SATA drive backplane, supporting $4 \times$ NVMe Drives UART UART вмс VGA VGA USB2.0 SATA x8 TYPE-C PCH SATA drive 2*PCle 3.0 x1 2*USB2.0 SMLink eSPI SPI MUX BIOS ROM 2*M.2 SPI VROC CONN PCH USB2.0 x1 SPI TPM/TCM USB3.0 x2 Rear USB3.0 USB3.0 x2 Front USB3.0 SLOT21 SLOT20 ОСР3 with OCP2 of support MultihostX16 OCP1 PCIE5.0x8 PCIE5.0x16 PCIE5.0x16 PCIE5.0x16 DMI X4 PCIE5.0x8 - CH0 PEO PE1 PE2 DMI PEO PE2 CH₀ UPI2.0 PE1 — CH1 -— CH1 -. — сн2 – UPI2.0 - CH2 · __ снз __ - CH3 -CPU1 CPU2 — cн4 – UPI2.0 - CH4 -__ СН5 -CH5 -UPI2.0 CH6 PE3 PE4 PE4 PE3 _ CH7 -PCIE5.0x16 PCIE5.0x16 PCIE5.0x8 PCIE5.0x8 PCIe5.0 SW1 PCIe5.0 SW2 CIE5.0x16 PCIE5.0x16 CIE5.0x16 SLOT3 GPU SLOTS GPU SLOT14 GPU Single/dual root

Figure 4-5 Logical structure 5 (configuration with 12 x 3.5" drives + 8 x dual-width GPUs + 1 x PCle switch board)

12 x 3.5" SAS/SATA backplane with support for 4 NVMe drives RJ 45 GE UART UART вмс VGA USB2.0 TYPE-C 2*PCle3.0 x1 SMLink 2*USB2.0 eSPI SPI MUX BIOS ROM 2*M.2 SPI VROC CONN PCH USB2.0 x1 SPI Built-in USB TPM/TCM USB3.0 x2 Rear USB 3.0 USB3.0 x2 FrontUSB3.0 with OCP2 o support MultihostX16 OCP1 PCIE5.0x8 PCIE5.0x16 PCIE5.0x8 PCIE5.0x16 DMI X4 PCIE5.0x8 PCIE5.0x8 - CH0 -CH0 -PE2 PE0 PE2 DMI UPI2.0 PE1 CH1 _ CH1 -CH2 -_ CH2 -UPI2.0 _ снз -CPU1 CPU2 UPI2.0 CH4 -- CH4 -_ CH5 -UPI2.0 — CH6 — CH7 - CH6 -PE3 PE4 PE3 - CH7 -PCIE5.0x16 PCIE5.0x16 PCIE5.0x8 PCIE5.0x8 PCle5.0 SW1 PCIe5.0 SW2 PCIE5.0x16 PCIE5.0x16 PCIE5.0x16 PCIE5.0x16 GPU SLOT10 GPU SLOT12 GPU SLOT14 GPU SLOT16 GPU SLOT23 SLOT25 GPU Front riser

Figure 4-6 Logical structure 6 (configuration with 12 x 3.5" drives + 8 x dual-width GPUs + 1 DPU)





Figure 4-7 Logic structure 7 (10 x 3.5" drive pass-through configuration)

- The server supports two fourth-generation Intel® Xeon® Scalable processors (Sapphire Rapids) and fifth-generation Intel® Xeon® Scalable processors (Emerald Rapids). It supports 32 DDR5 DIMMs. The processors interconnect with each other through four UltraPath Interconnect (UPI) links at a speed of up to 20 Gbit/s.
- The PCIe bus resources of the processor are connected to the PCIe riser card through PCBs or cables. Different PCIe riser cards support PCIe slots of different specifications. CPU 1 and CPU 2 support a maximum of three OCP 3.0 X8 NICs, depending on the configurations.
- The BMC management chip integrated on the mainboard supports a video graphics array (VGA) port, a management network port, and a serial port.
- The G5500 V7 supports multiple logical topologies. Supports balanced and cascaded topologies. When a dual-root switchover module (the P/N code is 0258Y074) is configured, the topology can be configured using the iBMC management software to quickly adapt to different service scenarios and achieve optimal service performance. Take Figure 4-1 as an example. The details are as follows:


 As shown in Figure 4-8, the balanced topology is applicable to large-scale deep learning training.

Figure 4-8 Balanced topology



 As shown in Figure 4-9, the cascaded topology is applicable to small- and medium-scale deep learning training and inference, public cloud, and HPC scenarios.

Figure 4-9 Cascaded topology



5 Hardware Description


- 5.1 Front Panel
- 5.2 Rear Panel
- 5.3 Processors
- 5.4 Memory
- 5.5 Storage
- 5.6 Network
- 5.7 I/O Expansion
- 5.8 PSUs
- 5.9 Fan Modules
- 5.10 Boards

5.1 Front Panel

5.1.1 Appearance

• 24 x 3.5" drive configuration


Figure 5-1 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

• 20 x 2.5" drive configuration


Figure 5-2 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

• 9 x 3.5-inch drive configuration


Figure 5-3 Front view



1	Drives	2	Slide-out label plate (with an SN label)
3	Hard disk dummy module a	-	-
a: indicates a dummy hard disk module, which does not support expansion.			

• 12 x 3.5" drive configuration


Figure 5-4 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

10 x 3.5" drive configuration

Figure 5-5 Front view



1	Drives	2	Hard disk dummy module ^a
3	Slide-out label plate (with an SN label)	-	-
a: indicates a dummy hard disk module, which does not support expansion.			

5.1.2 Indicators and Buttons

Positions of Indicators and Buttons


24 x 3.5" drive configuration


5 6 7

Figure 5-6 Indicators and buttons on the front panel

1	Fault diagnosis LED	2	Power button/indicator
3	Health status indicator	4	Unit identification light (UID) button/indicator
5	FlexIO card 1 presence indicator	6	FlexIO card 3 presence indicator
7	iBMC direct connect management port indicator	-	-

• 20 x 2.5" drive configuration






1	Fault diagnosis LED	2	Power button/indicator
3	Health status indicator	4	UID button/indicator
5	FlexIO card 1 presence indicator	6	FlexIO card 3 presence indicator
7	iBMC direct connect management port indicator	-	-

• 9 x 3.5-inch drive configuration


Figure 5-8 Indicators and buttons on the front panel



1	Fault diagnosis LED	2	Power button/indicator
3	Health status indicator	4	UID button/indicator
5	FlexIO card 1 presence indicator	6	FlexIO card 3 presence indicator
7	iBMC direct connect management port indicator	-	-

• 12 x 3.5" drive configuration

Figure 5-9 Indicators and buttons on the front panel




1	Fault diagnosis LED	2	Power button/indicator
3	Health status indicator	4	UID button/indicator
5	FlexIO card 1 presence indicator	6	FlexIO card 3 presence indicator

7	iBMC direct connect management port	-	-
	indicator		

• 10 x 3.5" drive configuration

Figure 5-10 Indicators and buttons on the front panel



1	Fault diagnosis LED	2	Power button/indicator
3	Health status indicator	4	UID button/indicator
5	FlexIO card 1 presence indicator	6	FlexIO card 3 presence indicator
7	iBMC direct connect management port indicator	-	-

Indicator and Button Description

Table 5-1 Indicators and buttons on the front panel

Silkscreen	Indicators and Buttons	Description
888	Fault diagnosis LED	 : The device is operating properly. Error code: A component is faulty. For details about fault codes, see <i>iBMC</i> Alarm Handling.

Silkscreen	Indicators and Buttons	Description
ტ	Power button/ indicator	Power indicator:
		Off: The device is powered off.Steady green: The device is powered on.
		 Steady green: The device is powered on. Blinking yellow: The iBMC is starting. The power button is locked and cannot be pressed. The iBMC is started in about 1 minute, and then the power indicator turns steady yellow.
		Steady yellow: The device is standby.
		Power button:
		When the device is powered on, you can press this button to gracefully shut down the OS.
		NOTE For different OSs, you may need to shut down the OS as prompted.
		 When the device is powered on, you can hold down this button for 6 seconds to forcibly power off the device.
		When the power indicator is steady yellow, you can press this button to power on the device.
\square	Health status	Off: The device is powered off or is faulty.
	indicator	Blinking red at 1 Hz: A major alarm has been generated on the system.
		Blinking red at 5 Hz: A critical alarm has been generated on the system.
		Steady green: The device is operating properly.
@	UID button/ indicator	The UID button/indicator helps identify and locate a device.
		UID indicator:
		Off: The device is not being located.Blinking or steady blue: The device is being
		located.
		UID button:
		 You can control the UID indicator status by pressing the UID button or using the iBMC.
		You can press this button to turn on or off the UID indicator.
		You can press and hold down this button for 4 to 6 seconds to reset the iBMC.

Silkscreen	Indicators and Buttons	Description
**	FlexIO card presence indicator	 Indicates whether the FlexIO card is detected. Off: The OCP 3.0 NIC is not in position. Blinking green at 0.5 Hz: The OCP 3.0 NIC is in position but is not powered on. Blinking green at 2 Hz: The OCP 3.0 NIC is in position and has just been inserted. Steady green: The OCP 3.0 NIC is in position, and the power supply is normal.
	iBMC direct connect management port indicator	 Indicates the status when the iBMC direct connect management port connects to a terminal (local PC or Android mobile phone): Off: No terminal is connected. Blinking green at short intervals for 3 seconds and then off: The port is disabled. Steady green: The terminal is connected. Indicates the status when the iBMC direct connect management port connects to a USB device: Blinking red at long intervals: The job fails or an error is reported when the job is complete. Blinking green at short intervals: The job is being executed. Blinking green at short intervals for 3 seconds and then off: The port is disabled. Steady green: The server configuration file is being copied from the USB device or the job is successfully completed.

5.1.3 Ports

Port Positions

• 24 x 3.5" drive configuration


Figure 5-11 Ports on the front panel



1	USB 3.0 ports	2	iBMC direct connect management port
3	VGA port	-	-

• 20 x 2.5" drive configuration

Figure 5-12 Ports on the front panel



1	USB 3.0 ports	2	iBMC direct connect management port
3	VGA port	-	-

• 9 x 3.5-inch drive configuration


Figure 5-13 Ports on the front panel



1	USB 3.0 ports	2	iBMC direct connect management port
3	VGA port	-	-

• 12 x 3.5" drive configuration

Figure 5-14 Ports on the front panel



1	USB 3.0 ports	2	iBMC direct connect management port
3	VGA port	-	-

• 10 x 3.5" drive configuration

Figure 5-15 Ports on the front panel



1	USB 3.0 ports	2	iBMC direct connect management port
3	VGA port	-	-

Port Description

Table 5-2 Ports on the front panel

Port	Туре	Quantity ^{Note}	Description
VGA port	DB15	1	Used to connect a display terminal, such as a monitor or KVM.

Port	Туре	Quantity ^{Note}	Description
iBMC direct connect management port	USB Type-C NOTE The USB 2.0 protocol is supported.	1	Used to connect to a local PC or mobile phone through a USB Type-C cable to monitor and manage the system. NOTE Only local PCs running Windows 10 and mobile phones running Android are supported. • To log in to the iBMC from the local PC, enter https:///P address of the iBMC management network port in the address box of the browser on the local PC. • When accessing the iBMC through a mobile phone, you need to use the mobile application FusionMobile to access the iBMC. For details, see the FusionMobile User Guide. Used to connect to a USB device. NOTICE • Before connecting an external USB device, ensure that the USB device functions properly. Otherwise, it may adversely impact the server. • For details about how to connect the iBMC direct management interface to a USB device, see the iBMC User Guide.
USB port	USB 3.0	2	Used to connect to a USB 3.0 device. NOTICE Before connecting an external USB device, ensure that the USB device functions properly. Otherwise, it may adversely impact the server. The USB 3.0 port can be used to supply power to low-power peripherals. However, the USB 3.0 port must comply with the USB specifications. To run advanced peripherals, such as external CD/DVD drives, an external power supply is required.


Port	Туре	Quantity ^{Note}	Description
------	------	--------------------------	-------------

Note: The number of ports varies depending on server configuration. This table lists the maximum number of ports in different configurations.

5.2 Rear Panel

5.2.1 Appearance

Rear view




1	Slot1 (PCIe 5.0 x16)	2	Slot3 (PCIe 5.0 x16)
3	Slot5 (PCIe 5.0 x16)	4	Slot7 (PCIe 5.0 x16)
5	Slot9 (PCIe 5.0 x 16) ^a	6	Slot10 (PCle 5.0 x16)
7	Slot12 (PCle 5.0 x16)	8	Slot14 (PCle 5.0 x16)
9	Slot16 (PCle 5.0 x 16)	10	PSU 1
11	PSU 2	12	PSU 3
13	PSU 4	14	FlexIO card 3
15	Slot21 (PCle 5.0 x16) b	16	FlexIO card 2
17	Slot20 (PCle 5.0 x16) b	18	FlexIO card 1
19	Slot19 (PCle 5.0 x16) b	20	Slot18 (PCle 5.0 x16) b
21	BMC card	-	-

Note: Chassis silkscreen slots 2, 4, 6, 8, 11, 13, 15, and 17 are unavailable.

- a: Supported only in the PCle pass-through board scenario.
- b: Supported only in the PCle switch board scenario.

◯ NOTE

- For details about the OCP 3.0 NIC, see 5.6.1 OCP 3.0 NICs.
- The figure is for reference only. The actual configuration may vary.
- Rear panel appearance (12 x 3.5-inch drives + 8 x dual-width GPUs + 1 DPU))



1	Slot1 (PCIe 5.0 x16)	2	Slot3 (PCIe 5.0 x16)
3	Slot5 (PCIe 5.0 x16)	4	Slot6 (PCIe 5.0 x16))
5	Slot7 (PCIe 5.0 x16)	6	Slot10 (PCle 5.0 x16)
7	Slot12 (PCle 5.0 x16)	8	Slot14 (PCle 5.0 x16)
9	Slot16 (PCle 5.0 x 16)	10	PSU 1
11	PSU 2	12	PSU 3
13	PSU 4	14	FlexIO card 3
15	Slot21 (PCle 5.0 x16) a	16	FlexIO card 2
17	Slot20 (PCle 5.0 x16) a		FlexIO card 1
19	Slot19 (PCle 5.0 x16) a	20	BMC card

Note: Slot 2/4/8/9/11/13/15/17/18 is unavailable.

a: Supported only in the PCle switch board scenario.


◯ NOTE

- For details about the OCP 3.0 NIC, see 5.6.1 OCP 3.0 NICs.
- The figure is for reference only. The actual configuration may vary.

5.2.2 Indicators and Buttons

Indicator Positions

Figure 5-18 Indicators on the rear panel



1	Data transmission status indicator of the management network port	2	Connection status indicator of the management network port
3	Serial port indicators NOTE Reserved and unavailable currently.	4	UID indicator
5	PSU indicator	-	-

Indicator Description

Table 5-3 Description of indicators on the rear panel


Silkscreen	Indicator	Description
-	Data transmission status indicator of the management network port	 Off: No data is being transmitted. Blinking yellow: Data is being transmitted.

Silkscreen	Indicator	Description
-	Connection status indicator of the management network port	 Off: The network is not connected. Steady green: The network port is properly connected.
	PSU indicator	 Off: No power is supplied. Blinking green at 1 Hz: — The input is normal and the power supply enters SV12 mode. — The input is overvoltage or undervoltage. — The PSU is in deep hibernation mode. Blinking green at 4 Hz: The firmware is being upgraded online. Steady green: The input and output are normal. Steady orange: The input is normal but there is no output. NOTE The possible causes of no output are as follows: Power supply overtemperature protection Power output overcurrent or short-circuit Output overvoltage Short-circuit protection Device failure (excluding failure of all devices)
(UID indicator	 The UID indicator helps identify and locate a device. Off: The device is not being located. Blinking or steady blue: The device is being located. NOTE You can control the UID indicator status by pressing the UID button or using the iBMC.

5.2.3 Ports

Port Positions

Figure 5-19 Ports on the rear panel



1	Management network port	2	Serial port
3	VGA port	4	USB 3.0 ports
5	Socket for PSU 3	-	-

Port Description

Table 5-4 Ports on the rear panel

Port	Туре	Quantity	Description
Management network port	RJ45	1	iBMC management network port, which is used to manage the server.
			NOTE The management network port is a GE port that supports 100 Mbit/s and 1000 Mbit/s auto-negotiation.
Serial port	RJ45	1	A port used for debugging. By default, it serves as the OS serial port. You can also set it as the iBMC serial port on the iBMC CLI.
			NOTE The port is a 3-wire serial communication port, and its default baud rate is 115,200 bit/s.

Port	Туре	Quantity	Description
VGA port	DB15	1	Used to connect a display terminal, such as a display or KVM.
USB port	USB 3.0	2	Used to connect to a USB 3.0 device.
			NOTICE
			The maximum current is 1.3 A for an external USB device.
			Before connecting an external USB device, ensure that the USB device functions properly. Otherwise, it may adversely impact the server.
			The USB 3.0 port can be used to supply power to low-power peripherals. However, the USB 3.0 port must comply with the USB specifications. To run advanced peripherals, such as external CD/DVD drives, an external power supply is required.
PSU socket	-	4	Used to connect to a power distribution unit (PDU) through a power cable. You can select the PSUs as required.
			When determining the PSUs, ensure that the rated power of the PSUs is greater than that of the server.

5.3 Processors

- Supports two processors.
- Processors of the same model must be used in a server.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.





Figure 5-20 Positions of processors of a server with 24 x 3.5" drives (example)

5.4 Memory

5.4.1 DDR5 Memory

5.4.1.1 Memory Identifier

You can determine the memory module properties based on the label attached to the memory module and the following figures and tables.



Issue 06 (2025-03-04)

No.	Description	Example
1	Capacity	16 GB32 GB64 GB128 GB
2	rank(s)	 1R = Single rank 2R = Dual rank 4R = Quad rank 8R = Octal rank
3	Data width on the DRAM	x4: 4-bitx8: 8-bit
4	Type of the memory interface	• PC5 = DDR5
5	Maximum memory speed	• 5600MT/S
6	Memory latency parameters (CL-nRCD-nRP)	 A = 34-34-34 B = 40-40-40 C = 42-42-42
7	DIMM type	RD0: reference design for version RDIMM D0
8	SPD version	10: SPD version10: SPD versions from Byte 192 to Byte 447
9	Temperature grade	 Extended temperature grade (XT): 0°C to 95°C (32°F to 203°F) Normal temperature grade
		(NT): 0°C to 85°C (32°F to 185°F)

5.4.1.2 Memory Subsystem Architecture

The server provides 32 memory interfaces. Each processor integrates eight memory channels.

Install the memory modules in the primary memory channels first. If the primary memory channel is not populated, the memory modules in secondary memory channel cannot be used.

Table 5-5 Memory channels

CPU	Memory Channel	DIMM
CPU 1	A (primary)	DIMM000(A)
	A	DIMM001(I)
	B (primary)	DIMM010(B)
	В	DIMM011(J)
	C (primary)	DIMM020(C)
	С	DIMM021(K)
	D (primary)	DIMM030(D)
	D	DIMM031(L)
	E (primary)	DIMM040(E)
	Е	DIMM041(M)
	F (primary)	DIMM050(F)
	F	DIMM051(N)
	G (primary)	DIMM060(G)
	G	DIMM061(O)
	H (primary)	DIMM070(H)
	Н	DIMM071(P)
CPU 2	A (primary)	DIMM100(A)
	A	DIMM101(I)
	B (primary)	DIMM110(B)
	В	DIMM111(J)
	C (primary)	DIMM120(C)
	С	DIMM121(K)
	D (primary)	DIMM130(D)
	D	DIMM131(L)
	E (primary)	DIMM140(E)
	Е	DIMM141(M)
	F (primary)	DIMM150(F)
	F	DIMM151(N)
	G (primary)	DIMM160(G)

СРИ	Memory Channel	DIMM
	G	DIMM161(O)
	H (primary)	DIMM170(H)
	Н	DIMM171(P)

5.4.1.3 Memory Compatibility

Observe the following rules when configuring DDR5 memory modules:

NOTICE

- A server must use DDR5 memory modules of the same part number (P/N code), and the memory speed is the minimum value of the following items:
 - Memory speed supported by a processor.
 - Maximum operating speed of a memory module.
- The DDR5 DIMMs of different types (RDIMM and LRDIMM) and specifications (capacity, bit width, rank, and height) cannot be used together.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.
- The server supports the fourth-generation Intel® Xeon® Scalable processors (Sapphire Rapids) and the fifth-generation Intel® Xeon® Scalable processors (Emerald Rapids). The maximum memory capacity supported by all processor models is the same.
- For details about the type of a single memory module, see "Search Parts" in the compatibility list on the technical support website.
- The maximum number of memory modules supported depends on the memory module type and number of ranks.

◯ NOTE

Each memory channel supports a maximum of eight ranks. The number of memory modules supported by each channel varies depending on the number of ranks supported by each channel:

Number of memory modules supported by each channel ≤ Number of ranks supported by each memory channel/Number of ranks supported by each memory module.

 Each memory channel supports more than eight ranks for load-reduced DIMMs (LRDIMMs).

■ NOTE

A quad-rank LRDIMM generates the same electrical load as a single-rank RDIMM on a memory bus.

Parameter		Specific	ations					
Capacity of a DDR5 memory module (GB)		16	32	48	64	96 c/d	128	256
Туре		RDIM M	RDIM M	RDI MM	RDIM M	RD IM M	RDIM M-3DS	RDIM M-3DS
Rated speed (MT/s)		4800	5600 ^e	5600	5600 ^e	56 00	4800	4800
Operating voltage (V)		1.1	1.1	1.1	1.1	1.1	1.1	1.1
Maximum number of DDR5 DIMMs in a server ^a		32	32	16	32	32	32	32
Maximur memory of the se (GB)	capacity	512	1024	768	2048	30 72	4096	8192
Actual speed	1DPC ^b	4800	5600	5600	5600	56 00	4800	4800
(MT/s)	2DPC	4400	4400	-	4400	44 00	4400	4400

Table 5-6 DDR5 memory parameters

- a: The maximum number of DDR5 memory modules is based on dualprocessor configuration.
- b: DIMM per channel (DPC) indicates the number of memory modules per channel.
- c: Only XCC CPUs are supported when SPR CPUs are configured. This parameter is supported when EMR CPUs are configured.
- d: supports only 1DPC. (half-configured, that is, slot 0 of each channel) and 2DPC (fully configured).
- d: When the SPR CPU is configured, the maximum memory rate can reach 4800 MT/s. When the EMR CPU is configured, the maximum memory rate can reach 5600 MT/s.
- The information listed in this table is for reference only. For details, consult the local sales representative.

5.4.1.4 DIMM Installation Rules

Observe the following rules when configuring DDR5 memory modules:

• The memory modules configured must be DDR5 RDIMMs.

- The memory modules must be configured with the same number of ranks.
- Install filler memory modules in vacant slots.

5.4.1.5 Positions of Memory Modules


A server supports up to 32 DDR5 memory modules. To maximize performance, it is advised to use balanced memory configuration.

Observe the memory module installation rules when configuring memory modules. For details, see the memory configuration guide on the technical support website.

NOTICE

At least one DDR5 memory module must be installed in the primary memory channels corresponding to each CPU.

Figure 5-22 Positions of memory modules



NOTE

2 Processors: When 48 GB DIMMs are configured, only 16 DIMMs and insertion methods are supported. When 96 GB DIMMs are configured, only 16 or 32 DIMMs and insertion methods are supported.

Number of DIMMs CPU Channel DIMM Slot 2 12 16 24 32 DIMM000(A) • • • • • • Α DIMM001(I) • • DIMM010(B) • • • В DIMM011(J) DIMM020(C) • • • • C DIMM021(K) • DIMM030(D) • • • • D • DIMM031(L) CPU1 DIMM040(E) • • • • • Ε DIMM041(M) • • DIMM050(F) • • • F DIMM051(N) • DIMM060(G) G • DIMM061(O) • DIMM070(H) • Н • DIMM071(P) DIMM100(A) • • • • • Α DIMM101(I) • • DIMM110(B) • • • В DIMM111(J) • DIMM120(C) • • • С DIMM121(K) • • DIMM130(D) • • • D DIMM131(L) • CPU2 DIMM140(E) • • • • • Ε DIMM141(M) ٠ ٠ DIMM150(F) • • • • F DIMM151(N) DIMM160(G) G DIMM161(O) • • DIMM170(H) Н DIMM171(P) •

Figure 5-23 DDR5 memory installation guidelines (two processors)

5.4.1.6 Memory Protection Technologies

DDR5 DIMMs support the following memory protection technologies:

- ECC
- Memory Mirroring
- Memory Single Device Data Correction (SDDC)
- Failed DIMM Isolation
- Memory Thermal Throttling
- Command/Address Parity Check and Retry
- Memory Demand/Patrol Scrubbing
- Memory Data Scrambling
- Memory Multi Rank Sparing
- Post Package Repair (PPR)
- Write Data CRC Protection
- Adaptive Data Correction Single Region (ADC-SR)
- Adaptive Double Device Data Correction Multiple Region (ADDDC-MR)

5.5 Storage

5.5.1 Drive Configuration and Drive Numbering

5.5.1.1 24 x 3.5" Drive Configuration

Drive Configuration

Table 5-7 Drive configuration

Configuration	Front Drive	Drive Management Mode
24 x 3.5" drive switch model configuration	 Front drives: 24 x 3.5" Slots 0 to 3 support only SAS/SATA drives. Slots 4 to 5 support SAS/SATA/NVMe drives. Slots 6 to 9 support only SAS/SATA drives. Slots 10 to 11 support SAS/SATA/NVMe drives. Slots 12 to 15 support only SAS/SATA drives. Slots 16 to 17 support SAS/SATA/NVMe drives. Slots 18 to 21 support only SAS/SATA drives. Slots 18 to 21 support only SAS/SATA drives. Slots 22 to 23 support only SAS/SATA/NVMe drives. 	 SAS/SATA drives: 1x PCle plug-in RAID control card^a NVMe drive: From slot 4 to slot 5, and from slot 10 to slot 11, CPU 2 is straight out From slot 16 to slot 17 and from slot 22 to slot 23, CPU 1 is straight out
24 x 3.5" drive pass- through model configuration	 Front drives: 24 x 3.5" Slots 0 to 23 support only SAS/ SATA drives. 	SAS/SATA drives: 1x PCle plug-in RAID control card ^a

- a: The PCle plug-in RAID controller card is installed in slot 26 by default.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.

Drive Numbering

NOTICE

The drive numbers identified by the RAID controller card vary depending on the cabling of the RAID controller card. This section uses the drive numbers identified by a RAID controller card that adopts the default cabling described in "Internal Cabling" in the *Maintenance and Server Guide*.

Drive numbering of the 24 x 3.5" drive switch model configuration in Table 5-7



Figure 5-24 Drive numbering

Table 5-8 Drive numbering

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4 ^{Note}
5	5	5 ^{Note}
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10 ^{Note}
11	11	11 ^{Note}

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16 ^{Note}
17	17	17 ^{Note}
18	18	18
19	19	19
20	20	20
21	21	21
22	22	22 ^{Note}
23	23	23 ^{Note}

- Note: If the slot is configured with a SAS/SATA drive, the RAID controller card can manage the drive and allocate a number to the drive.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.
- Drive numbering of the 24 x 3.5" drive pass-through model configuration in Table
 5-7





Table 5-9 Drive numbering

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16
17	17	17
18	18	18
19	19	19
20	20	20
21	21	21
22	22	22
23	23	23

• For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.

5.5.1.2 20 x 2.5" Drive Configuration

Drive Configuration

Table 5-10 Drive configuration

Configuration	Front Drive	Drive Management Mode
20 x 2.5" drive switch model configuration	 Front drives: 20 x 2.5" Slots 0 to 3 support only SAS/SATA drives. 	 SAS/SATA drives: 1x PCIe plug-in RAID control card^a NVMe drive:
	 Slots 4 to 11 support only NVMe drives. 	From slot 4 to slot 7, CPU2 is straight out
	 Slots 12 to 15 support only SAS/SATA drives. 	 Slots 8 to 9: PCle Switch2 is connected directly
	 Slots 16 to 19 support only NVMe drives. 	From slot 10 to slot 11, PCle Switch1 is connected directly
		From slot 16 to slot 19: CPU 1 is straight out

- a: The PCIe plug-in RAID controller card is installed in slot 26 by default.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.

Drive Numbering

NOTICE

The drive numbers identified by the RAID controller card vary depending on the cabling of the RAID controller card. This section uses the drive numbers identified by a RAID controller card that adopts the default cabling described in "Internal Cabling" in the *Maintenance and Server Guide*.

Drive numbering of the 20 x 2.5" drive switch model configuration in **Table 5-10**

Figure 5-26 Drive numbering




Table 5-11 Drive numbering

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
0	0	0
1	1	1
2	2	2
3	3	3
4	4	-
5	5	-
6	6	-
7	7	-
8	8	-
9	9	-
10	10	-
11	11	-
12	12	12
13	13	13
14	14	14
15	15	15
16	16	-
17	17	-
18	18	-
19	19	-

For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.

5.5.1.3 9 x 3.5" Drive Configuration

Drive Configuration

Table 5-12 Drive Configuration

support website.

Configuration	Front Drive	Drive Management Mode
9 x 3.5" Drive Configuration + 8 x dual- width GPU pass-through (8 x SATA + 1 x NVMe))	 Front drives (9x3.5): Slots 0 to 7 support only SATA drives. Slot 11 supports only NVMe hard disks 	 SATA drive: PCH pass-through NVMe drives: CPU1 straight out
For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical		

Drive Numbering

• Numbers of all drive in the Table 5-12






Table 5-13 Drive Numbering

Drive Number	Drive Number Displayed on the iBMC WebUI
0	0
1	1
2	2
3	3
4	4

Drive Number	Drive Number Displayed on the iBMC WebUI
5	5
6	6
7	7
11	11

5.5.1.4 12 x 3.5" Drive Configuration

Drive Configuration

Table 5-14 Drive Configuration

Configuration	Front Drive	Drive Management Mode
12 x 3.5" drive + 8 x dual- width GPU switch configuration (8 x SATA + 4 x NVMe)	 Front drives: 12x 3.5" Slots 0 to 7 support only SATA drives Slots 8 to 11 support only NVMe drives. 	 SATA drive: PCH NVMe drive: Slots 8 to 9: CPU2 is straight out From slot 10 to slot 11: CPU 1 is straight out
12 x 3.5" drive s + 8 x dual-width GPU + 1 DPU (8 x SATA + 4 x NVMe)	 Front drives: 12x 3.5"^a Slots 0 to 7 support only SATA drives Slots 8 to 11 support only NVMe drives. 	 SATA drive: PCH NVMe drive: Slots 8 to 9: CPU2 is straight out From slot 10 to slot 11: CPU 1 is straight out

- a: For details about the number of supported SATA/NVMe drives, see A.3 Operating Temperature Limitations.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.

Drive Numbering

NOTICE

The drive numbers identified by the RAID controller card vary depending on the cabling of the RAID controller card. This section uses the drive numbers identified by a RAID controller card that adopts the default cabling described in "Internal Cabling" in the *Maintenance and Server Guide*.

 Drive numbering of the 12 x 3.5" drive + 8 x dual-width GPU switch configuration (8 x SATA + 4 x NVMe) configuration in Table 5-14





Table 5-15 Drive Numbering

Drive Number	Drive Number Displayed on the iBMC WebUI
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11

5.5.1.5 10 x 3.5" drive configuration

Table 5-16 Drive Configuration

Configuration	Front Drive	Drive Management Mode
10 x 3.5" drive pass- through configuration 1 (8 x SATA + 2 x NVMe)	 Front drive: 10 x 3.5" Slots 0 to 7 support only SATA drives. Slots 10 and 11 support only NVMe drives. 	SATA drive: PCHNVMe drive: CPU
10 x 3.5" drive pass- through configuration 2 (8 x SAS/SATA + 2 x NVMe)	 Front drive: 10 x 3.5" Slots 0 to 7 support only SAS/SATA drives. Slots 10 and 11 support only NVMe drives. 	 SAS/SATA drive: 1 x PCIe RAID controller card^a NVMe drive: CPU

- a: The PCle plug-in RAID controller card is installed in slot 26 by default.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the Compatibility List on the support website.

Drive Numbering

Drive numbering of the 10 x 3.5" drive pass-through configuration 1 (8 x SATA + 2 x NVMe) in Table 5-16

Figure 5-29 Drive Numbering




Table 5-17 Drive Numbering

Drive Number	Drive Number Displayed on the iBMC WebUI
0	0

Drive Number	Drive Number Displayed on the iBMC WebUI
1	1
2	2
3	3
4	4
5	5
6	6
7	7
10	10
11	11

 Drive numbering of the 10 x 3.5" drive pass-through configuration 2 (8 x SAS/ SATA + 2 x NVMe) in Table 5-16

Figure 5-30 Drive Numbering




Table 5-18 Drive Numbering

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6

Drive Number	Drive Number Displayed on the iBMC WebUI	Drive Number Identified by the RAID Controller Card
7	7	7
10	10	-
11	11	-

For details about the optional components, consult the local sales representative or see "Search Parts" in the Compatibility List on the support website.

5.5.2 Drive Indicators

SAS/SATA Drive Indicators

Figure 5-31 SAS/SATA Drive Indicators





Table 5-19 SAS/SATA drive indicators

Active Indicator (Green)	Fault Indicator (Red/Blue)	Description
Off	Off	The drive is not detected.
Steady on	Off	The drive is detected.
Blinking at 4 Hz	Off	Data is being read or written properly, or data on the primary drive is being rebuilt.
Steady on	Blinking blue at 4 Hz	The drive is being located.
Blinking at 1 Hz	Blinking red at 1 Hz synchronously	Data on the secondary drive is being rebuilt.
Off	Red steady on	A drive in a RAID array is removed.
Steady on	Red steady on	The drive is faulty.

NVMe Drive Indicators

Figure 5-32 NVMe Drive Indicators



 If the VMD function is enabled and the latest VMD driver is installed, the NVMe drives support surprise hot swap.

Table 5-20 NVMe drive indicators (VMD enabled)

Active Indicator (Green)	Fault Indicator (Red/Blue)	Description
Off	Off	The NVMe drive is not detected.
Steady on	Off	The NVMe drive is detected and operating properly.
Blinking at 4 Hz	Off	Data is being read from or written to the NVMe drive.
Steady on/ Blinking	Blinking blue at 4 Hz	The NVMe drive is being located.
Blinking at 1 Hz	Blinking red at 1 Hz synchronously	Data on the NVMe secondary drive is being rebuilt.
Steady on/Off	Red steady on	The NVMe drive is faulty.

• If the VMD function is disabled, the NVMe drives support only orderly hot swap.

Table 5-21 NVMe drive indicators (VMD disabled)

Active Indicator (Green)	Fault Indicator (Red/Blue)	Description
Off	Off	The NVMe drive is not detected.
Steady on	Off	The NVMe drive is detected and operating properly.

Active Indicator (Green)	Fault Indicator (Red/Blue)	Description
Blinking at 4 Hz	Off	Data is being read from or written to the NVMe drive.
Steady on/ Blinking	Blinking blue at 4 Hz	The NVMe drive is being located.
Off	Blinking red at 0.5 Hz	The NVMe drive has completed the hot swap process and is removable.
Off	Blinking red at 2 Hz	The NVMe drive is being hot- swapped.
Steady on/Off	Red steady on	The NVMe drive is faulty.

5.5.3 RAID Controller Card

The RAID controller card supports RAID configuration, RAID level migration, and drive roaming.

- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.
- For details about the RAID controller card, see the V7 Server RAID Controller Card User Guide.

5.6 Network

5.6.1 OCP 3.0 NICs

OCP 3.0 NICs provide network expansion capabilities.

◯ NOTE

OCP 3.0 NICs are configured in the FlexIO slots.

- The default running bandwidth is x8. A 14270055-002 cable is configured to connect the OCP 3.0 NIC 2 UBC connector (UBC2-2B/J6071) to the UBC 2 straight connector (UBC 2-2/J6054) of the mainboard. In this case, OCP 3.0 NIC 1 and OCP 3.0 NIC 2 can be configured.
- To expand the operating bandwidth to x8+x8 Multi-host, use a 14270055-003 cable to connect the OCP 3.0 NIC 1 UBC connector (UBC2-2A/J42) to the UBC 2 straight UBC connector (UBC 2-2/J6054) of the mainboard. In this case, OCP 3.0 NIC 1 supports the Multi-host function but does not support OCP 3.0 NIC 2 configuration.
- The FlexIO slot supports an OCP 3.0 network adapter, which can be configured as required.
- For details about the optional components, consult the local sales representative or see "Search Parts" in the compatibility list on the technical support website.
- For details about the OCP 3.0 NICs, see the OCP 3.0 NIC User Guide.

5.7 I/O Expansion

5.7.1 PCIe Cards

PCIe cards provide ease of expandability and connection.


- A maximum of 16 PCle slots are supported.
- For details about the optional components, consult the local sales representative or see "OS and Parts Compatibilit" in the compatibility list on the technical support website.
- When IB cards are used to build an IB network, ensure that the IPoIB modes of the IB cards at both ends of the network are the same. For details, contact technical support.

5.7.2 PCIe Slots

PCIe Slots

Rear PCIe slot

Figure 5-33 PCIe slots



- The rear GPU module provides slots 1, 3, 5, 7, 9, 10, 12, 14, and 16.
- I/O module 1 provides slots 18, 19, 20, and 21. Select corresponding PCle riser cards based on the NIC types.
- Built-in PCle slot




Figure 5-34 Built-in PCle slot (example: 24 x 3.5" Drive Configuration))

The built-in riser module provides slot 26 and supports built-in PCIe plug-in RAID controller cards.

Front PCle slots




Figure 5-35 Front PCIe slots

The front GPU riser module provides slots 23 and 25 and supports two GPUs.

PCIe Riser Cards

PCle riser card installed in I/O module 1 of the switch module
 The PCle riser card is installed in I/O module 1 of the switch model. It provides
 PCle slots 18, 19, 20, and 21.

CEM connector

Figure 5-36 PCle riser card

PCle riser card of the pass-through model

The PCIe riser card is installed in the middle of the pass-through module and provides PCIe slot 9.




Figure 5-37 PCIe riser card

PCle riser card of the built-in riser module

It is installed in the built-in riser module and provides PCIe slot 26.






Figure 5-38 PCIe riser card (example: 24 x 3.5" Drive Configuration))

PCIe riser card of the front GPU riser module
 It provides PCIe slots 23 and 25.

Figure 5-39 PCle riser card





5.7.3 PCIe Slot Description

◯ NOTE

The following table lists the PCIe port numbers mapped to CPUs. For details about the PCIe port numbers displayed on the BIOS screen, see the *Eagle Stream Platform BIOS Parameter Reference*.

Server PCIe Slot Information

• Configuration with 24 x 3.5" drives + 8 x dual-width GPUs + 1 switch board

Table 5-22 PCIe slot description

PCle Riser Card	PCIe Slot	PCIe Slot or Port Descrip tion	CPU	PCIe Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
PCIe Riser Card Support	Slot 1	PCIe 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
ed by the Rear	Slot 3	PCIe 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
GPU Module	Slot 5	PCle 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
	Slot 7	PCle 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
	Slot 10	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 12	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 14	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 16	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descrip tion	CPU	PCIe Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
PCle riser card	Slot 18	PCle 5.0 x16 (x16)	CPU 1	PE 0	Por t1a	-	HHHL
support ed by I/O module	Slot 19	PCle 5.0 x16 (x16)	CPU 1	PE 2	Por t3a	-	HHHL
1	Slot 20	PCle 5.0 x16 (x16)	CPU 2	PE 0	Por t1a	-	HHHL
	Slot 21	PCle 5.0 x16 (x16)	CPU 2	PE 2	Por t3a	-	HHHL
PCIe riser card of the built-in riser module	Slot 26	PCIe 4.0 x16 (x8)	CPU 1	PE1(0-7)	Por t2a	-	HHHL
-	FlexIO card 1	PCIe 5.0 x 16 (x8, x8+x8°)	CPU 1	PE 1 (8-15)	Por t2e	-	OCP 3.0 specific ations
	FlexIO card 2	PCIe 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Por t2a	-	OCP 3.0 specific ations
	FlexIO card 3	PCle 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Por t2e	-	OCP 3.0 specific ations

PCle Riser Card	PCIe Slot	PCle Slot or Port Descrip tion	CPU	PCle Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
-----------------------	--------------	--------------------------------------------	-----	---------------------	-----------------------------	--------	-------------------------------------------------

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: FlexIO card 1 can be redirected through a cable. FlexIO card 1 supports Multi-host function.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCIe slot is 75 W.
- Configuration with 20 x 2.5" drives + 10 x dual-width GPUs + 1 switch board

Table 5-23 PCIe slot description

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descrip tion	CPU	PCle Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
PCle Riser Card Support	Slot 1	PCIe 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
ed by the Rear	Slot 3	PCle 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
GPU Module	Slot 5	PCIe 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width

PCle Riser Card	PCIe Slot	PCIe Slot or Port Descrip tion	CPU	PCIe Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
	Slot 7	PCle 5.0 x16 (x16)	CPU 1	PE4	Por t5a	SW1	FHFL dual- width
	Slot 10	PCle 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 12	PCle 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 14	PCle 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
	Slot 16	PCle 5.0 x16 (x16)	CPU 2	PE 4	Por t5a	SW2	FHFL dual- width
PCIe riser card	Slot 18	PCle 5.0 x16 (x16)	CPU 1	PE 0	Por t1a	-	HHHL
support ed by I/O module	Slot 19	PCle 5.0 x16 (x16)	CPU 1	PE 2	Por t3a	-	HHHL
1	Slot 20	PCle 5.0 x16 (x16)	CPU 2	PE 0	Por t1a	-	HHHL
	Slot 21	PCle 5.0 x16 (x16)	CPU 2	PE 2	Por t3a	-	HHHL
PCIe riser card of the built-in riser module	Slot 26	PCIe 4.0 x16 (x8)	CPU 1	PE1(0-7)	Por t2a	-	HHHL

PCle Riser Card	PCIe Slot	PCIe Slot or Port Descrip tion	СРИ	PCIe Port No.	Po rt Nu mb er in the BI OS	Switch	PCIe Device Suppor ted by the PCIe Slot or Port
PCle riser card	Slot 23	PCle 5.0 x16 (x16)	CPU 1	PE 1	Por t2a	SW1	FHFL dual- width
support ed by the front GPU module	Slot 25	PCle 5.0 x16 (x16)	CPU 2	PE 3	Por t4a	SW2	FHFL dual- width
-	FlexIO card 1	PCIe 5.0 x16 (x8, x8+x8°)	CPU 1	PE 1 (8-15)	Por t2e	-	OCP 3.0 specific ations
	FlexIO card 2	PCle 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Por t2e	-	OCP 3.0 specific ations
	FlexIO card 3	PCle 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Por t2a	-	OCP 3.0 specific ations

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: FlexIO card 1 can be redirected through a cable. FlexIO card 1 supports Multi-host function.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCle slot is 75 W.
- 24 x 3.5" drives + 8 x dual-width GPU pass-through model configuration

Table 5-24 PCIe slot description

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descripti on	CPU	PCIe Port No.	Port Numbe r in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
PCIe Riser Card Supporte	Slot 1	PCle 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Port5a	FHFL dual- width
d by the Rear GPU	Slot 3	PCIe 5.0 x16 (x16)	CPU 1	PE3	Port4a	FHFL dual- width
Module	Slot 5	PCIe 5.0 x16 (x16)	CPU 1	PE 0	Port1a	FHFL dual- width
	Slot 7	PCIe 5.0 x16 (x16)	CPU 1	PE 2	Port3a	FHFL dual- width
	Slot 9	PCle 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Port2a	HHHL
	Slot 10	PCIe 5.0 x16 (x16)	CPU 2	PE 0	Port1a	FHFL dual- width
	Slot 12	PCIe 5.0 x16 (x16)	CPU 2	PE 2	Port3a	FHFL dual- width
	Slot 14	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Port5a	FHFL dual- width
	Slot 16	PCIe 5.0 x16 (x16)	CPU 2	PE 3	Port4a	FHFL dual- width
PCle riser card of the built- in riser module	Slot 26	PCIe 4.0 x16 (x8)	CPU 1	PE1(0-7)	Port2a	HHHL
-	FlexIO card 1	PCIe 5.0 x16 (x8, x8+x8°)	CPU 1	PE 1 (8-15)	Port2e	OCP 3.0 specificati ons

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descripti on	CPU	PCle Port No.	Port Numbe r in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
	FlexIO card 3	PCle 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Port2e	OCP 3.0 specificati ons

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: FlexIO card 1 can be redirected through a cable. FlexIO card 1 supports Multi-host function.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCle slot is 75 W.
- 9 x 3.5" drives + 8 x dual-width GPU pass-through models

Table 5-25 PCIe Slot Description

PCIe Riser Card	PCle Slot	PCIe Slot or Port Descripti on	CPU	PCIe Port No.	Port Numbe r in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
PCIe Riser Card Supporte	Slot 1	PCle 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Port5a	FHFL dual- width
d by the Rear GPU	Slot 3	PCIe 5.0 x16 (x16)	CPU 1	PE3	Port4a	FHFL dual- width
Module	Slot 5	PCle 5.0 x16 (x16)	CPU 1	PE 0	Port1a	FHFL dual- width
	Slot 7	PCle 5.0 x16 (x16)	CPU 1	PE 2	Port3a	FHFL dual- width

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descripti on	СРИ	PCIe Port No.	Port Numbe r in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
	Slot 10	PCle 5.0 x16 (x16)	CPU 2	PE 0	Port1a	FHFL dual- width
	Slot 12	PCIe 5.0 x16 (x16)	CPU 2	PE 2	Port3a	FHFL dual- width
	Slot 14	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5a	FHFL dual- width
	Slot 16	PCIe 5.0 x16 (x16)	CPU 2	PE 3	Port4a	FHFL dual- width
-	FlexIO card 1	PCle 5.0 x16 (x8, x8 + x8)	CPU1 / CPU2	PE1(0-7)	Port2a	OCP 3.0 specificati ons
	FlexIO card 3	PCle 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Port2e	OCP 3.0 specificati ons

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCIe slot is 75 W.
- Configuration with 12 x 3.5" drives + 8 x dual-width GPUs + 1 switch board

Table 5-26 PCIe Slot Description

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descript ion	СРИ	PCIe Port No.	Port Numb er in the BIOS	Sw itc h	PCIe Device Support ed by the PCIe Slot or Port
PCIe Riser Card Supporte	Slot 1	PCIe 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Port5a	S W 1	FHFL dual- width
d by the Rear GPU	Slot 3	PCle 5.0 x16 (x16)	CPU 1	PE4	Port5a	S W 1	FHFL dual- width
Module	Slot 5	PCle 5.0 x16 (x16)	CPU 1	PE4	Port5a	S W 1	FHFL dual- width
	Slot 7	PCle 5.0 x16 (x16)	CPU 1	PE4	Port5a	S W 1	FHFL dual- width
	Slot 10	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5a	S W 2	FHFL dual- width
	Slot 12	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5a	S W 2	FHFL dual- width
	Slot 14	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Port5a	S W 2	FHFL dual- width
	Slot 16	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5a	S W 2	FHFL dual- width
PCIe riser card	Slot 18	PCle 5.0 x16 (x16)	CPU 1	PE 0	Port1a	-	HHHL
supporte d by I/O module 1	Slot 19	PCIe 5.0 x16 (x16)	CPU 1	PE 2	Port3a	-	HHHL
	Slot 20	PCIe 5.0 x16 (x16)	CPU 2	PE 0	Port1a	-	HHHL

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descript ion	CPU	PCIe Port No.	Port Numb er in the BIOS	Sw itc h	PCIe Device Support ed by the PCIe Slot or Port
	Slot 21	PCIe 5.0 x16 (x16)	CPU 2	PE 2	Port3a	-	HHHL
PCIe riser card of the built- in riser module	Slot 26	PCIe 4.0 x16 (x8)	CPU 1	PE1(0- 7)	Port2a	-	HHHL
-	FlexIO card 1	PCIe 5.0 x 16 (x8, x8+x8 ^c)	CPU1 , CPU1 / CPU2	PE1 (8-15), PE1 (8-15)/ PE1 (0-7)	Port2e/ Port2e/ Port2a	-	OCP 3.0 specifica tions
	FlexIO card 2	PCIe 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Port2a	-	OCP 3.0 specifica tions
	FlexIO card 3	PCIe 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Port2e	-	OCP 3.0 specifica tions

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: FlexIO card 1 can be redirected through a cable. FlexIO card 1 supports Multi-host function.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCIe slot is 75 W.
- 12 x 3.5" drives + 8 x dual-width GPUs + 1 x DPU card

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descript ion	CPU	PCIe Port No.	Port Num ber in the BIOS	S wi tc h	PCIe Device Support ed by the PCIe Slot or Port
PCIe Riser Card Supporte	Slot 1	PCIe 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Port5 a	S W 1	FHFL dual- width
d by the Rear GPU	Slot 3	PCIe 5.0 x16 (x16)	CPU 1	PE4	Port5 a	S W 1	FHFL dual- width
Module	Slot 5	PCle 5.0 x16 (x16)	CPU 1	PE4	Port5 a	S W 1	FHFL single- width
	Slot6	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5 a	S W 2	FHFL single- width
	Slot7	PCIe 5.0 x16 (x16)	CPU 1	PE 0	Port1 a	-	FHFL dual- width
	Slot 10	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Port5 a	S W 2	FHFL dual- width
	Slot 12	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5 a	S W 2	FHFL dual- width
	Slot 14	PCIe 5.0 x16 (x16)	CPU 2	PE 4	Port5 a	S W 2	FHFL dual- width
	Slot 16	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5 a	S W 2	FHFL dual- width
PCIe riser card	Slot19	PCIe 5.0 x16 (x16)	CPU 1	PE 2	Port3 a	-	HHHL
supporte d by I/O module 1	Slot 20	PCIe 5.0 x16 (x16)	CPU 2	PE 0	Port1 a	-	HHHL
	Slot 21	PCIe 5.0 x16 (x16)	CPU 2	PE 2	Port3 a	-	HHHL

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descript ion	СРИ	PCIe Port No.	Port Num ber in the BIOS	S wi tc h	PCIe Device Support ed by the PCIe Slot or Port
PCle riser card	Slot 23	PCle 5.0 x16 (x16)	CPU 1	PE 1	Port2 a	S W 1	FHFL dual- width
supporte d by the front GPU module	Slot 25	PCIe 5.0 x16 (x16)	CPU 2	PE 3	Port4 a		FHFL dual- width
PCIe riser card of the built- in riser module	Slot 26	PCIe 4.0 x16 (x8)	CPU 1	PE1(0-7)	Port2 a	-	HHHL
-	FlexIO card 1	PCIe 5.0 x 16 (x8, x8+x8 ^c)	CPU1, CPU1/ CPU2	PE1 (8-15), PE1 (8-15) /P E1 (0-7)	Port2 e/ Port2 e/ Port2 a	-	OCP 3.0 specifica tions
	FlexIO card 2	PCIe 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Port2 a	-	OCP 3.0 specifica tions
	FlexIO card 3	PCIe 5.0 x16 (x8)	CPU 2	PE 1 (8-15)	Port2 e	-	OCP 3.0 specifica tions

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: FlexIO card 1 can be redirected through a cable. FlexIO card 1 supports Multi-host function.
- The PCIe x16 slots are compatible with PCIe x16, PCIe x8, PCIe x4, and PCIe x1 cards. That is, the PCIe slot width cannot be smaller than the PCIe card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCIe slot is 75 W.

• 10 x 3.5" drive pass-through configuration

Table 5-27 PCIe Slot Description

PCIe Riser Card	PCle Slot	PCIe Slot or Port Descripti on	CPU	PCIe Port No.	Port Number in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
PCIe Riser Card Supporte	Slot 1	PCIe 5.0 x16 ^a (x16) ^b	CPU 1	PE4	Port5a	FHFL dual- width
d by the Rear GPU	Slot 3	PCIe 5.0 x16 (x16)	CPU 1	PE3	Port4a	FHFL dual- width
Module	Slot 5	PCIe 5.0 x16 (x16)	CPU 1	PE 0	Port1a	FHFL dual- width
	Slot 7	PCIe 5.0 x16 (x16)	CPU 1	PE 2	Port3a	FHFL dual- width
	Slot9 ^c	PCle 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Port2a	HHHL
	Slot 10	PCIe 5.0 x16 (x16)	CPU 2	PE 0	Port1a	FHFL dual- width
	Slot 12	PCIe 5.0 x16 (x16)	CPU 2	PE 2	Port3a	FHFL dual- width
	Slot 14	PCle 5.0 x16 (x16)	CPU 2	PE 4	Port5a	FHFL dual- width
	Slot 16	PCIe 5.0 x16 (x16)	CPU 2	PE 3	Port4a	FHFL dual- width
PCle riser card of the built- in riser module	Slot 26	PCle 4.0 x16 (x8)	CPU 1	PE 1 (8-15)	Port2e	HHHL
-	FlexIO card 1	PCle 5.0 x16 (x16)	CPU 1	PE 1	Port2a	OCP 3.0 specificati ons

PCIe Riser Card	PCIe Slot	PCIe Slot or Port Descripti on	CPU	PCle Port No.	Port Number in the BIOS	PCIe Device Supporte d by the PCIe Slot or Port
-	FlexIO card 2 ^c	PCle 5.0 x16 (x8)	CPU 2	PE 1 (0 to 7)	Port2a	OCP 3.0 specificati ons

- a: PCle 5.0 refers to the PCle of the fifth generation, and x16 refers to the physical slot width. This also applies to the content below.
- b: The x16 in bracket indicates that the link bandwidth is x16. This also applies to the content below.
- c: Slot 9 shares PCle resources with FLEX IO card 2. You can only select one of the slots for configuration.
- The PCle x16 slots are compatible with PCle x16, PCle x8, PCle x4, and PCle x1 cards. That is, the PCle slot width cannot be smaller than the PCle card link width.
- The FHFL PCIe slots are compatible with FHFL PCIe cards, FHHL PCIe cards, and HHHL PCIe cards.
- The maximum power supply of each PCle slot is 75 W.

Server Bus/Device/Function Number (B/D/F) Information

The B/D/F information of the server may change with PCle card configurations. You can obtain the B/D/F information of the server using the following methods:

- BIOS serial port log: If the serial port log has been collected, you can query the B/D/F information of the server by searching for the keyword RootPortSBDF or DeviceSBDF.
- The following describes how to obtain the B/D/F information on different OSs.
 - Linux OS: You can obtain the B/D/F information of the server running the Ispci -vvv command.

◯ NOTE

If the OS does not support the **Ispci** command by default, obtain the **pci-utils** package from the **yum** source and install it to make the OS support the command.


- Windows OS: After installing the **pci-utils** package, run the **lspci** command to obtain the B/D/F information of the server.
- VMware OS: The **Ispci** command is supported by default. You can directly obtain the B/D/F information of the server running the **Ispci** command.

5.8 PSUs

• The server supports a maximum of four PSUs.

- The server supports AC PSUs.
- The PSUs support hot swap.
- The PSUs support 2+2 redundancy or 3+1 redundancy when four PSU are configured.
- PSUs of the same P/N code must be used in a server.
- The PSUs are protected against short circuit. Double-pole fuse is provided for the PSUs with dual input live wires.
- The power consumption parameters vary with hardware configurations (including the configurations complying with EU ErP). For details, see Power Calculator on the technical support website.
- For details about the optional components, consult the local sales representative or see "OS and Parts Compatibilit" in the compatibility list on the technical support website.

Figure 5-40 Power module location (example: 24 x 3.5" Drive Configuration))



5.9 Fan Modules


• Supports four fan modules. Each module contains two layers of fans. (Fan xA on the upper layer, Fan xB on the lower layer, and x indicates the fan module number), available with 6 or 8 fans.

∩ NOTE

- When six fans are configured:
 - The P/N codes of the fan modules installed in Fan 1 and Fan 4 must be the same. Fan 2 and Fan 3 must have the same fan module P/N code.
 - Fans 1A and 4A are installed with fan filler modules, and fans in other locations.
- · When eight fans are configured:
 - Fan 1/2/3/4 fan module P/N codes must be the same.
 - Fans are installed on all Fan 1A/1B/2A/2B/3A/3B/4A/4B.
- 24 x 3.5" drive configuration:
 - The configuration with 24 x 3.5" drives + 8 x dual-width GPUs + 1 x PCIe switch board requires six fans.
 - The configuration with 24 x 3.5" drives + 8 x dual-width GPUs + 1 x PCle passthrough board requires six fans.
- Configuration with 20 x 2.5" drives + 10 x dual-width GPUs + 1 switch board:

- The configuration with a front GPU riser module requires eight fans.
- The configuration without a front GPU riser module requires six fans.
- The PSUs support hot swap.
- N+1 redundancy is supported. That is, the server can work properly when a single fan fails.
- The fan speed can be adjusted.


Figure 5-41 Positions of fan modules in a server with 20 x 2.5" drives (example)



5.10 Boards

5.10.1 Mainboard

Figure 5-42 Mainboard (P/N code: 0302Y183)



1	OCP 3.0 NIC 3 connector (OCP3 CONN/J7023)	2	RAID controller card low- speed signal connector (RAID MIS/J7017)
3	OCP 3.0 NIC 2 UBC connector (UBC2-2B/ J6071)	4	OCP 3.0 NIC 2 connector (OCP2 CONN/J7016)

5	Rear I/O board low-speed signal connector (BACK IO BOARD/J7000)	6	OCP 3.0 NIC 1 connector (OCP1 CONN/J7014)
7	OCP 3.0 NIC 1 UBC connector (UBC2-2A/J42)	8	2 x USB 3.0 ports (USB3.0 CONN/J88)
9	Rear VGA port (VGA CONN/J60)	10	Serial port (COM/J6020)
11	BMC management port (BMC_GE/J6019)	12	BMC management board
13	LCD connector (LCD CONN/J6025) ^a	14	TPM/TCM connector (J6065)
15	Built-in USB 3.0 connector (INNER USB3.0/J6067)	16	M.2 low-speed signal connector (M.2 MIS/J61)
17	NC-SI connector (NCSI CONN/J7013)	18	PCH SATA port A&B connector (PORT(A-B)/ J7009)
19	CPU 1 UBC DD connector (UBCDD 1-1/J64)	20	RAID controller card UBC connector (UBC 1-2/J6051)
21	CPU 1 UBC DD connector (UBCDD 1-3/J6052)	22	Fan board signal connector (FAN BOARD/J7022)
23	Right mounting ear connector (R_EAR BOARD/J7012)	24	CPU 1 UBC DD connector (UBCDD 1-5/J37)
25	CPU 1 UBC DD connector (UBCDD 1-4/J49)	26	Intrusion sensor connector (INTRUDER/S2)
27	CPU 2 UBC DD connector (UBCDD 2-5/J45)	28	CPU 2 UBC DD connector (UBCDD 2-4/J41)
29	Drive backplane low-speed signal connector (FRONT HDD BP/J6082)	30	CPU 2 UBC DD connector (UBCDD 2-1/J6053)
31	UBC2 straight connector (UBC 2-2/J6054)	32	CPU 2 UBC DD connector (UBCDD 2-3/J53)
33	Left mounting ear connector (L_EAR BOARD/ J7003)	34	VROC key connector (VROC KEY/J6066)
35	Fan board power connector 1 (FAN PWR_1/J7010)	36	Fan board power connector 2 (FAN PWR_2/ J7006)
37	PSU backplane input power connector (PWR IN/ J6093)	38	Copper bar power connector (PWR GND/ J7008)


39	Copper bar power	40	PSU backplane power
	connector (PWR 12V_IN/		connector (PDB MIS
	J7007)		CONN/J7005)

a: Reserved and unavailable currently.

NOTE

OCP 3.0 NICs are configured in the FlexIO slots.

- The default running bandwidth is x8. A 14270055-002 cable is configured to connect the OCP 3.0 NIC 2 UBC connector (UBC2-2B/J6071) to the UBC 2 straight connector (UBC 2-2/J6054) of the mainboard. In this case, OCP 3.0 NIC 1 and OCP 3.0 NIC 2 can be configured.
- To expand the operating bandwidth to x8+x8 Multi-host, use a 14270055-003 cable to connect the UBC connector (UBC2-2A/J42) of OCP 3.0 NIC 1 to the UBC 2 straight UBC connector (UBC 2-2/J6054) of the mainboard. In this case, OCP 3.0 NIC 1 supports the Multi-host function but does not support OCP 3.0 NIC 2 configuration.



4

Figure 5-43 Mainboard (P/N code: 0302Y636)

3

RAID controller card lowspeed signal connector

(RAID MIS/J7017)

OCP 3.0 NIC 2 UBC

connector (UBC2-6B/

J6071)

5	OCP 3.0 NIC 2 connector (OCP2 CONN/J7016)	6	Rear I/O board low-speed signal connector (BACK IO BOARD/J7000)
7	OCP 3.0 NIC 1 UBC connector (UBC1-2A/J38)	8	OCP 3.0 NIC 1 connector (OCP1 CONN/J7014)
9	OCP 3.0 NIC 1 UBC connector (UBC1-6A/J42)	10	2 x USB 3.0 ports (USB3.0 CONN/J88)
11	Rear VGA port (VGA CONN/J60)	12	Serial port (COM/J6020)
13	BMC management port (BMC_GE/J6019)	14	BMC management board
15	LCD connector (LCD CONN/J6025) ^a	16	TPM/TCM connector (J6065)
17	M.2 low-speed signal connector (M.2 MIS/J61)	18	NC-SI connector (NCSI CONN/J7013)
19	PCH SATA port A&B connector (PORT(A-B)/ J7009)	20	CPU 1 UBC DD connector (UBCDD 1-1/J64)
21	UBC straight connector (UBC1-6/J31)	22	RAID controller card UBC connector (UBC 1-2/J6051)
23	CPU 1 UBC DD connector (UBCDD 1-3/J6052)	24	Fan board signal connector (FAN BOARD/J7022)
25	Right mounting ear connector (R_EAR BOARD/J7012)	26	CPU 1 UBC DD connector (UBCDD 1-5/J37)
27	CPU 1 UBC DD connector (UBCDD 1-4/J49)	28	Intrusion sensor connector (INTRUDER/S2)
29	CPU 2 UBC DD connector (UBCDD 2-5/J45)	30	CPU 2 UBC DD connector (UBCDD 2-4/J41)
31	Drive backplane low-speed signal connector (FRONT HDD BP/J6082)	32	CPU 2 UBC DD connector (UBCDD 2-1/J6053)
33	UBC straight connector (UBC2-6/J36)	34	UBC2 straight connector (UBC 2-2/J6054)
35	CPU 2 UBC DD connector (UBCDD 2-3/J53)	36	Left mounting ear connector (L_EAR BOARD/J7003)
37	VROC key connector (VROC KEY/J6066)	38	Fan board power connector 1 (FAN PWR_1/ J7010)

39	Fan board power connector 2 (FAN PWR_2/J7006)	40	PSU backplane input power connector (PWR IN/ J6093)
41	Copper bar power connector (PWR GND/ J7008)	42	Copper bar power connector (PWR 12V_IN/ J7007)
43	PSU backplane power connector (PDB MIS CONN/J7005)	-	-
a: Reserved and unavailable currently.			

NOTE


OCP 3.0 NICs are configured in the FlexIO slots.

5.10.2 Drive Backplane

Front-Drive Backplane

24 x 3.5" drive configuration backplane
 All configurations in section 5.5.1.1 24 x 3.5" Drive Configuration support this backplane.

Figure 5-44 24 x 3.5" drive backplane (16 x SAS/SATA + 8 x NVMe/SAS/SATA)




1	Low-speed signal connector (REAR BP0/ J37)	2	UBC high-speed signal connector (J1)
3	mini-SAS HD connector (REAR BP PORTA/J34)	4	mini-SAS HD connector (REAR BP PORTB/J35)

5	mini-SAS HD connector (REAR BP0/1 J33)	6	Low-speed signal connector (REAR BP1/ J38)
7	Low-speed signal connector (MAIN BOARD/J40)	8	UBC 4 high-speed connector (J5)
9	Power connector (24HDD POWER MAINBOARD/ J42)	10	mini-SAS HD connector (REAR BP PORTC/J36)
11	UBC 3 high-speed connector (J4)	12	UBC 2 high-speed connector (J3)
13	Low-speed signal connector (REAR BP/ J39)	14	Power connector (POWER REAR BP/J43)
15	UBC 1 high-speed connector (J2)	-	-

20 x 2.5" drive switch model configuration backplane
 All configurations in section 5.5.1.2 20 x 2.5" Drive Configuration support this backplane.

Figure 5-45 20 x 2.5" pass-through configuration backplane




1	UBC connector 1-E (UBC1-E/J11)	2	UBC connector 1-D (UBC1-D/J10)
3	UBC connector 1-C (UBC1-C/J9)	4	UBC connector 1-B (UBC1-B/J8)
5	UBC connector 1-A (UBC1-A/J7)	6	UBC connector 2-F (UBC2-F/J6)
7	UBC connector 2-E (UBC2-E/J5)	8	UBC connector 2-C (UBC2-C/J3)
9	UBC connector 2-B (UBC2-B/J2)	10	UBC connector 2-A (UBC2-A/J1)

11	Backplane signal cable connector (HDD BP/J40)	12	Power connector (HDD_POWER/J41)
13	mini-SAS HD connector (PORT A/J13)	14	UBC connector 2-D (UBC2-D/J4)
15	mini-SAS HD connector (PORT B/J14)	16	UBC connector 1-F (UBC1-F/J12)

• 9x3.5" drive pass-through configuration, 10x3.5" drive pass-through configuration, and 12x3.5" switched configuration backplane

All drive configurations in the 5.5.1.3 9 x 3.5" Drive Configuration, 5.5.1.4 12 x 3.5" Drive Configuration and 5.5.1.5 10 x 3.5" drive configuration sections support this backplane.

Figure 5-46 12 x 3.5" drive pass-through configuration backplane




No.	Connector	Managed Drive Slot
1	Indicator signal cable connector (REAR BP0/ J17)	-
2	mini-SAS HD connector (PORT C/J4)	Slot 8~Slot 11
3	mini-SAS HD connector (PORT B/J3)	Slot 4~Slot 7
4	Mini-SAS HD connector (PORT A/J28)	Slot 0~Slot 3
5	Power connector (HDD_POWER/J21)	-
6	Backplane signal cable connector (HDD BP/ J19)	-
7	Indicator signal cable connector (REAR BP1/ J18)	-

No.	Connector	Managed Drive Slot
8	UBC connector 1 (UBC1/J1)	Slot 8~Slot 9
9	UBC connector 2 (UBC2/J2)	Slot 10~Slot 11

5.10.3 Fan Board

Figure 5-47 Fan board




1	LAAC JTAG connector (LAAC JTAG/J17)	2	Fan board signal connector (MISC CONN/J3)
3	Water detection cable presence detection connector (LIQ PRES1/J19) ^a	4	LAAC connector (LAAC4/ J16)
5	Water detection cable leakage detection connector (LIQ LEAK1/ J18) ^a	6	LAAC connector (LAAC3/ J15)
7	Fan board power connector 2 (POWER CONN2/J2)	8	LAAC connector (LAAC2/ J14)
9	Water detection cable presence detection connector (LIQ PRES2/ J21) ^a	10	LAAC connector (LAAC1/ J13)
11	Water detection cable leakage detection connector (LIQ LEAK2/ J20) ^a	12	Fan connector (FAN1A/J5)
13	Fan connector (FAN1B/J7)	14	Fan connector (FAN2B/J8)

15	Fan connector (FAN2A/J6)	16	Fan board power connector 1 (POWER CONN1/J4)
17	Fan connector (FAN3B/ J11)	18	Fan connector (FAN3A/J9)
19	Fan connector (FAN4B/ J12)	20	Fan connector (FAN4A/ J10)
a: Reserved and unavailable currently.			

5.10.4 PSU Backplane

Figure 5-48 PSU backplane




1	Power connector (HDD BP/ J100)	2	Power connector (RSW-2&MB/J102)
3	Power connector (RSW-1&RISER/J101)	4	Guide sleeve (J108)

(0100)	5	Spurious signal connector (J103)	-	-
--------	---	----------------------------------	---	---

5.10.5 PCle Switch Board

Figure 5-49 PCIe switch board 1



1	CEM connector (PCIE SLOT16 X16/J18)	2	CEM connector (PCIE SLOT14 X16/J17)
3	CEM connector (PCIE SLOT12 X16/J16)	4	CEM connector (PCIE SLOT10 X16/J15)
5	Power connector (PWR CON1/J121)	6	Power connector (PWR CON2/J122)
7	UBCDD high-speed connector (UBCDD1-1/ J133)	8	UBCDD high-speed connector (UBCDD2-1/ J134)
9	CEM connector (PCIE SLOT7 X16/J14)	10	CEM connector (PCIE SLOT5 X16/J13)

11	CEM connector (PCIE SLOT3 X16/J12)	12	CEM connector (PCIE SLOT1 X16/J11)
13	UBC high-speed connector (UBC1-5B/J137)	14	UBC high-speed connector (UBC1-5A/J136)
15	UBC high-speed connector (UBC6-HDDBP/J140)	16	GPU power connector (GPU PWR CONN1/J111)
17	GPU power connector (GPU PWR CONN3/J112)	18	GPU power connector (GPU PWR CONN5/J113)
19	GPU power connector (GPU PWR CONN7/J114)	20	Low-speed signal connector (MISC CONN/ J102)
21	GPU power connector (GPU PWR CONN10/J115)	22	Power connector (BACK_RISER1/2_PWR/ J119/J120)
23	GPU power connector (GPU PWR CONN12/J116)	24	GPU power connector (GPU PWR CONN14/J117)
25	GPU power connector (GPU PWR CONN16/J118)	26	UBC high-speed connector (UBC5-HDDBP/J141)
27	UBC high-speed connector (UBC2-4B/J139)	28	UBC high-speed connector (UBC2-4B/J138)
29	Low-speed signal connector (DPU/J144)	-	-

1 2 3 4 5 6 7 8 9 10 11 12 13 14

1 2 3 4 5 6 7 8 9 10 11 12 13 14

30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15

Figure 5-50 PCIe switch module 2

1	CEM connector (PCIE SLOT16 X16/J18)	2	CEM connector (PCIE SLOT14 X16/J17)
3	CEM connector (PCIE SLOT12 X16/J16)	4	CEM connector (PCIE SLOT10 X16/J15)
5	DPU low-speed connector (DPU CONN/J144)	6	RETIMER power connector (RT PWR CONN/J145)
7	UBCDD high-speed connector (UBCDD3/J3)	8	UBCDD high-speed connector (UBCDD1/J133)
9	UBCDD high-speed connector (UBCDD2/J134)	10	CEM connector (PCIE SLOT7 X16/J1)
11	CEM connector (PCIE SLOT6 X16/J14)	12	CEM connector (PCIE SLOT5 X16/J13)
13	CEM connector (PCIE SLOT3 X16/J12)	14	CEM connector (PCIE SLOT1 X16/J11)
15	UBC high-speed connector (UBC1-5B/J137)	16	UBC high-speed connector (UBC1-5A/J136)

17	UBC high-speed connector (UBC5-HDDBP/J140)	18	GPU power connector (GPU PWR CONN1/J111)
19	GPU power connector (GPU PWR CONN3/J112)	20	GPU power connector (GPU PWR CONN5/J113)
21	GPU power connector (GPU PWR CONN7/J114)	22	Low-speed signal connector (MISC CONN/ J102)
23	GPU power connector (GPU PWR CONN10/J115)	24	Power connector (PWR CON1/J121)
25	GPU power connector (GPU PWR CONN12/J116)	26	GPU power connector (GPU PWR CONN14/J117)
27	GPU power connector (GPU PWR CONN16/J118)	28	UBC high-speed connector (UBC6-HDDBP/J141)
29	UBC high-speed connector (UBC2-4B/J139)	30	UBC high-speed connector (UBC2-4A/J138)

5.10.6 PCle Pass-Through Board

Figure 5-51 PCle pass-through board


1 2 3 4 5 6 7 8 9

1	CEM connector 8 (PCIE SLOT16 x16 (UBCDD2-4)/ J17)	2	CEM connector 7 (PCIE SLOT14 x16 (UBCDD2-5)/ J16)
3	CEM connector 6 (PCIE SLOT10 x16 (UBCDD2-3)/ J15)	4	CEM connector 5 (PCIE SLOT10 x16 (UBCDD2-1)/ J14)
5	Spurious connector for the riser card (MISC SLOT9/J1)	6	CEM connector 4 (PCIE SLOT7 x16 (UBCDD1-3)/ J13)
7	CEM connector 3 (PCIE SLOT5 x16 (UBCDD1-1)/ J12)	8	CEM connector 2 (PCIE SLOT3 x16 (UBCDD1-4)/ J11)

9	CEM connector 1 (PCIE SLOT1 x16 (UBCDD1-5)/ J10)	10	GPU power cable connector 1 (GPU PWR CONN1/J110)
11	GPU power cable connector 2 (GPU PWR CONN3/J111)	12	GPU power cable connector 3 (GPU PWR CONN5/J112)
13	GPU power cable connector 4 (GPU PWR CONN7/J113)	14	GPU power cable connector 5 (GPU PWR CONN10/J114)
15	GPU power cable connector 6 (GPU PWR CONN12/J115)	16	Power connector (PWR CONN1/J3)
17	Spurious connector for the BIOA board (MISC CONN/ J102)	18	GPU power cable connector 7 (GPU PWR CONN14/J116)
19	GPU power cable connector 8 (GPU PWR CONN16/J117)	20	Power connector (PWR CONN2/J4)

5.10.7 M.2 SSD Adapter Board

Figure 5-52 M.2 adapter board



1	Signal connector (J1)	2	High-speed connector (J2)
---	-----------------------	---	---------------------------

6 Product Specifications

- 6.1 Technical Specifications
- 6.2 Environmental Specifications
- 6.3 Physical Specifications

6.1 Technical Specifications

Table 6-1 Technical specifications

Category	Specifications
Form factor	4U Al server
Chipset	Emmitsburg PCH

Category	Specifications	
Processor	Supports two processors.	
	The server supports the fourth-generation Intel® Xeon® Scalable processors (Sapphire Rapids) and the fifth-generation Intel® Xeon® Scalable processors (Emerald Rapids).	
	Built-in memory controller and eight DIMM channels per processor.	
	Built-in PCle controller, supporting PCle 5.0 and 80 lanes per processor.	
	Four UltraPath Interconnect (UPI) buses between processors, providing up to 20 GT/s transmission per channel.	
	Up to 64 cores.	
	Max. 4.2 GHz frequency.	
	Min. 2 MB L3 cache per core.	
	Max. 385 W thermal design power (TDP).	
	NOTE The preceding information is for reference only. For details, see "Search Parts" in the compatibility list on the technical support website.	
Memory	Up to 32 DDR5 DIMMs. 32 memory slots.	
	 RDIMM or RDIMM-3DS supported. 	
	 Max. 5600 MT/s memory speed. 	
	 DDR5 memory modules of different types (RDIMM and RDIMM-3DS) and specifications (capacity, bit width, rank, and height) cannot be used together. 	
	 A server must use DDR5 DIMMs of the same P/N code. 	
	NOTE The preceding information is for reference only. For details, see "Search Parts" in the compatibility list on the technical support website.	

Category	Specifications
Storage	Supports a variety of drive configurations. For details, see 5.5.1 Drive Configuration and Drive Numbering.
	Supports two M.2 SSDs.
	 M.2 SSDs are supported for VROC (SATA RAID) configuration when the server is configured with an M.2 SSD adapter card.
	NOTE
	 The M.2 SSD is used only as a boot device for installing the OS. Small-capacity (32 GB or 64 GB) M.2 SSDs do not support logging due to poor endurance. If a small- capacity M.2 SSD is used as the boot device, a dedicated log drive or log server is required for logging. For example, you can dump VMware logs in either of the following ways:
	 Redirect /scratch. For details, see https:// kb.vmware.com/s/article/1033696.
	 Configure syslog. For details, see https:// kb.vmware.com/s/article/2003322.
	 The M.2 SSD cannot be used to store service data due to poor endurance. In write-intensive applications, the M.2 SSD will wear out in a short time. If you want to use SSDs or HDDs as data storage devices, use enterprise-level SSDs or HDDs with high DWPD.
	 The M.2 SSD is not recommended for write-intensive service software due to poor endurance.
	Do not use M.2 SSDs for cache.
	Supports hot swap of SAS/SATA/NVMe U.2 drives.
	NOTE When NVMe drives are configured, note the following:
	Before using the VMD function, contact technical support engineers of the OS vendor to check whether the OS supports the VMD function. If yes, check whether the VMD driver needs to be manually installed and check the installation method.
	 If the VMD function is enabled and the latest VMD driver is installed, the NVMe drives support surprise hot swap.
	 If the VMD function is disabled, the NVMe drives support orderly hot swap.
	Supports a variety of RAID controller cards.For details, visit the technical support website and see Search Parts in the compatibility list.
	 The RAID controller card supports RAID configuration, RAID level migration, and drive roaming.
	The RAID controller card supports a supercapacitor for power-off protection to ensure user data security.
	The PCIe plug-in RAID controller card occupies one PCIe slot.

Category	Specifications
	For details about the RAID controller card, see the server RAID Controller Card User Guide.
	NOTE If the BIOS is in legacy mode, the 4K drive cannot be used as the boot drive.
Network	OCP 3.0 NICs provide network expansion capabilities.
	 Three or two OCP3.0 NICs can be configured. If two OCP3.0 NICs are configured, OCP 3.0 1 supports the Multi-Host function.
	 The 10x3.5" drive pass-through model supports either 2 OCP 3.0 network adapters or 1 OCP 3.0 network adapter configuration, and does not support Multi- Host.
	Supports orderly hot swap.
	NOTE The OCP 3.0 NIC supports orderly hot swap only when the VMD function is disabled.
	 Supports a variety of OCP 3.0 NICs. For details, visit the technical support website and see Search Parts in the compatibility list.

Category	Specifications
I/O expansion	24 x 3.5" drive switch model provides 16 PCIe slots including:
	Eight GPU slots.
	 Four standard NIC slots.
	- Three OCP 3.0 NIC slots.
	 One built-in slot for a PCIe plug-in RAID controller card.
	The 20 x 2.5" drive switch model supports 18 PCle slots including:
	10 GPU slots.
	 Four standard NIC slots.
	 Three OCP 3.0 NIC slots.
	 One built-in PCle plug-in RAID controller card slot.
	The 24 x 3.5" drive pass-through model supports 12 PCle slots including:
	 Eight GPU slots.
	 One standard NIC slot.
	Two OCP 3.0 NIC slots.
	 One built-in PCle plug-in RAID controller card slot.
	 9 x 3.5" drives and 8 x dual-width GPU pass-through models support 10 PCIe slots.
	 Eight GPU slots.
	Two OCP 3.0 NIC slots.
	12 x 3.5" drives + 8 x dual-width GPUs provide 16 PCIe slots.
	 Eight GPU slots.
	 Four standard NIC slots.
	 Three OCP 3.0 NIC slots.
	 One built-in slot for a PCIe plug-in RAID controller card.
	10 x 3.5" drive pass-through model configuration
	Eight GPU slots.
	 Two OCP 3.0 NIC slots or One OCP 3.0 NIC slot + one standard NIC slot.
	 One built-in slot for a PCIe plug-in RAID controller card.
	For details, see 5.7.2 PCIe Slots and 5.7.3 PCIe Slot Description .
	NOTE
	The preceding information is for reference only. For details, see "Search Parts" in the compatibility list on the technical support website.

Category	Specifications
Ports	Supports a variety of ports. Ports on the front panel: One USB Type-C iBMC direct connect management port Two USB 3.0 ports One DB15 VGA port Ports on the rear panel: Two USB 3.0 ports One DB15 VGA port One DB15 VGA port One RJ45 serial port One RJ45 management network port
Video card	You are not advised to install the OS on the USB storage media. An SM750 video chip with 32 MB display memory is integrated on the BMC card. The maximum display resolution is 1920 x 1200 at 60 Hz with 16M colors. NOTE The integrated video card can provide the maximum display resolution (1920 x 1200) only after the video card driver matching the OS version is installed. Otherwise, only the default resolution supported by the OS is provided. If both the front and rear VGA ports are connected to monitors, only the monitor connected to the front VGA port displays information.
System management	 UEFI iBMC NC-SI Integration with third-party management systems
Security feature	 Power-on password Administrator password TPM (for China and outside China)/TCM (only for China) Secure boot Front bezel (optional) Chassis cover opening detection

6.2 Environmental Specifications

Table 6-2 Environmental specifications

Category	Specifications
Temperature	Operating temperature: 5°C to 35°C (41°F to 95 °F), compliant with ASHRAE Classes A1 and A2
	 Storage temperature (within three months): -30°C to +60°C (-22°F to +140°F)
	 Storage temperature (within six months): -15°C to +45°C (5°F to 113°F)
	 Storage temperature (within one year): -10°C to +35°C (14°F to 95°F)
	Maximum rate of temperature change: 20°C (36°F) per hour, and 5°C (9°F) per 15 minutes
	NOTE The highest operating temperature varies depending on the server configuration. For details, see A.3 Operating Temperature Limitations.
Relative humidity (RH,	Operating humidity: 8% to 90%
non-condensing)	Storage humidity (within three months): 8% to 85%
	Storage humidity (within six months): 8% to 80%
	Storage humidity (within one year): 20% to 75%
	Maximum rate of humidity change: 20% per hour
	Operational climatic range category 8% RH with -12°C (10.4°F) minimum dew point to 90% RH with 21°C (69.8°F) maximum dew point (ASHRAE Classes A2 compliant)
Air volume	≥ 330 CFM
Altitude	≤ 3050 m (10,006.56 ft)
	When the server configuration complies with ASHRAE Classes A1 and A2 and the altitude is above 900 m (2952.76 ft), the highest operating temperature decreases by 1°C (1.8°F) for every increase of 300 m (984.24 ft).
	HDDs cannot be used at an altitude of over 3050 m (10,006.56 ft).
Corrosive airborne contaminant	Maximum growth rate of the corrosive product thickness:
	Copper corrosion rate test: 300 Å/month (meeting level G1 requirements of the ANSI/ISA-71.04-2013 standard on gaseous corrosion)
	Silver corrosion rate test: 200 Å/month

Category	Specifications
Particle contaminant	The equipment room environment meets the requirements of ISO 14664-1 Class 8.
	There is no explosive, conductive, magnetic, or corrosive dust in the equipment room.
	NOTE It is recommended that the particulate pollutants in the equipment room be monitored by a professional organization.
Acoustic noise	The declared A-weighted sound power levels (LWAd) and declared average bystander position A-weighted sound pressure levels (LpAm) listed are measured at 23°C (73.4°F) in accordance with ISO 7779 (ECMA 74) and declared in accordance with ISO 9296 (ECMA 109).
	• Idle:
	- LWAd: 6.16Bels
	– LpAm: 49.4dBA
	Operating:
	- LWAd: 7.01Bels
	– LpAm: 57.4dBA
	NOTE Actual sound levels generated during server operation vary depending on server configuration, load, and ambient temperature.

◯ NOTE

SSDs and HDDs (including NL-SAS, SAS, and SATA) cannot be preserved for a long time in the power-off state. Data may be lost or faults may occur if the preservation duration exceeds the specified maximum duration. When drives are preserved under the storage temperature and humidity specified in the preceding table, the following preservation duration is recommended:

- Maximum preservation duration of SSDs:
 - 12 months in power-off state without data stored
 - 3 months in power-off state with data stored
- Maximum preservation duration of HDDs:
 - 6 months in unpacked/packed and powered-off state
- The maximum preservation duration is determined according to the preservation specifications provided by drive vendors. For details, see the manuals provided by drive vendors.

6.3 Physical Specifications

Table 6-3 Physical specifications

Category	Description	
Dimension (H x W x D)	175 mm × 447 mm × 898 mm (6.89 in. x 17.60 in. x 35.35 in.)	
	Figure 6-1 Physical dimensions (example: a chassis with 3.5" drives)	
	888 mm (87 80 m) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	NOTE • See Figure 6-1 for methods in measuring physical	
	dimensions of the chassis.	
	 The measuring method for chassis with 3.5" drives and that for chassis with 2.5" drives are the same. The chassis with 3.5" drives is used as an example. 	
Installation dimension requirements	Requirements for cabinet installation: Cabinet compliant with the International Electrotechnical Commission (IEC) 297 standard	
	Width: 482.6 mm (19.00 in.)	
	Depth: ≥ 1100 mm (43.31 in.)	
	Requirements for guide rails installation:	
	- The adjustable L-shaped guide rails apply to cabinets with a distance of 610 mm to 950 mm (24.02 in. to 37.40 in.) between the front and rear mounting bars.	
	 A ball bearing rail kit applies to cabinets with a distance of 609 mm to 950 mm (23.98 in. to 37.40 in.) between the front and rear mounting bars. 	

Category	Description		
Fully equipped weight	Net weight:		
	 Maximum weight of a server with 24 x 3.5" drives: 71 kg (156.53 lb) 		
	 Maximum weight of a server with 20 x 2.5" drives: 57 kg (125.66 lb) 		
	 Maximum weight of 9 3.5" drives: 69 kg (152.12 lb) 		
	 Maximum weight for server with 12 x 3.5" drives: 69 kg (152.12 lb) 		
	Packing materials: 24 kg (52.91 lb)		
	NOTE The data is for reference only. the actual weight shall prevail.		
Power consumption	Power consumption parameters vary with server configurations (including ErP-standard configurations). For details, see Power Calculator on the technical support website.		

Software and Hardware Compatibility

For details about the OS and hardware, see the compatibility list on the technical support website.

NOTICE

- If incompatible components are used, the device may be abnormal. Such a fault is beyond the scope of technical support and warranty.
- The performance of servers is closely related to application software, basic middleware software, and hardware. The slight differences of the application software, middleware basic software, and hardware may cause performance inconsistency between the application layer and test software layer.
 - If the customer has requirements on the performance of specific application software, contact technical support to apply for proof of concept (POC) tests in the pre-sales phase to determine detailed software and hardware configurations.
 - If the customer has requirements on hardware performance consistency, specify the specific configuration requirements (for example, specific drive models, RAID controller cards, or firmware versions) in the presales phase.

8 Safety Instructions

- 8.1 Security
- 8.2 Maintenance and Warranty

8.1 Security

General Statement

- Comply with local laws and regulations when operating devices. These safety instructions are only a supplement.
- The "DANGER", "WARNING", and "CAUTION" information in this document does not represent all the safety instructions, but supplements to the safety instructions.
- Observe all safety instructions provided on the device labels when installing hardware. Follow them in conjunction with these Safety Instructions.
- Operators of special types of work (such as electricians and operators of forklifts) must be certified or authorized by the local government or authority.

• WARNING


In a household scenario, operation of this device may cause wireless interference.

Personal Safety

- This device is not suitable for use in places where children may be present.
- Only certified or authorized personnel are allowed to install device.
- Discontinue any dangerous operations and take protective measures. Report anything that could cause personal injury or device damage to a project supervisor.
- Do not move devices or install cabinets and power cables in hazardous weather conditions.

- Do not carry the weight that is over the maximum load per person allowed by local laws or regulations. Check the maximum device weight and arrange required personnel.
- Wear clean protective gloves, ESD clothing, a protective hat, and protective shoes, as shown in **Figure 8-1**.

Figure 8-1 Protective clothing



 Before touching a device, wear ESD clothing and gloves (or wrist strap), and remove conductive objects (such as watches and jewelry). Figure 8-2 shows conductive objects that must be removed before you touch a device.


Figure 8-2 Removing conductive objects



Figure 8-3 shows how to wear an ESD wrist strap.

- a. Put your hands into the ESD wrist strap.
- b. Fasten the strap buckle and ensure that the ESD wrist strap is in contact with your skin.
- c. Insert the ground terminal attached to the ESD wrist strap into the jack on the grounded cabinet or chassis.

Figure 8-3 Wearing an ESD wrist strap



- Exercise caution when using tools.
- If the installation position of a device is higher than the shoulders of the
 installation personnel, use a vehicle such as a lift to facilitate installation. Prevent
 the device from falling down and causing personal injury or damage to the
 device.
- The device is powered by high-voltage power sources. Direct or indirect contact (especially through damp objects) with high-voltage power sources may result in serious injury or death.
- Ground a device before powering it on. Otherwise, high voltage leakage current may cause personal injury.
- When a ladder is used, ensure that another person holds the ladder steady to prevent accidents.
- Do not look into optical ports without eye protection when installing, testing, or replacing optical cables.

Device Security

- Use the recommended power cables at all times.
- Use power cables only for dedicated servers. Do not use them for other devices.
- Use dedicated power cables to ensure equipment and personal safety.
- When moving a device, hold the bottom of the device. Do not hold the handles of the installed modules, such as the PSUs, fan modules, drives, and the mainboard. Handle the device with care.
- Exercise caution to prevent damage to the device when using tools during installation or maintenance.
- Connect the primary and secondary power cables to different power distribution units (PDUs) to ensure reliable device operation.
- Ground a device before powering it on. Otherwise, high voltage leakage current may cause device damage.

Transportation Precautions

Improper transportation may damage device. Contact the manufacturer for precautions before attempting transportation.

Transportation precautions include but are not limited to:

 The logistics company engaged to transport the device must be reliable and comply with international standards for transporting electronics. Ensure that the device being transported is always kept upright. Take necessary precautions to prevent collisions, corrosion, package damage, damp conditions, and pollution.

- Transport each device in its original packaging.
- If the original packaging is unavailable, package heavy, bulky parts (such as chassis and blades) and fragile parts (such as PCIe cards and optical modules) separately.

◯ NOTE

For details about components supported by the server, see "Search Parts" in the compatibility list on the technical support website.

Ensure that all devices are powered off before transportation.

Maximum Weight Carried by a Person



The maximum weight allowed to be carried by a person is subject to local laws or regulations. The markings on the device and the descriptions in the documentation are for reference only.

Table 8-1 lists the maximum weight a person is permitted to carry as stipulated by a number of organizations.

Table 8-1 Maximum weight carried per person

Organization	Weight (kg/lb)
European Committee for Standardization (CEN)	25/55.13
International Organization for Standardization (ISO)	25/55.13
National Institute for Occupational Safety and Health (NIOSH)	23/50.72
Health and Safety Executive (HSE)	25/55.13
General Administration of Quality Supervision, Inspection and Quarantine of the People's Republic of China (AQSIQ)	Male: 15/33.08Female: 10/22.05

For more information about safety instructions, see Server Safety Information.

8.2 Maintenance and Warranty

For details about the maintenance policy, visit Customer Support Service.

For details about the warranty policy, visit Warranty.

9 System Management

The server the new-generation Intelligent Baseboard Management Controller (iBMC), which complies with Intelligent Platform Management Interface 2.0 (IPMI 2.0) specifications and provides highly reliable hardware monitoring and management.

The iBMC supports the following features and protocols:

Various management interfaces

The iBMC provides the following standard interfaces to meet various system integration requirements:

- DCMI 1.5 interface
- IPMI 1.5/IPMI 2.0 interface
- Command-line interface
- Redfish interface
- Hypertext Transfer Protocol Secure (HTTPS)
- Simple Network Management Protocol (SNMP)
- Fault monitoring and diagnosis

Faults can be detected and rectified in advance to ensure 24/7 stable running of the device.

- The iBMC allows screenshots and videos to be created when the system breaks down, facilitating cause analysis of the system breakdown.
- The iBMC offers screen snapshots and videos, simplifying routine preventive maintenance, recording, and auditing.
- The fault diagnose management (FDM) function supports component-based precise fault diagnosis, facilitating component fault locating and replacement.
- The iBMC supports the reporting of alarms through syslog packets, trap packets, and emails, helping the upper-layer NMS to collect the fault information about the server.
- Security management
 - Software image backup improves system security. Even if the running software breaks down, the system can be started from the backup image.
 - Diversified user security control interfaces are provided to ensure user login security.

- Multiple types of certificates can be imported and replaced to ensure data transmission security.
- System maintenance interface
 - The virtual KVM and virtual media functions facilitate remote maintenance.
 - Out-of-band RAID monitoring and configuration are supported to improve RAID configuration efficiency and management capability.
 - Smart Provisioning provides a convenient operation interface for installing the OS, configuring RAID, and performing the upgrade without a CD-ROM.
- Various network protocols
 - The NTP synchronizes network time to optimize time configuration.
 - The iBMC supports domain name system (DNS) and Lightweight Directory Application Protocol (LDAP) to implement domain management and directory service.
- Intelligent power management
 - The power capping technology helps you easily improve deployment density.
 - The iBMC uses dynamic power saving to reduce operational expenditure (OPEX).
- License Management

By managing licenses, you can use the features of the iBMC advanced edition in authorization mode.

Compared with the standard edition, the iBMC advanced edition provides more advanced features, such as:

- Implements the OS deployment using Redfish.
- Collect the original data of intelligent diagnosis using Redfish.

10 Certifications

Country/Region	Certification	Standard
China	ccc	GB4943.1-2011
		GB9254-2008 (Class A)
		GB17625.1-2012


1 1 Waste Product Recycling

If product users need product recycling service provided by xFusion after products are scrapped, contact technical support for services.



A.1 Chassis Label Information

A.1.1 Chassis Head Label



3	Quick access label	4	SN NOTE For details, see A.2 Product Serial Number.
5	Slide-out label plate NOTE The location of the slide-out label plate varies depending on the server model or configuration. For details, see 5.1.1 Appearance.	6	SN NOTE For details, see A.2 Product Serial Number.
7	Reserved space for the customized label	8	Pressure-proof label NOTE This label warns users not place any objects on top of a rack- mounted device.

A.1.1.1 Nameplate

Figure A-2 Sample nameplate




Table A-1 Nameplate description

No.	Description
1	Server model NOTE
	For details, see A.4 Nameplate.
2	Device name
3	Power supply requirements
4	Enterprise standard number
5	Vendor information
6	Certification marks

A.1.1.2 Certificate

Figure A-3 Certificate example



Table A-2 Certificate description

No.	Description
1	Order
2	No. NOTE For details, see Figure A-4 and Table A-3.
3	QC inspector
4	Production date
5	No. barcode

Figure A-4 Certificate number example



Table A-3 Certificate number description

No.	Description
1	P: a fixed value for this digit
2	Z : a fixed value for this digit
3	 Y: a server B: a semi-finished server N: a spare part

No.	Description
4	0: a value for the reserved digit
5	Year (two characters)
6	Month (one character) • Digits 1 to 9 indicate January to September respectively. • Letters A to C indicate October to December respectively.
7	Day (one character) • Digits 1 to 9 indicate the 1st to 9th. • Letters A to H indicate the 10th to 17th. • Letters J to N indicate the 18th to 22nd. • Letters P to Y indicate the 23rd to 31st.
8	Hour (one character) • Digits 0 to 9 indicate 0:00 to 9:00. • Letters A to H indicate 10:00 to 17:00. • Letters J to N indicate 18:00 to 22:00. • Letters P to Q indicate 23:00 to 24:00.
9	Serial number (two characters).
10	Manufacturing serial number (five characters).

A.1.1.3 Quick Access Label

Figure A-5 Quick access label example





Table A-4 Quick access label description

No.	Description	
1	Default IP address of the iBMC management network port	
2	Default subnet mask of the iBMC management network port	
3	Default iBMC username	
4	Default iBMC password	
5	Default BIOS password	
6	Technical support website	
7	P/N code	
8	QR code	
	NOTE Scan the QR code to obtain technical support resources.	

A.1.2 Chassis Internal Label

Figure A-6 Chassis internal label




◯ NOTE

- The quick start guide is located on the inside of the chassis cover. It describes how to remove the mainboard components, important components of the chassis, precautions, and QR codes of technical resources. The pictures are for reference only. For details, see the actual product.
- The quick start guide is optional. For details, see the actual product.

A.1.3 Chassis Tail Label

Figure A-7 Chassis tail label



◯ NOTE


For details about the warning label, see Server Security Information.

A.2 Product Serial Number

The serial number (SN) on the slide-out label plate uniquely identifies a device. The SN is required when you contact technical support. SN example 1 and SN example 2 show two SN examples.

SN example 1

Figure A-8 SN example 1



SN example 2

Figure A-9 SN example 2




Table A-5 SN description

No.	Description	
1	SN ID (two characters), which is 21.	
2	Material identification code (eight digits), that is, processing code.	
3	Vendor code (two digits), that is, the code of the processing place.	
4	 Year and month (two characters). The first character indicates the year. Digits 1 to 9 indicate years 2001 to 2009, respectively. Letters A to H indicate years 2010 to 2017, respectively. Letters J to N indicate years 2018 to 2022, respectively. Letters P to Y indicate years 2023 to 2032, respectively. NOTE The years from 2010 are represented by upper-case letters excluding I, O, and Z because the three letters are similar to the digits 1, 0, and 2. The second character indicates the month. Digits 1 to 9 indicate January to September, respectively. Letters A to C indicate October to December, respectively. 	
5	Sequence number (six characters).	
6	RoHS compliance (one character). Y indicates environmental-friendly processing.	
7	Internal model, that is, product name. The actual board model format may vary. For details, see the actual board model.	

A.3 Operating Temperature Limitations

Table A-6 Operating Temperature Limitations

Configuration	Maximum operating temperature: 30°C (86°F)	Maximum Operating Temperature: 35°C (95°F)
24 x 3.5" drive switch model configuration	When the number of front drives is less than or equal to 12, A40 GPUs are supported.	When the CPU power is higher than 270 W and the number of front drives is less than or equal to 12, A100/H100 GPUs are supported.
		 When the CPU power is 270 W or lower than 270 W and the number of front drives is less than or equal to 16, A100/H100 GPUs are supported. A40 GPUs are not supported.
20 x 2.5" drive switch model configuration	All configurations are supported.	A40 GPUs are not supported.
24 x 3.5" drive pass- through model configuration	When the number of front drives is less than or equal to 12, A40 GPUs are supported.	When the CPU power is higher than 270 W and the number of front drives is less than or equal to 12, A100/H100 GPUs are supported.
		 When the CPU power is 270 W or lower than 270 W and the number of front drives is less than or equal to 16, A100/H100 GPUs are supported. A40 GPUs are not supported.
9 x 3.5" drives + 8 x dual- width GPU pass-through model configuration	All configurations are supported.	A40 GPUs are not supported.

Configuration	Maximum operating temperature: 30°C (86°F)	Maximum Operating Temperature: 35°C (95°F)
24 x 3.5" drive switch model configuration	All configurations are supported.	A40 GPUs are not supported.
12 x 3.5" drives + 8 x dual-width GPUs + 1 DPU	 L20 GPU + BF3 card when the CPU power consumption is ≤ 270 W and the number of front drives is ≤ 8 L20 GPU + BF3 card when the CPU power consumption is > 270 W and the number of front drives is ≤ 4 	• No
10 x 3.5" drive pass- through configuration	All configurations are supported.	A40 GPUs are not supported.

◯ NOTE

- When a single fan is faulty, the highest operating temperature is 5°C (9°F) lower than the rated value.
- When a single fan is faulty, the system performance may be affected.
- It is recommended that servers be deployed at an interval of 1U to reduce server noise and improve server energy efficiency.

A.4 Nameplate

Certified Model	Remarks
G5500 V7	Global
H52GP-07	Global
Note: The nameplate depends on the actual product.	

A.5 RAS Features

The serThe server supports a variety of Reliability, Availability, and Serviceability (RAS) features. You can configure these features for better performance.

For details about RAS features, see the *Sapphire Rapids Platform Server RAS Feature Technical White Paper*.

A.6 Sensor List

Sensor	Description	Component
Inlet Temp	Air inlet temperature	Right mounting ear plate
Outlet Temp	Air outlet temperature	BMC card
PCH Temp	PCH bridge temperature	Mainboard
PCH Status	PCH chip fault diagnosis health status	Mainboard
1711 Core Temp	Core temperature of the 1711 chip	BMC card
SSD Max Temp	Maximum SSD temperature (reported by BMA)	SSD
CPUN Core Temp	CPU core temperature	CPUN
		N indicates the CPU number. The value is 1 or 2 .
CPUN DTS	Difference between the	CPUN
	real-time CPU temperature and the CPU core temperature threshold	N indicates the CPU number. The value is 1 or 2.
CPUN Margin	Difference between the	CPUN
	real-time CPU temperature and the CPU Tcontrol threshold	N indicates the CPU number. The value is 1 or 2 .
CPUN MEM Temp	Temperature of the	Memory module
	memory module corresponding to a CPU	orresponding to CPU N N indicates the CPU number. The value is 1 or 2.
CPUN 12V	12 V voltage supplied by	Mainboard
	the mainboard to the CPU	N indicates the CPU number. The value is 1 or 2.
CPUN Status	CPU status check	CPUN
		N indicates the CPU number. The value is 1 or 2 .

Sensor	Description	Component
CPUN Memory	Check of the status of the memory module corresponding to a CPU	Memory module corresponding to CPU <i>N N</i> indicates the CPU number. The value is 1 or 2 .
CPUN UPI Link	CPU UPI link fault	Mainboard or CPU N
	diagnosis health status	N indicates the CPU number. The value is 1 or 2 .
CPUN Prochot	CPU Prochot	CPUN
		N indicates the CPU number. The value is 1 or 2 .
CPUN VCCIN	CPU VCCIN voltage	Mainboard
		N indicates the CPU number. The value is 1 or 2 .
CPUN FIVRA	CPU FIVRA voltage	Mainboard or CPU N
		N indicates the CPU number. The value is 1 or 2 .
CPUN INFAON	CPU INFAON voltage	CPUN
		N indicates the CPU number. The value is 1 or 2 .
CPUN VCCFA	CPU VCCFA voltage	CPUN
		N indicates the CPU number. The value is 1 or 2 .
CPUN VCCD	CPU VCCD voltage	CPUN
		N indicates the CPU number. The value is 1 or 2 .
CPUN VRD Temp	CPU VRD temperature	Mainboard
		N indicates the CPU number. The value is 1 or 2 .
CPUN FIVRA Temp	CPU FIVRA temperature	CPUN
		N indicates the CPU number. The value is 1 or 2 .

Sensor	Description	Component
CPUN INFAON Temp	CPU INFAON temperature	CPUN N indicates the CPU number. The value is 1 or 2.
CPUN VCCFA Temp	CPU VCCFA temperature	CPUN N indicates the CPU number. The value is 1 or 2.
CPUN VCCD Temp	CPU VCCD temperature	CPUN N indicates the CPU number. The value is 1 or 2.
PSN VIN	PSU N input voltage	PSU N N indicates the PSU number. The value ranges from 1 to 4.
PS\$ IIn	PSU input current	PSU
PS\$ IOut	PSU output current	PSU
PS\$ POut	PSU output power	PSU
PS\$ Temp	Maximum internal temperature of the PSU	PSU
PS\$ Inlet Temp	PSU air inlet temperature	PSU
PSN Status	PSU fault status	PSU N N indicates the PSU number. The value ranges from 1 to 4.
PSN Fan Status	PSU fan fault status	PSU N N indicates the PSU number. The value ranges from 1 to 4.
PSN Temp Status	PSU presence status	PSU N N indicates the PSU number. The value ranges from 1 to 4.
PS Redundancy	Redundancy failure due to PSU removal	PSU
Power	Server input power	PSU

Sensor	Description	Component
Disks Temp	Maximum drive temperature	Drives
Power <i>N</i>	PSU input power	PSU N N indicates the PSU number. The value ranges from 1 to 4.
FANN F Speed	Fan speed	Fan module <i>N</i>
FANN R Speed		N indicates the fan module number. The value ranges from 1 to 8 .
FANN F Status	Fan fault status	Fan module N
FANN R Status		N indicates the fan module ID. The value is 1A, 1B, 2A, 2B, 3A, 3B, 4A, or 4B.
FANN F Presence	Fan module presence	Fan module <i>N</i>
FANN R Presence		N indicates the fan module ID. The value is 1A, 1B, 2A, 2B, 3A, 3B, 4A, or 4B.
DIMMN	DIMM status	DIMM N
		N indicates the DIMM slot number.
RTC Battery	RTC battery status. An alarm is generated when the voltage is lower than 1 V.	RTC battery on the mainboard
Power Button	Power button pressed state	Mainboard and power button
Watchdog2	Watchdog	Mainboard
Mngmnt Health	Management subsystem health status	Management module
UID Button	UID button status	Mainboard
PwrOk Sig. Drop	Voltage drop status	Mainboard
PwrOn TimeOut	Power-on timeout	Mainboard
PwrCap Status	Power capping status	Mainboard
HDD Backplane	Entity presence	Drive Backplane

Sensor	Description	Component	
HDD BP Status	Drive backplane health status	Drive Backplane	
HDD BP\$ Temp	HDD backplane temperature	Drive Backplane	
RiserN Card	Entity presence	Riser card N	
		N indicates the riser card slot number. The value is 1 or 2 .	
RiserN 12V	12 V voltage supplied by	Mainboard	
	the mainboard to the riser card	N indicates the riser card slot number. The value is 1 or 2 .	
Riser\$ Temp	Riser card temperature	Riser card	
SAS Cable	Entity presence	SAS cable on the mainboard	
LCD Status	LCD health status	LCD	
LCD Presence	LCD presence	LCD	
DISK\$	Drive status	Drives	
RAID Presence	RAID controller card presence	RAID controller card	
RAID Temp	Temperature of the RAID controller card	RAID controller card	
Raid BBU Temp	BBU temperature of the RAID controller card	Supercapacitor of the RAID controller card	
PCIE Status	PCle status error	PCIe Card	
PCIe\$ OP Temp	PCle card optical module temperature sensor	PCle Card	
PCIe\$ Temp	PCle card chip temperature sensor	PCle Card	
PCIe RAID\$ Temp	PCIe RAID controller card temperature	PCIe RAID controller card	
PCIe\$ Card BBU	BBU status of the PCIe RAID controller card		
PCIe NIC\$ Temp	PCle card chip temperature sensor	PCIe Card	
PCIe FC\$ Temp	PCle card chip temperature sensor	PCIe Card	

Sensor	Description	Component	
IB\$ Temp	IB NIC temperature sensor	IB card	
M2 Adapter Temp	M.2 adapter temperature	M.2 adapter card	
M2Disk1	Status of the M.2 drive on the riser card	M.2 adapter card	
M2Disk2	Status of the M.2 drive on the riser card	M.2 adapter card	
AreaIntrusion	Listening to the unpacking action	Mainboard	
OCP\$ OP Temp	OCP card optical module temperature sensor	OCP 3.0 NIC	
OCP\$ Temp	OCP card chip temperature sensor	OCP 3.0 NIC	
SSD Disk\$ Temp	SSD temperature	SSD	
GPU\$ Power	GPU power	GPU	
GPU\$ Temp	GPU temperature	GPU	
System Notice	Hot restart reminder and fault diagnosis program information collection	N/A	
System Error	System suspension or restart. Check the background logs.		
ACPI State	ACPI status		
SysFWProgress	Software processes and system startup errors		
SysRestart	System restart causes		
Boot Error	Boot error		
CPU Usage	CPU usage		
Memory Usage	Memory usage		
BMC Boot Up	BMC startup event		
BMC Time Hopping	Time hopping		
NTP Sync Failed	NTP synchronization failure and recovery events		
SEL Status	SEL full or events being cleared		

Sensor	Description	Component
Op. Log Full	Operation log full or events being cleared	
Sec. Log Full	Security log full or events being cleared	
Host Loss	System monitoring software (BMA) link loss detection	
ProductID Status	Product identification status	

A.7 FAQs About Optical Modules

The server NIC must be used with optical modules that have passed the compatibility test of xFusion. With uncertain transmission reliability, optical modules that have not been tested for compatibility may affect the service stability. xFusion is not liable for any problems caused by the use of optical modules that have not been tested for compatibility by xFusion and will not fix such problems in principle.

When performing the compatibility tests on the optical modules used by servers, xFusion comprehensively verifies their functions to ensure their quality. The verified items include optical module plugging or unplugging, transmit and receive optical power, signal transmission quality, basic data reading, error tolerance, compatibility, electromagnetic compatibility (EMC), and environmental performance.

Table A-7 Problems of using optical modules that have not been tested for compatibility and corresponding causes

Symptom	Cause
Due to non-standard structure and size, an optical module fails to be inserted into the optical interface or removed after being inserted.	Structures or sizes of some optical modules that have not been tested for compatibility do not comply with the Multi-Source Agreement (MSA). When such an optical module is installed on an optical interface, the size of this optical module hinders optical module installation on adjacent optical interfaces. In addition, optical modules can be unlocked through self-unlocking, press-unlocking, push-unlocking, or tilt-unlocking. For optical modules that have not been tested for compatibility, the server may not be able to have the optical modules removed that are not unlocked through press-unlocking.
Data bus defects cause the data bus suspension of a device.	Some optical modules that have not been tested for compatibility have defects in data bus designs. Using such an optical module causes suspension of the connected data bus on the device. As a result, data on the suspended bus cannot be read.

Symptom	Cause
An optical module with improper edge connector size damages electronic components of the optical interface.	If an optical module that has not been tested for compatibility with improper edge connector size is used on an optical interface, electronic components of the optical interface will be damaged by short circuits.
Unnormalized temperature monitoring causes incorrect alarms.	The temperature monitoring systems of some optical modules that have not been tested for compatibility do not comply with industry standards and report temperature values higher than the real temperature. When such optical modules are used, the system will report incorrect temperature alarms.
Improper register settings cause errors or failures in reading parameters or diagnostic information.	Some optical modules that have not been tested for compatibility have improper register values on page A0, which can cause errors or failures when the data bus attempts to read parameters or diagnostic information.
Optical modules bring electromagnetic interference to nearby devices.	Some optical modules that have not been tested for compatibility are not designed in compliance with EMC standards and have low anti-interference capability. Additionally, they bring electromagnetic interference to nearby devices.
Services are interrupted when an optical module is operating under overtemperature.	The operating temperature ranges of optical modules that have not been tested for compatibility cannot meet service requirements. When they are used under a relatively high temperature, the optical power decreases, resulting in service interruption.
Optical modules cannot work properly when the temperature change rate exceeds the normal range without adapting to the heat dissipation policy of the server.	Some optical modules that are not tested for compatibility have poor heat dissipation. Since they are not adapted to the heat dissipation policy of the server, abnormally high temperatures may occur continuously after they are running for a period of time. As a result, the optical modules cannot work properly.

B Glossary

B.1 A-E

В

baseboard management controller (BMC)	The BMC complies with the Intelligent Platform Management Interface (IPMI). It collects, processes, and stores sensor signals, and monitors the operating status of components. The BMC provides the hardware status and alarm information about the managed objects to the management system so that the management system can implement unified management of the devices.

Ε

ejector lever	A part on the panel of a device used to facilitate installation or removal of the device.
Ethernet	A baseband local area network (LAN) architecture developed by Xerox Corporation by partnering with Intel and DEC. Ethernet uses the Carrier Sense Multiple Access/Collision Detection (CSMA/CD) access method and allows data transfer over various cables at 10 Mbit/s. The Ethernet specification is the basis for the IEEE 802.3 standard.

B.2 F-J

G

Gigabit Ethernet (GE)	An extension and enhancement of traditional shared media Ethernet standards. It is compatible with 10 Mbit/s and 100 Mbit/s Ethernet and
	complies with IEEE 802.3z standards.

Н

·	Replacing or adding components without stopping or shutting down the
	system.

B.3 K-O

K

	A hardware device that provides public video, keyboard and mouse (KVM).
	video, keyboard and mouse (Kvivi).

B.4 P-T

Ρ

panel	An external component (including but not limited to ejector levers, indicators, and ports) on the front or rear of the server. It seals the front and rear of the chassis to ensure optimal ventilation and electromagnetic compatibility (EMC).
-------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Peripheral Component Interconnect Express (PCIe)	A computer bus PCI, which uses the existing PCI programming concepts and communication standards, but builds a faster serial communication system. Intel [®] is the main sponsor for PCIe. PCIe is used only for internal interconnection. PCIe is based on the existing PCI system. Therefore, the existing PCI system can be converted into PCIe only by modifying the physical layer without modifying the software. PCIe has a faster rate. It can replace almost all existing internal buses (including AGP and PCI).
-----------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

R

redundancy	A mechanism that allows a backup device to automatically take over services from a faulty device to ensure uninterrupted running of the system.
redundant array of independent disks (RAID)	A storage technology that combines multiple physical drives into a logical unit for the purposes of data redundancy and performance improvement.

S

server	A special computer that provides services for clients over a network.
Standby 12 V Out (SV12)	Standby 12 V output of the PSU.
System event log (SEL)	Event records stored in the system used for subsequent fault diagnosis and system recovery.

B.5 U-Z

U

U	A unit defined in International Electrotechnical Commission (IEC) 60297-1 to measure the height of a cabinet, chassis, or subrack. 1 U = 44.45 mm = 1.75 in.
UltraPath Interconnect (UPI)	A point-to-point processor interconnect developed by Intel [®] .

C Acronyms and Abbreviations

C.1 A-E

Α

AC	alternating current
AES	Advanced Encryption Standard New Instruction Set
ARP	Address Resolution Protocol
AVX	Advanced Vector Extensions

В

BBU	backup battery unit
BIOS	Basic Input/Output System
ВМС	Baseboard Management Controller

C

CCC	China Compulsory Certification
CD	calendar day
CE	Conformite Europeenne
CIM	Common Information Model
CLI	command-line interface

D

DC	direct current
DDR4	Double Data Rate 4
DDDC	double device data correction
DEMT	Dynamic Energy Management Technology
DIMM	dual in-line memory module
DRAM	dynamic random-access memory
DVD	digital video disc

Ε

ECC	error checking and correcting
ECMA	European Computer Manufacturer Association
EDB	Execute Disable Bit
EID	Enclosure ID (backplane ID)
EN	European Efficiency
ERP	enterprise resource planning
ETS	European Telecommunication Standards

C.2 F-J

F

FB-DIMM	Fully Buffered DIMM
FC	Fiber Channel
FCC	Federal Communications Commission
FCoE	Fibre Channel Over Ethernet
FTP	File Transfer Protocol

G

GE	Gigabit Ethernet
GPIO	General Purpose Input/Output
GPU	graphics processing unit

Н

НА	high availability
HDD	hard disk drive
HPC	high-performance computing
НТТР	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure

I

івмс	Intelligent Baseboard Management Controller
IC	Industry Canada
ICMP	Internet Control Message Protocol
IDC	Internet Data Center
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Message Protocol
IOPS	input/output operations per second
IP	Internet Protocol
IPC	intelligent power capability
ІРМВ	Intelligent Platform Management Bus
IPMI	Intelligent Platform Management Interface

C.3 K-O

K

KVM	keyboard, video, and mouse
-----	----------------------------

L

LC	Lucent connector
LRDIMM	load-reduced dual in-line memory module
LED	light emitting diode
LOM	LAN on motherboard

M

MAC	media access control
ммс	module management controller

N

NBD	next business day
NC-SI	Network Controller Sideband Interface

0

ОСР	Open Compute Project

C.4 P-T

Ρ

PCle	Peripheral Component Interconnect Express

PDU	power distribution unit
PHY	physical layer
PMBUS	power management bus
РОК	power OK
PWM	pulse-width modulation
PXE	Preboot Execution Environment

R

RAID	redundant array of independent disks
RAS	reliability, availability and serviceability
RDIMM	registered dual in-line memory module
REACH	Registration Evaluation and Authorization of Chemicals
RJ45	registered jack 45
RoHS	Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment

S

SAS	Serial Attached Small Computer System Interface
SATA	Serial Advanced Technology Attachment
SCM	supply chain management
SDDC	single device data correction
SERDES	serializer/deserializer
SGMII	serial gigabit media independent interface
SMI	serial management interface
SMTP	Simple Mail Transfer Protocol
SNMP	Simple Network Management Protocol
SOL	serial over LAN

SONCAP	Standards Organization of Nigeria- Conformity Assessment Program
SSD	solid-state drive
SSE	Streaming SIMD Extensions

Т

TACH	tachometer signal
ТВТ	Turbo Boost Technology
TCG	Trusted Computing Group
TCM	trusted cryptography module
тсо	total cost of ownership
TDP	thermal design power
TELNET	Telecommunication Network Protocol
TET	Trusted Execution Technology
TFM	TransFlash module
TFTP	Trivial File Transfer Protocol
TOE	TCP offload engine
TPM	trusted platform module

C.5 U-Z

U

UBC	Union Bus Connector
UBC DD	Union Bus Connector Double Density
UDIMM	unbuffered dual in-line memory module
UEFI	Unified Extensible Firmware Interface
UID	unit identification light
UL	Underwriter Laboratories Inc.
UPI	UltraPath Interconnect
USB	Universal Serial Bus

٧

VCCI	Voluntary Control Council for Interference by Information Technology Equipment
VGA	Video Graphics Array
VLAN	Virtual local area network
VRD	Voltage regulator-down
VROC	Virtual RAID on CPU

W

WEEE	Waste Electrical and Electronic Equipment
WSMAN	Web Service Management